Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun 54B

Braun Series 5 Electric Shaver Replacement Head User Manual

Model: 54B

Introduction

This manual provides essential information for the proper use, maintenance, and replacement of your Braun Series 5 Electric Shaver Replacement Head. Designed for optimal performance, this replacement head ensures a shave as efficient as day one, maintaining the quality and comfort you expect from Braun.

Safety Information

For your safety and to ensure the longevity of your shaver, please observe the following precautions:

- Ensure the shaver is clean and dry before attaching the new head.
- Always turn off and unplug the shaver before cleaning.
- Be cautious when handling the shaver to avoid cuts.
- Clean and dry the shaver regularly to prevent bacterial growth.
- Do not use the shaver near water or while charging the device.

Compatibility

This Braun Series 5 Electric Shaver Replacement Head (Model 54B) is designed to work best with Braun Series 5 Shavers: 5118s, 5120s, and 5150cs. It is also compatible with all Braun Series 5, 6, and 7 flex new generation shavers (models from 2020 onwards).



Image: The replacement head is compatible with new generation Braun Series 5 shavers, featuring an easy click attachment.

Setup and Installation

Replacing your shaver head is a simple process designed for user convenience. For optimal performance, it is recommended to replace the foil and knife block every 18 months.

1. To remove the old shaver head, slide the spare part from front to back.
2. Click your new Braun shaving head into position. Ensure it is securely fastened.




Image: Step-by-step guide on how to replace your shaver head for optimal performance.

Operating Instructions

Once the new replacement head is installed, your Braun shaver is ready for use. The new head provides enhanced cutting efficiency for a closer shave compared to previous Braun Series 5 models.

- Ensure your shaver is charged before use.
- Turn on the shaver and gently glide the head across your skin, moving against the direction of hair growth.
- The 3 Flex blades adapt to your facial contours for a comfortable and close shave, even in tricky areas.




Image: The shaver head is designed for a closer shave, even in hard-to-reach areas.

Maintenance

Regular cleaning of your shaver head is crucial for maintaining performance and hygiene. The Braun Series 5 shaver features an "EasyClean" system.

- After each shave, rinse the shaver head under running water.
- For a more thorough clean, you may detach the head and rinse both the head and the shaver body.
- Allow all parts to air dry completely before reassembling or storing.



Image: The 3 Flex blades adapt to contours for a close shave, and the shaver features an EasyClean design.

Troubleshooting

If you notice a decrease in shaving efficiency or comfort, it is likely due to the natural wear of the cutting edges over time. Braun recommends replacing the foil and knife block every 18 months to maintain peak performance.



Image: Replace the shaver head every 18 months to maintain your best shave.

Specifications

Feature	Detail
Product Dimensions	3.15 x 0.79 x 5.79 inches; 0.71 ounces
Item Model Number	54B
UPC	069055140239
Manufacturer	Procter & Gamble
Brand	Braun
Recommended Uses	Beard, Face
Special Feature	Detachable Head

Model Name	Series 5

Warranty and Support

For detailed warranty information and customer support, please refer to the official Braun website or contact Braun customer service directly. Product authenticity can be verified via the Transparency code on the packaging.
Each item has a unique code that Braun verifies before shipping, ensuring you receive a genuine product.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CP6VJ6BN

More documents and user manuals: **https://manuals.plus/**