Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Waterdrop WD-ED04B-L

Waterdrop Mega Electric Water Filter Dispenser User Manual

Model: WD-ED04B-L

Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Waterdrop Large 27-Cup Mega Electric Water Filter Dispenser. Please read this manual thoroughly before using the product and retain it for future reference.

Safety Information

- Ensure the dispenser is placed on a stable, flat surface.
- Do not immerse the electrical components in water. Clean with a damp cloth.
- Use only the provided charging cable for recharging.
- Keep out of reach of children to prevent accidental spills or misuse.
- Do not use with water temperatures exceeding 101 degrees Fahrenheit (38 degrees Celsius).
- This system does not lower TDS value. If low TDS water is desired, please use a different Waterdrop model designed for TDS reduction.

Package Contents

- Waterdrop Large 27-Cup Mega Electric Water Filter Dispenser (Main Unit)
- 1 x Water Filter Cartridge
- USB-C Charging Cable
- Cleaning Brush
- User Manual (this document)

Setup

1. **Unpacking and Initial Cleaning**
   Carefully remove all components from the packaging. Wash the water container and lid with mild soap and warm

water. Rinse thoroughly. Do not wash the main electrical unit with water; wipe it with a damp cloth.

2. **Filter Installation**

   The filter cartridge is typically pre-installed. If not, align the buckles of the filter to the notches of the water pumping unit and insert the new filter until a "click" sound is heard, indicating it is securely in place.



Image: Effortless Filter Replacement. This image illustrates the four steps for replacing the water filter: 1. Pull out the water pumping unit and place a water container below. 2. Push the filter inwards and pull it out by pinching buckles on two sides. 3. Align the buckles of the filter to notches of the water pumping unit. 4. Insert a new filter until a "click" sound is heard.

3. **Initial Charging**

   Before first use, fully charge the dispenser using the provided USB-C cable. The power indicator light will show charging status.



Image: 30-day Prime Pure Performance. This diagram highlights the power indicator and filter life indicator on the dispenser. It also notes the 30-day battery life (5,000 mAh) on a single charge, assuming 101-135 oz of water is taken daily.

Operating Instructions

1. **Filling the Water Container**

   Remove the top lid. Fill the stainless steel water container with tap water up to the "MAX" fill line. Replace the lid securely.



Image: Larger than Larger: 27 Cups Ultra-large Capacity. This image shows the Waterdrop dispenser with its dimensions (12"W x 7.1"D x 10.2"H) and highlights its 27-cup ultra-large capacity, catering to multi-person hydration needs.

2. **Dispensing Water**

   Place your cup or container under the dispenser spout. Tap the touch-sensitive button on the top of the spout once to activate the blue indicator light. Tap it a second time to begin dispensing filtered water. Tap again to stop the flow.



Image: Get Pure Water without Waiting. This image demonstrates the rapid dispensing of water from the Waterdrop filter, emphasizing its 0.8 L/min filtration speed and 1-second water dispensing with a single touch.

3. **Filter Performance**

   The filter is designed to reduce over 45 substances, including chlorine, lead, mercury, benzene, bisphenol A, PFOA, and PFOS. It is NSF/ANSI 42, 53, 401 & 372 certified.



Image: Reduces 45+ Contaminants in Water. This diagram illustrates the filtration process, showing how the Waterdrop E-PureTech Filter reduces over 45 contaminants, including chlorine, taste & odor, lead, benzene, PFOS, and PFOA, with 10X filtration efficiency. It explicitly states that it does not reduce TDS.



Image: NSF/ANSI 42, 53, 401 & 372 Certified. This image displays the NSF/ANSI certifications, confirming the filter's ability to reduce various contaminants and its lead-free, food-grade materials.

Maintenance

- **Cleaning**

  Regularly clean the water container and lid with mild soap and water. Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the electrical components.

- **Filter Replacement**

  The filter cartridge should be replaced every 200 gallons or approximately every 3 months, whichever comes first. The filter life indicator on the dispenser will signal when a replacement is needed. Refer to the "Filter Installation" section under Setup for replacement steps.

- **Charging**

  Recharge the dispenser when the power indicator light signals low battery. A full charge provides approximately 30 days of battery life.

Troubleshooting

Problem	Possible Cause	Solution
No water dispenses.	Low battery; water container empty; filter not properly installed.	Charge the unit; refill water container; re-install filter until "click" is heard.
Water tastes unusual.	Filter needs replacement; initial use residue.	Replace filter; for initial use, discard the first few liters of filtered water.
Dispenser leaks.	Lid or filter not properly sealed.	Ensure lid is securely placed and filter is correctly installed.
Indicator lights not working.	Low battery; electrical malfunction.	Charge the unit. If problem persists, contact customer support.

Specifications

Feature	Detail
Brand	Waterdrop
Model Name	WD-ED04B-L
Capacity	27 Cups (approx. 6.4 Liters)
Filter Lifespan	200 Gallons or 3 Months
Filtration Speed	0.8 Liters Per Minute
Battery Life	Approx. 30 days on a single charge (5,000 mAh)
Product Dimensions	7.1"L x 12"W x 10.2"H
Certifications	NSF/ANSI 42, 53, 401 & 372 Certified
Contaminant Reduction	Reduces 45+ substances including chlorine, lead, mercury, benzene, bisphenol A, PFOA, PFOS. Does not lower TDS.

Warranty Information

Waterdrop products typically come with a manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Waterdrop website for detailed warranty terms and conditions. Retain your proof of purchase for warranty claims.

Support

For further assistance, technical support, or to purchase replacement filters, please contact Waterdrop Customer Service:

Website: www.waterdropfilter.com

Email: Refer to the official website for contact email.

Phone: Refer to the official website for contact phone number.

You can also visit the Waterdrop Store on Amazon for product information and support:Waterdrop Amazon Store

© 2025 Waterdrop. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPJB524Q

More documents and user manuals: **https://manuals.plus/**