Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Waterdrop WD-ED02W

Waterdrop Compact Electric Water Filter Pitcher User Manual

Model: WD-ED02W

Introduction

Welcome to your new Waterdrop Compact Electric Water Filter Pitcher. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your water filter pitcher to ensure you enjoy clean, filtered water.



The Waterdrop Compact Electric Water Filter Pitcher and its filter cartridge.

Product Overview and Components

Familiarize yourself with the main components of your Waterdrop Electric Water Filter Pitcher.



Key features of the Waterdrop pitcher, including the power indicator, filter life indicator, and IPX5 waterproof rating.

- **Water Pumping Unit:** Houses the electronic components, power indicator, and filter life indicator.
- **Water Reservoir:** The main body of the pitcher with a 14-cup capacity for unfiltered water.
- **Filter Cartridge:** Provides 200 gallons or 3 months of filtration.
- **USB-C Charging Port:** For recharging the internal battery.
- **Handle:** Integrated handle for easy portability.

Setup Guide

Initial Charging

Before first use, fully charge the pitcher. The built-in battery offers approximately 30 days of life on a single charge.

- Locate the USB-C charging port on the side of the water pumping unit.
- Connect the provided USB-C cable to the port and a power source.
- The power indicator light will show charging status.

Filter Installation

Follow these steps to install the filter cartridge:



A visual guide demonstrating how to replace the filter cartridge in four simple steps.

1. Pull out the water pumping unit.
2. Push the filter inwards, and pull the filter out by pinching buckles on two sides.
3. Align the buckles of the filter to notches of the water pumping unit.
4. Insert a new filter until a slight "click" sound is heard, indicating it's securely in place.

First Use & Flushing

For optimal performance and taste, flush the filter before first use.

1. Fill the water reservoir with tap water.
2. Dispense and discard the first few cups of filtered water to remove any carbon fines.
3. Repeat until water runs clear and tastes fresh.

Operating Instructions

Filling the Reservoir

Open the lid and pour unfiltered water into the reservoir. Ensure water does not enter the water pumping unit space.

Dispensing Water

Place a cup or container under the dispenser spout. Press the water drop button on the top of the unit to start dispensing. Press again to stop.



The pitcher provides instant water dispensing, reducing waiting time for filtered water.

Portability

The compact design and long battery life allow you to easily move and use the pitcher in various settings, including your kitchen, bedroom, or even for outdoor activities like camping.



Enjoy clean water anywhere with the portable Waterdrop pitcher.

Maintenance and Care

Filter Replacement

The filter should be replaced every 200 gallons or 3 months, whichever comes first. The filter life indicator light will blink red when replacement is needed. Refer to the "Filter Installation" section for replacement steps.



Large Capacity, Compact Size

Suitable for any place

The filter is designed for a long lifespan, providing 200 gallons or 3 months of filtered water.

Cleaning Instructions

Regularly clean the pitcher and its components to maintain hygiene and performance.

- Disassemble the pitcher components (reservoir, lid, pumping unit).
- Wash the reservoir and lid with mild soap and warm water. Do not wash the electronic pumping unit in a dishwasher or submerge it in water.
- Wipe the exterior of the pumping unit with a damp cloth.
- Ensure all parts are completely dry before reassembling.
- Pay attention to the drainage hole at the bottom of the water feeder space and clean it regularly to prevent water accumulation.

Troubleshooting

Problem	Possible Cause	Solution
No water dispenses	Low battery	Charge the unit using the USB-C port.

Problem	Possible Cause	Solution
No water dispenses	Filter not installed correctly	Reinstall the filter, ensuring it clicks into place.
Water tastes unusual	New filter needs flushing	Discard the first few cups of water after new filter installation.
Water tastes unusual	Filter needs replacement	Replace the filter cartridge. The filter life indicator will blink red.
Water leakage	Water poured into pumping unit space	Ensure water is only poured into the reservoir. Clean the drainage hole if necessary.

Product Specifications

- **Model Name:** WD-ED02W
- **Brand:** Waterdrop
- **Capacity:** 14-Cup (approx. 1 gallon)
- **Filter Lifespan:** 200 Gallons or 3 Months
- **Power Source:** Battery Powered (5000 mAh battery, approx. 30-day life)
- **Installation Type:** Countertop
- **Special Features:** Reduces Chlorine, Lead, Mercury, Benzene, Bisphenol A, PFAS, and more.
- **Certifications:** NSF/ANSI 42, 53, 401 & 372 Certified by IAPMO.
- **Product Dimensions:** 10.2 x 10.6 x 4.6 inches
- **Item Weight:** 5.34 pounds
- **Waterproof Rating:** IPX5



The pitcher is certified by IAPMO against NSF/ANSI standards for reducing various contaminants.



Its compact size allows it to fit conveniently inside most refrigerators.

Warranty and Support

For warranty information and customer support, please visit the official Waterdrop website or contact their customer service.

You can also refer to the official user manual PDF for detailed information:Waterdrop User Manual (PDF)

For additional information and products, visit the Waterdrop Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CPLS71CK

More documents and user manuals: **https://manuals.plus/**