Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ADIMO BGX-M/D-K1

ADIMO Biometric Handgun Safe Instruction Manual

Brand: ADIMO | Model: BGX-M/D-K1

1. Introduction

Welcome to the instruction manual for your new ADIMO Biometric Handgun Safe. This safe is designed to provide superior security and quick access to your firearms and valuables through advanced biometric technology, a secure keypad, and traditional key access. Please read this manual thoroughly before operating your safe to ensure proper setup and usage.

2. Key Features

2.1 Advanced Biometric Technology

The ADIMO gun safe features cutting-edge biometric fingerprint technology, ensuring superior security and rapid access to your firearm. This system is more reliable than traditional keypad locks and allows for single-handed access with a high-resolution fingerprint scanner. It can store up to 32 user fingerprints, allowing multiple authorized users to access the safe without hassle, ensuring accurate recognition.



Image: The biometric fingerprint scanner on the ADIMO safe, highlighting its quick and secure access.

2.2 Three Ways Quick Access

The biometric handgun safe offers instant access via three methods: biometric fingerprint, a 5-digit backlit keypad, and two backup keys. The automatic opening door allows for firearm access within 3 seconds using fingerprint, ensuring readiness. A silent mode feature allows muting the keypad beep for discreet entry.



Image: Visual representation of the three unlocking methods: fingerprint, key, and keypad.

▶ **Watch video online**

ADIMO Gun Safe, Biometric Gun Safe for Pistols, Handgun

Video: Demonstrates the various access methods including keypad, fingerprint, and key, along with battery installation and mute mode.

2.3 Sturdy and Secure Construction

Constructed with a sturdy 1.8mm thickened steel lid and a pry-resistant door, this gun safe is designed to withstand break-in attempts. A reliable high-strength locking mechanism and precise fittings ensure your firearms are always secure. The safe includes a steel wire rope and 2 screws for easy mounting, a backlit keyboard, and LED lights for quick access in the dark during emergencies.



Image: The safe's dimensions and capacity, illustrating its robust design.

2.4 Child Safety

For families with children, the ADIMO biometric gun safe provides a solution for balancing firearm accessibility and safety. Its fingerprint access ensures firearms are secure yet quickly accessible in emergencies, keeping them out of children's reach.



Image: The safe positioned in a home environment, highlighting its role in protecting families.

2.5 Capacity and Interior Protection

The safe can securely hold 2 standard handguns and extra ammunition. It can also store other valuables like jewelry. The interior is lined with soft foam to prevent scratches. Its lightweight and compact size allows for placement in a car, nightstand, drawer, or bedside.



Image: The main product image, showcasing the safe's interior capacity and included accessories.

2.6 Low Battery Alarm

When the battery is low, the red light on the fingerprint button flashes 4 times, indicating it's time to replace the batteries (AA*4 batteries, not included).



Image: The safe's power awareness feature, showing the low battery indicator.

2.7 Emergency USB Power Port

The ADIMO pistol safe includes a built-in USB power port, ensuring continuous power even if the battery dies or backup keys are lost. This port allows connection to an adapter, power bank, or car charger for temporary power, ensuring constant security and accessibility. Note: This feature does not charge the internal batteries.



Image: The safe's emergency USB power port in use, providing temporary power.

3. Setup

3.1 Battery Installation

The safe requires 4 AA batteries (not included) for operation. The battery compartment is located inside the safe, behind the front panel. Ensure correct polarity when inserting batteries.

3.2 Initial Access and Default Password

For first-time access, use the default password:**12345#**. Alternatively, use one of the provided backup keys by inserting it into the hidden keyhole located behind the ADIMO logo plate on the front panel.

3.3 Mounting the Safe

The safe comes with a steel wire rope and 2 screws for secure mounting. You can attach the safe to a fixed object or furniture to prevent unauthorized removal.



Image: The safe's security cable attachment point, demonstrating how to secure it.

4. Operating the Safe

4.1 Setting/Changing Passcode

1. Open the safe.
2. Locate the 'SET' button inside the safe (usually near the battery compartment).
3. Short press the 'SET' button. The keypad lights will illuminate.
4. Enter your desired 4-8 digit password, followed by '#'.

5. Re-enter the same password, followed by '#', to confirm.
6. A successful beep indicates the password has been set.

4.2 Setting/Changing Fingerprints

1. Open the safe.
2. Short press the 'SET' button. The keypad lights will illuminate.
3. Place your finger on the fingerprint sensor. The sensor will beep and turn green.
4. Lift and place your finger on the sensor two more times (total of 3 times continuously).
5. A successful beep indicates the fingerprint has been set. The safe can store up to 32 fingerprints.

4.3 Unlocking with Keypad

Press any key to wake up the keypad. Enter your programmed 4-8 digit password followed by '#'. The safe will open automatically.

4.4 Unlocking with Fingerprint

Place your registered finger on the fingerprint sensor. The safe will open automatically upon successful recognition.

4.5 Unlocking with Key

Locate the hidden keyhole behind the ADIMO logo plate on the front panel. Insert one of the provided backup keys and turn it to unlock and open the safe.

4.6 Silent Mode Setting

To turn off key sound: Press '3' then '#'. To turn on key sound: Press '3' then '#'.

▶ **Watch video online**
ADIMO Gun Safe, Biometric Gun Safe for Pistols, Handgun

Video: Provides a comprehensive guide on setting passwords, registering fingerprints, and activating/deactivating mute mode.

5. Maintenance

5.1 Battery Replacement

When the low battery alarm activates (red light flashes 4 times), replace all 4 AA batteries promptly. Ensure the safe is open when replacing batteries.

5.2 Cleaning

Wipe the exterior of the safe with a soft, damp cloth. Avoid using abrasive cleaners or solvents. Keep the fingerprint sensor clean and dry for optimal performance.

6. Troubleshooting

6.1 Safe Not Opening

- **Check Batteries:** Ensure batteries are correctly installed and not depleted. Replace if necessary.
- **Try All Access Methods:** Attempt to open using the keypad, fingerprint, and physical key.
- **Emergency Power:** If batteries are completely dead, connect a USB power source to the emergency USB port to temporarily power the keypad.

6.2 Forgot Password or Fingerprint Not Working

- **Use Backup Key:** The physical backup keys are the primary method for access if electronic methods fail or are forgotten.
- **Reset to Factory Settings:** To erase all fingerprints and passwords, press and hold the 'SET' button for 5-6 seconds. The initial password will revert to **12345#**.

6.3 False Rejections (Fingerprint)

- Ensure your finger and the sensor are clean and dry.
- Try re-registering your fingerprint, ensuring full contact and consistent placement during the process.

7. Specifications

Feature	Detail
Brand	ADIMO
Model Number	BGX-M/D-K1
Product Dimensions	12.6"D x 10.23"W x 3.14"H
Interior Dimensions	12.2" x 7.87" x 2.83"
Internal Volume	4.5 Liters
Lock Type	Key Unlock, LED Keypad, Fingerprint Recognition
Color	Black
Material	Alloy Steel, Carbon Steel
Special Features	2 Guns Capacity, Emergency USB Power Port, Mute Mode, Backlit Keyboard, 3 Ways Quick Access
Mounting Type	Wall Mount
Control Type	Fingerprint, Keyboard, Key
Included Components	1 USB Cable, 2 Screws, 1 Gun Safe, 1 Security Cable, 2 Keys

Feature	Detail
Item Weight	6.6 Pounds
Alarm	Audible
Water Resistance Level	Not Water Resistant
Country of Origin	China

8. Warranty

The ADIMO Biometric Handgun Safe comes with a**1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects and malfunctions under normal use.

9. Support

For any questions, technical assistance, or warranty inquiries, please contact ADIMO US, the seller. Refer to your purchase platform or product packaging for specific contact details.

© 2025 ADIMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the SET button located on the ADIMO BGX-M/D-K1 Biometric Handgun Safe, and is it under the batteries?

For the ADIMO BGX-M/D-K1 Biometric Handgun Safe, the SET button is located inside the safe, typically positioned near the battery compartment behind the front panel. To find and use it: Open the safe: Use...

Read full answer

Open the live page

https://manuals.plus/asin/B0CQJNY85F

More documents and user manuals: **https://manuals.plus/**