Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS ND010

SICOTAS White Alder Night Stand with Drawer (Model ND010)

User Manual

Introduction

Thank you for choosing the SICOTAS White Alder Night Stand with Drawer. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The SICOTAS White Alder Night Stand, featuring a single drawer and an open shelf.

Safety Information

WARNING: To ensure safe use and prevent injury, please adhere to the following guidelines:

- Do not overload the bedside table. The maximum weight recommendation is 29.94 kg (66 lbs).
- Avoid placing fingers in the drawer slots during operation.
- Keep the bedside table away from direct heat sources, open flames, and excessive moisture.
- Assemble the bedside table strictly following the provided instructions to ensure stability and prevent tipping or collapse.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- This product is intended for indoor use only.

Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- All necessary furniture panels (top, bottom, sides, back, drawer components)
- Hardware pack (screws, dowels, drawer slides, cam locks, etc.)
- Assembly Guide
- Tools Recommended For Assembly: Screw Driver (not included)

Setup and Assembly Instructions

Assembly is required for this night stand. It is recommended that 1 person assemble this product. Follow the detailed, step-by-step instructions provided in the included Assembly Guide. Ensure you have a clean, flat surface for assembly to prevent scratching the furniture.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface.
2. **Identify Parts:** Refer to the Assembly Guide to identify each panel and hardware piece.
3. **Assemble Frame:** Follow the sequence in the guide to connect the side panels, bottom panel, and back panel using the provided hardware.
4. **Install Drawer Slides:** Attach the drawer slides to the inner side panels and the drawer box according to the instructions.
5. **Assemble Drawer:** Construct the drawer box and attach the front panel.
6. **Insert Drawer:** Carefully slide the assembled drawer into the installed slides.
7. **Attach Top Panel:** Secure the top panel to the assembled frame.
8. **Final Check:** Ensure all connections are tight and the night stand is stable.



Image: Visual representation of key features and construction elements for assembly reference.

Operating Instructions

The SICOTAS Night Stand is designed for convenient storage and display of bedside essentials.

- **Drawer Use:** Gently pull the drawer front to open and push to close. The smooth slide rails ensure easy operation. Avoid

forcing the drawer if it encounters resistance.

- **Open Shelf:** Utilize the open shelf for items you wish to display or access frequently, such as books, decorative items, or small electronics.
- **Top Surface:** The top surface can hold lamps, alarm clocks, and other personal items. Ensure items are placed stably to prevent falling.



Image: The night stand with its drawer open, demonstrating its storage capacity.

Maintenance

To maintain the appearance and longevity of your SICOTAS Night Stand:

- **Cleaning:** Wipe with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

Troubleshooting

Problem	Possible Cause	Solution
Night stand is wobbly.	Loose fasteners or uneven floor.	Check and tighten all assembly screws. Ensure the night stand is on a level surface. Use furniture pads if necessary.
Drawer does not slide smoothly.	Drawer slides are misaligned or obstructed.	Ensure drawer slides are correctly installed and free of debris. Check that the drawer box is assembled squarely.
Scratches or minor damage.	Accidental impact or abrasive cleaning.	For minor scratches, use a furniture repair pen or wax crayon matching the finish. Avoid abrasive cleaning materials.

Specifications



Image: Detailed product dimensions.

Feature	Detail
Brand	SICOTAS
Model Name	ND010
Color	White Alder
Product Dimensions (D x W x H)	39.1D x 57.7W x 61.2H centimetres (15.4D x 22.7W x 24.1H inches)
Item Weight	16.33 kg
Maximum Weight Recommendation	29.94 kg (66 lbs)
Frame Material	Engineered Wood
Number of Drawers	1
Style	Modern, Minimalist
Recommended Uses	Bedroom, Living Room, Home Office, Nursery

Warranty and Support

Return Policy: This product is subject to a 30-day refund/replacement return policy. Please refer to your purchase platform for specific return procedures and conditions.
Manufacturer Contact: For any questions, missing parts, or support needs before or after purchase, please contact SICOTAS customer support. You can reach the manufacturer at:
CA-SICOTAS
1428 Lowen Dr
Gloucester, Ontario K1V 1H3

Canada

For additional information or to explore other products, visit the official SICOTAS store:SICOTAS Store on Amazon.

Product Videos

While the product listing indicates the presence of videos, specific embeddable URLs with creator type information were not available in the provided data. Therefore, no videos can be embedded in this manual.

© 2026 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQJZ7WGS

More documents and user manuals: **https://manuals.plus/**