Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sokany SK-5102

Sokany SK-5102 2000W Dual Burner Electric Stove Instruction Manual

Model: SK-5102

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the power outlet matches the voltage requirements of the stove (2000W). Do not use with damaged cords or plugs.
- **Placement:** Place the stove on a stable, heat-resistant surface. Ensure adequate ventilation around the unit. Do not place near flammable materials.
- **Supervision:** Never leave the appliance unattended while in use. Keep out of reach of children and pets.
- **Water and Moisture:** Do not immerse the stove in water or any other liquid. Avoid using in damp environments.
- **Hot Surfaces:** The heating plates and surrounding areas become very hot during operation and remain hot for some time after use. Use oven mitts or pot holders.
- **Proper Cookware:** Use only flat-bottomed cookware that is suitable for electric stoves. Ensure the cookware size is appropriate for the heating plate.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Repairs:** Do not attempt to repair or modify the appliance yourself. Contact qualified service personnel for any repairs.

2. Product Overview

The Sokany SK-5102 is a 2000W dual burner electric stove designed for efficient and fast heating. It features two large heating plates with individual temperature controls, making it suitable for various indoor cooking needs.



Image: Sokany SK-5102 2000W Dual Burner Electric Stove with packaging and cooking examples.

Key Features:

- Powerful 2000W heating capacity with dual burners.
- Two large heating plates for wide coverage and even heat distribution.
- Individual temperature control knobs for each burner.
- Suitable for use in homes, offices, and workshops.
- Energy-efficient operation.
- Lightweight and made of stainless steel.

3. Setup

1. **Unpacking:** Carefully remove the electric stove from its packaging. Retain packaging for future storage or transport.
2. **Inspection:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Placement:** Place the stove on a flat, stable, and heat-resistant surface. Ensure there is at least 10-15 cm (4-6 inches) of clear space around all sides of the stove for proper ventilation.
4. **Power Connection:** Ensure the control knobs are in the 'OFF' position before plugging the stove into a grounded electrical outlet.

4. Operating Instructions

1. **Prepare Cookware:** Place your desired cookware (pot or pan) onto the heating plate. Ensure the cookware is centered and stable.
2. **Power On:** Plug the stove into a suitable electrical outlet. The power indicator light may illuminate.
3. **Adjust Temperature:** Turn the control knob for the desired burner clockwise to select the desired heat setting. The indicator light for that burner will illuminate, indicating it is heating.
4. **Cooking:** Allow the heating plate to reach the desired temperature. Adjust the knob as needed during cooking.
5. **After Use:** Once cooking is complete, turn the control knob counter-clockwise to the 'OFF' position. The indicator light will turn off.
6. **Cool Down:** Unplug the stove from the outlet and allow it to cool completely before handling or cleaning. The heating plates will remain hot for some time after being turned off.

Note: During the first use, a small amount of smoke or odor may be emitted. This is normal and will dissipate quickly. Ensure good ventilation.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your electric stove.

1. **Always Unplug:** Before cleaning, always unplug the stove from the power outlet and allow it to cool down completely.
2. **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, a mild detergent can be used. Avoid abrasive cleaners or scouring pads, as they can damage the stainless steel finish.
3. **Heating Plates:** For spills on the heating plates, wait until they are cool. Gently scrape off any dried food residue with a plastic scraper. Wipe with a damp cloth. Do not use harsh chemicals or immerse the plates in water.
4. **Control Knobs:** The control knobs can be removed by pulling them gently for easier cleaning of the surrounding area. Ensure they are dry before reattaching.
5. **Storage:** When not in use, store the stove in a dry, safe place, away from moisture and extreme temperatures.

Caution: Do not use water jets or steam cleaners to clean the appliance.

6. Troubleshooting

If you encounter issues with your electric stove, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Stove does not turn on.	Not plugged in; power outage; faulty outlet; control knob not turned on.	Ensure the stove is securely plugged in. Check your circuit breaker. Try a different outlet. Turn the control knob to a heat setting.
Heating is slow or uneven.	Incorrect heat setting; unsuitable cookware; cookware not flat.	Increase the heat setting. Use flat-bottomed cookware suitable for electric stoves. Ensure cookware is centered.
Smoke or odor during first use.	Protective coating burning off.	This is normal. Ensure good ventilation. It will dissipate after a few minutes of initial use.
Indicator light is off but stove is hot.	Residual heat after turning off.	This is normal. The plates retain heat. Allow to cool completely before touching.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Detailed technical specifications for the Sokany SK-5102 Electric Stove:

- **Model:** SK-5102
- **Power:** 2000 Watts
- **Number of Heating Elements:** 2
- **Heating Element Type:** Radiant
- **Control Type:** Knob
- **Material:** Stainless Steel
- **Special Features:** Lightweight

- **Power Source:** Corded Electric
- **Included Components:** 1 x Sokany SK-5102 2000W Heater with Two Burners
- **Item Weight:** 5 Kilograms
- **Manufacturer:** Sokany
- **Part Number:** 50219

8. Warranty and Support

Warranty Information:

This Sokany SK-5102 Electric Stove comes with a Sokany Standard Warranty. Please refer to the warranty card included in the product packaging for specific terms, conditions, and duration of the warranty.

Customer Support:

For technical assistance, service, or warranty claims, please contact Sokany customer support. Contact details can typically be found on the product packaging, warranty card, or the official Sokany website. Please have your model number (SK-5102) and proof of purchase ready when contacting support.

You can visit the Sokany Store on Amazon for more information or to browse other products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CQYT87B7

More documents and user manuals: **https://manuals.plus/**