Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Taygeer 100100BLK

Taygeer Travel Laptop Backpack User Manual

Model: 100100BLK

Introduction

This manual provides comprehensive instructions for the proper use, care, and maintenance of your Taygeer Travel Laptop Backpack. Designed for convenience and durability, this backpack is ideal for travel, business, college, and daily use. Please read this manual thoroughly to ensure optimal performance and longevity of your product.



Image: The Taygeer Travel Laptop Backpack in black, showcasing its sleek design and multiple compartments.

Key Features

- **Convenient USB Port:** Equipped with a built-in USB charger port on the exterior and an internal charging cable, allowing for convenient phone charging on the go. *Note: Power bank and charging cable for the phone are not included. The USB port serves as a pass-through for easy access.*
- **Roomy Capacity & Multi-Pocket Design:** Features three main large compartments and nine internal pockets, along with side pockets, to keep your belongings organized. Includes dedicated space for a 15.6-inch laptop and a 12.9-inch iPad.
- **Flight Approved Size:** Designed to meet airline carry-on requirements, fitting both overhead bins and under-seat spaces. The 180-degree zipper opening facilitates quick security checks.
- **Versatile Carrying Options:** Can be used as a traditional backpack with padded adjustable shoulder straps or transformed into a handbag using the two padded grab handles located on the top and side. A luggage strap allows for easy attachment to rolling luggage.
- **Water-Resistant Material:** Constructed from durable polyester fabric with water-resistant properties to protect your items from light rain and spills.



Image: Close-up view highlighting the water-resistant polyester fabric, comfortable padded handle, and integrated luggage strap for easy transport.



Image: The dedicated laptop compartment, designed to securely hold a 15.6-inch laptop and a 12.9-inch iPad, along with other accessories.



Image: An open view of the backpack's interior, demonstrating its spacious main compartment, a wet bag for toiletries, and a built-in shoe pouch.

Setup

1. **Unpacking:** Remove the backpack from its packaging. Unzip all compartments to allow the fabric to air out and regain its shape.
2. **Adjusting Shoulder Straps:** Loosen or tighten the padded shoulder straps to achieve a comfortable fit. Ensure the backpack sits snugly against your back, distributing weight evenly.
3. **USB Charging Port Setup:** Locate the internal charging cable within the backpack. Connect your personal power bank (not included) to this cable. The external USB port will then be ready to connect your phone's charging cable (not included).
4. **Utilizing Luggage Strap:** If traveling with rolling luggage, slide the backpack's luggage strap over the handle of your suitcase for secure attachment.

Operating Instructions

Packing Your Backpack

- **Main Compartments:** Utilize the large main compartments for clothing, books, or larger items. The 180-degree opening allows for suitcase-style packing.
- **Laptop & Tablet Storage:** Place your 15.6-inch laptop and 12.9-inch iPad in their designated padded sleeves within the laptop compartment for maximum protection.
- **Small Items & Accessories:** Use the various inner pockets and side pockets for smaller items such as pens, wallets, keys, and water bottles. The wet bag is suitable for toiletries or damp items.
- **Shoe Pouch:** Store shoes or dirty laundry in the dedicated shoe pouch to keep them separate from clean items.

Using the USB Charging Port

1. Connect your charged power bank to the internal USB cable.
2. Connect your device's charging cable to the external USB port on the backpack.
3. Ensure both connections are secure for proper charging.



Image: Examples of the backpack's versatility in different settings: college, business, travel, and hiking.

Maintenance

- **Cleaning:** For minor spills or dirt, wipe the exterior with a damp cloth and mild soap. For deeper cleaning, hand wash with cold water and a gentle detergent. Do not machine wash or tumble dry.
- **Drying:** Air dry the backpack completely before storing to prevent mold or mildew. Hang it upside down to allow water to drain from all compartments.
- **Storage:** Store the backpack in a cool, dry place away from direct sunlight when not in use.
- **Zipper Care:** Periodically check zippers for any debris and clean if necessary. Lubricate with a zipper lubricant if they become stiff.

Troubleshooting

Problem	Possible Cause	Solution
Device not charging via USB port.	Power bank not connected or discharged; faulty cable; device incompatibility.	Ensure power bank is charged and properly connected to the internal cable. Try a different charging cable or device to rule out cable/device issues.
Zippers are stiff or stuck.	Dirt/debris in zipper teeth; lack of lubrication.	Clean zipper teeth with a small brush. Apply a zipper lubricant (e.g., wax, silicone spray) to the teeth.
Backpack feels uncomfortable when worn.	Improper strap adjustment; uneven weight distribution.	Adjust shoulder straps to ensure a snug fit and even weight distribution. Pack heavier items closer to your back.

Specifications

Model Number: 100100BLK

Product Dimensions: 7.01 x 17.01 x 7.01 inches (L x H x W)

Item Weight: 1.74 pounds (0.79 kg)

Capacity: 35 Liters

Material: Water-resistant Polyester Fabric

Laptop Compatibility: Up to 15.6 inches

Tablet Compatibility: Up to 12.9 inches (iPad)

Features: USB Charging Port (pass-through), Multiple Compartments, Padded Shoulder Straps, Padded Handles, Luggage Strap, Wet Bag, Shoe Pouch.



Image: A visual comparison of the backpack's dimensions, illustrating its suitability as a personal item or carry-on.

Warranty and Support

Taygeer products are manufactured with high-quality materials and craftsmanship. For any questions, concerns, or support needs regarding your backpack, please contact Taygeer customer service through the retailer's platform or the official Taygeer website. Please retain your proof of purchase for warranty claims.

For more information, visit the official Taygeer Store on Amazon.

© 2024 Taygeer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CR9JFD7S

More documents and user manuals: **https://manuals.plus/**