Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FITHOOD CS-AEQ916VX

FITHOOD Replacement Battery Instruction Manual

Model: CS-AEQ916VX | Brand: FITHOOD

1. Introduction

This instruction manual provides essential information for the safe and effective use of your FITHOOD replacement Li-ion battery, model CS-AEQ916VX. This battery is designed for various AEG QX9 series vacuum cleaners. Please read this manual thoroughly before installation and use, and retain it for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, or other injury or damage.

- Do not attempt to disassemble, open, or service the battery pack.
- Replace only with the battery pack designated for your specific device model.
- Do not crush, puncture, short external contacts, or dispose of in fire or water.
- Do not store the battery above 60°C (140°F).
- Keep the battery out of reach of children.
- Dispose of used batteries according to local regulations.

3. Setup and Installation

Before installing the new battery, ensure your vacuum cleaner is powered off and disconnected from any charging source. Verify that the replacement battery model CS-AEQ916VX and its part numbers (4055542544, 4055542544, 4055478301) are compatible with your AEG QX9 series vacuum cleaner.



Image 1: The FITHOOD replacement battery, showing its main body, wiring, and identification labels. This view highlights the overall structure and connections.

1. **Power Off:** Ensure the vacuum cleaner is completely turned off and unplugged.
2. **Locate Battery Compartment:** Refer to your vacuum cleaner's original manual to locate and open the battery compartment.
3. **Remove Old Battery:** Carefully disconnect the old battery's connectors and remove it from the compartment.
4. **Insert New Battery:** Align the FITHOOD replacement battery with the compartment. Connect the battery's wiring harnesses to the corresponding ports in the vacuum cleaner. Ensure connections are secure.



Image 2: A detailed view of the various connectors and wiring harnesses included with the battery, illustrating the different types of plugs for connection to the vacuum cleaner's internal system.

5. **Secure Compartment:** Close and secure the battery compartment.
6. **Initial Charge:** The new battery pack must be fully charged before its first use. Connect your vacuum cleaner to its charger and allow it to charge completely.

4. Operating Instructions

Once the battery is installed and fully charged, your vacuum cleaner is ready for use. The battery operates similarly to the original battery.

- **Charging:** Always use the original charger provided with your AEG QX9 vacuum cleaner. Ensure the vacuum is properly docked or connected to the charger.
- **First Use:** For optimal performance and battery longevity, fully charge the battery before its initial use.
- **Discharge:** Avoid completely draining the battery frequently. Recharge when the vacuum cleaner indicates low battery.

5. Maintenance

Proper maintenance ensures the longevity and performance of your replacement battery.

- **Storage:** If storing the battery for an extended period, ensure it is partially charged (around 50%) and stored in a cool, dry place, away from direct sunlight and extreme temperatures. Do not store above 60°C (140°F).
- **Cleaning:** Keep the battery contacts clean and free from dust or debris. Use a dry, soft cloth for cleaning.
- **Regular Use:** For best results, use and recharge the battery regularly.

6. Troubleshooting

If you encounter issues with your replacement battery, consider the following:

- **Battery Not Charging:** Ensure the charger is properly connected and functioning. Check for any visible damage to the battery or charger.
- **Short Run Time:** Ensure the battery has been fully charged. Over time, all batteries experience some capacity degradation.
- **Vacuum Not Powering On:** Verify that the battery is correctly installed and its connectors are secure.

If troubleshooting steps do not resolve the issue, or if you are unsure about compatibility or installation, please contact customer support with your battery details or pictures for professional assistance.

7. Specifications

Feature	Specification
Model Number	CS-AEQ916VX
Battery Type	Li-ion
Voltage	25.2V
Capacity	3000mAh
Watt-Hours (Wh)	75.6Wh
Dimensions	87.0 x 82.0 x 54.6mm (3.43 x 3.23 x 2.15 inches)
Weight	440.0g (15.5 ounces)
Certifications	ISO9001, RoHS, CE, UN38.3, MSDS
Manufacturer	FITHOOD

8. Support

For further assistance, technical support, or inquiries regarding your FITHOOD replacement battery, please contact the manufacturer or seller. When contacting support, please provide your battery's model number (CS-AEQ916VX) and any relevant details or pictures of the issue.
Manufacturer: FITHOOD
For more information about Cameron Sino products, which may be related to the battery's internal components, you

may visit http://www.cameronsino.com.

© 2024 FITHOOD. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRRG2FJC

More documents and user manuals: **https://manuals.plus/**