Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO Nebo - 6907

NEBO SWYVEL 1000 Lumen Rechargeable Flashlight User Manual

Brand: NEBO | **Model:** Nebo - 6907

1. Introduction

The NEBO SWYVEL 1000 Lumen Rechargeable Flashlight is a versatile and powerful lighting tool designed for various applications, from everyday carry to professional work. Its compact size, rotating swivel head, and multiple light modes make it an essential device for hands-free illumination.





Image: Front view of the NEBO SWYVEL flashlight, showcasing its compact design and swivel head.

2. Key Features

- **Rotate & Illuminate:** Compact and ultra-bright, the SWYVEL rechargeable flashlight fits in your pocket without sacrificing power. Rotate the 90-degree swivel head to light up any situation, from everyday carry to electrical work, at the right angle.



Image: Close-up of the flashlight's head swiveling 90 degrees, highlighting its versatile design.

- **5 Light Modes:** Whether for home repairs or camping, this EDC flashlight can emit 1,000 lumens; use Turbo for boosted brightness, High for optimal visibility, Medium for balanced output, Low for up to 6 hours of use, and Strobe for emergency signaling.



Image: Illustration showing the powerful 1,000 lumen light beam emitted from the flashlight.

- **Compact & Capable:** With a swivel head, magnetic base and steel clip, this LED light easily attaches to metal surfaces or shirts & hats, offering hands-free lighting in tight spaces; water (IPX4) and impact resistant, it makes light work of tough jobs.



Image: A hand holding the compact NEBO SWYVEL flashlight, demonstrating its small form factor.

- **Easy to Use & Recharge:** Smart Power Control extends battery life by allowing seamless transitions between light modes, while the USB MagCable dock makes recharging a breeze (~4 hours charge time); when the indicator light turns blue, you're ready to go.
- **Tech Specs:** Size: 3.75" x 1" x 1.125"; Weight: 0.18 lbs; 600 mAh (3.7V) Lithium ion rechargeable battery; Includes: USB charging MagCable; Lumens: 50 lm (Low) – 1000 lm (Turbo). Note: higher lumens equal brighter lights.

3. Setup

1. **Unboxing:** Carefully remove the NEBO SWYVEL flashlight and all included accessories from the packaging. Verify that the USB charging MagCable is present.
2. **Initial Charge:** Before first use, fully charge the flashlight. Connect the USB MagCable to a power source and attach the magnetic end to the charging port on the flashlight. The indicator light will turn blue when fully charged. Refer to the 'Charging' section for more details.

4. Operating Instructions

The NEBO SWYVEL features Smart Power Control for seamless transitions between light modes.

1. **Power On/Off:** Press the power button once to turn the flashlight on. Press and hold the power button to turn it off.
2. **Cycle Light Modes:** While the flashlight is on, press the power button repeatedly to cycle through the available light modes: Turbo, High, Medium, Low, and Strobe.
3. **Swivel Head Adjustment:** The flashlight head can be rotated 90 degrees to direct light as needed. Gently rotate the head to the desired angle.
4. **Magnetic Base:** Utilize the integrated magnetic base to attach the flashlight to metallic surfaces for hands-free operation.



Image: The flashlight attached to a metal electrical box via its magnetic base, providing hands-free illumination.

4.1. Light Modes

The NEBO SWYVEL offers five distinct light modes to suit various needs:

- **Turbo:** Provides a boosted burst of 1000 lumens for maximum brightness over short durations.
- **High:** Offers optimal visibility with strong illumination.
- **Medium:** Provides balanced light output for general use.
- **Low:** Delivers extended battery life, up to 6 hours, for prolonged use.

- **Strobe:** A flashing light mode for emergency signaling or drawing attention.

5. Charging

The NEBO SWYVEL is equipped with a convenient wireless USB MagCable for recharging.

1. **Connect the MagCable:** Plug the USB end of the MagCable into a standard USB power adapter (not included) or a computer USB port.
2. **Attach to Flashlight:** Gently bring the magnetic end of the MagCable close to the charging port located at the base of the flashlight. The magnet will automatically align and secure the connection.
3. **Charging Indicator:** The indicator light on the flashlight will illuminate during charging. It will turn blue when the battery is fully charged.
4. **Charging Time:** A full charge typically takes approximately 4 hours.



Image: The flashlight's magnetic base connecting to the USB MagCable for recharging.

6. Maintenance

To ensure the longevity and optimal performance of your NEBO SWYVEL flashlight:

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents. Keep the lens clean for clear light output.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, ensure the battery is partially charged.
- **Battery Care:** Avoid fully depleting the battery frequently. Recharge the flashlight regularly to maintain battery health.

7. Troubleshooting

If you encounter issues with your NEBO SWYVEL flashlight, refer to the following table:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted.	Charge the flashlight using the provided MagCable.
Light is dim or flickers.	Low battery or dirty lens.	Recharge the battery. Clean the flashlight lens with a soft cloth.
Flashlight does not charge.	MagCable not properly connected or faulty power source.	Ensure the MagCable is securely connected to both the flashlight and a working USB power source. Try a different USB port or adapter.
Swivel head is stiff.	Accumulated dirt or debris.	Gently clean around the swivel mechanism. Do not force rotation.

8. Specifications

Specification	Detail
Brand	NEBO
Model Number	Nebo - 6907
Light Source Type	LED
Brightness	1000 Lumens (Turbo)
Light Modes	Turbo, High, Medium, Low, Strobe
Power Source	Battery Powered
Battery Type	600 mAh (3.7V) Lithium-Ion 16340 rechargeable battery
Runtime (Low)	Up to 6 hours
Charging Time	Approximately 4 hours
Dimensions	3.75" x 1" x 1.125"
Weight	0.18 lbs

Specification	Detail
Water Resistance	IPX4 (Water Resistant)
Special Features	90-degree Swivel Head, Magnetic Base, Steel Clip, Smart Power Control
Included Components	Flashlight, USB charging MagCable

9. Warranty and Support

Warranty Information: The NEBO SWYVEL 1000 Lumen Rechargeable Flashlight comes with a limited warranty. Please refer to the product packaging or the manufacturer's official website for specific terms and conditions.
Customer Support: For technical assistance, warranty claims, or product inquiries, please contact NEBO customer support through their official channels. Visit the NEBO website for contact information and frequently asked questions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CT4QCT21

More documents and user manuals: **https://manuals.plus/**