XLEADER SoundAngel A8

XLEADER SoundAngel A8 Portable Bluetooth Speaker User Manual

Model: SoundAngel A8

1. INTRODUCTION

Thank you for purchasing the XLeader SoundAngel A8 Portable Bluetooth Speaker. This compact and versatile speaker is designed to deliver high-quality audio with convenient touch controls and multiple connectivity options. Please read this manual carefully to ensure proper use and to maximize your listening experience.

2. KEY FEATURES

- **LED Touch Design:** Stylish and modern exterior with an intuitive LED touch screen for easy control of songs and volume. Glowing buttons are useful in low-light conditions.
- **Ultra-Portable Design:** Compact size (Φ3.3 x H1.2 inch, 6.4oz) for easy portability in pockets or backpacks, ideal for outdoor activities, travel, and various indoor settings.
- **Powerful Sound:** Equipped with a 5W full-range powerful driver, delivering loud and clear crystal sound suitable for any listening environment.
- **Built-in Microphone:** Enables convenient hands-free calling.
- **Long Playtime:** Features a 1200mAh high-performance Li-battery, providing up to 12 hours of music playback at 60% volume.
- **Strong Compatibility:** Supports Bluetooth connectivity for quick pairing with all Bluetooth devices, as well as AUX input and Micro SD/TF card playback.

3. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x XLeader SoundAngel A8 Small Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x 3.5mm Audio Cable
- 1 x Multilingual Instruction Manual
- 1 x Warranty Card

- 1 x Donation Card

4. PRODUCT OVERVIEW

Figure 4.1: Top-down view of the XLeader SoundAngel A8 speaker, highlighting its circular design and illuminated touch controls for volume, track navigation, and play/pause.

Smart Touch Design

A simple touch lets you enjoy music effortlessly

Independent buttons make it easier to Switch songs and Volume control

Figure 4.2: A hand demonstrating the "Smart Touch Design" of the XLeader SoundAngel A8 speaker, showing how a finger interacts with the touch-sensitive surface for effortless music control.

5W Crystal Sound & Bass

3D Digital Audio Processor+Passive Bass Radiator

Louder and more Bass than other 3W Speaker

Figure 4.3: An internal diagram illustrating the 5W Crystal Sound & Bass technology of the XLeader SoundAngel A8 speaker, highlighting the 3D Digital Audio Processor and Passive Bass Radiator for enhanced audio output.

Figure 4.4: The XLeader SoundAngel A8 speaker displayed with icons representing its multi-functional capabilities, including Bluetooth 5.0, AUX input, TF card support, Voice Assistant, Crystal Call, and TWS (True Wireless Stereo) functionality.

Figure 4.5: A visual representation of the XLeader SoundAngel A8 speaker's "Long Playtime" feature, showing a man using a laptop with the speaker nearby, emphasizing its 1200mAh battery and up to 15 hours of playback.

Controls and Ports:

- **Touch Panel (Top):**

  - **Play/Pause Button:** Center button to play or pause audio.
  - **Volume Up (+):** Touch to increase volume.
  - **Volume Down (-):** Touch to decrease volume.
  - **Next Track (>>|):** Touch to skip to the next song.
  - **Previous Track (|<<):** Touch to go to the previous song.

- **O/M Button (Side):** On/Off and Mode switch button.
- **TF Card Slot (Side):** For Micro SD/TF card insertion.
- **DC 5V Port (Side):** USB-C charging port.
- **AUX Input (Side):** 3.5mm audio jack for wired connection.

5. SETUP AND CONNECTION

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the DC 5V port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show charging status and turn off when fully charged. A full charge takes approximately 3 hours.

5.2 Powering On/Off

Press and hold the **O/M** button on the side of the speaker for a few seconds to power it on or off. A voice prompt will indicate the power status.

5.3 Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED light and a voice prompt.
2. Enable Bluetooth on your device (smartphone, tablet, laptop).
3. Search for "SoundAngel A8" in the list of available Bluetooth devices.
4. Select "SoundAngel A8" to connect. Once successfully paired, the LED light will turn solid blue, and you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

5.4 AUX Input Mode

To use the speaker with a non-Bluetooth device, connect one end of the provided 3.5mm audio cable to the AUX input port on the speaker and the other end to the audio output jack of your device. The speaker will automatically switch to AUX mode.

5.5 Micro SD/TF Card Mode

Insert a Micro SD/TF card (with pre-loaded MP3 audio files) into the TF card slot. The speaker will automatically detect the card and begin playing music from it. Press the **O/M** button to switch between modes if needed.

6. Operation

6.1 Music Playback

- **Play/Pause:** Tap the center button on the touch panel.
- **Volume Up:** Tap the '+' symbol on the touch panel.
- **Volume Down:** Tap the '-' symbol on the touch panel.
- **Next Track:** Tap the '>>|' symbol on the touch panel.
- **Previous Track:** Tap the '|<<' symbol on the touch panel.

6.2 Hands-Free Calling

- **Answer Call:** When a call comes in, tap the center Play/Pause button to answer.
- **End Call:** During a call, tap the center Play/Pause button to end the call.
- **Reject Call:** Press and hold the center Play/Pause button for 2 seconds to reject an incoming call.
- **Redial Last Number:** Double-tap the center Play/Pause button to redial the last number called.

7. Maintenance and Care

- Keep the speaker away from extreme temperatures, direct sunlight, and moisture.

- Do not expose the speaker to water or other liquids as it is not waterproof.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- Store the speaker in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue LED). Turn on Bluetooth on your device. Move device closer to speaker (within 20 meters).
No sound.	Volume too low; incorrect mode; device not playing.	Increase speaker and device volume. Ensure correct mode (Bluetooth, AUX, TF card). Check if audio is playing on the connected device.
Sound distortion.	Volume too high; low battery; interference.	Decrease volume. Charge the speaker. Move away from other electronic devices.

9. SPECIFICATIONS

| Feature	Detail
Model Name	SoundAngel A8
Product Dimensions	3.35"D x 1.26"W x 3.35"H
Item Weight	6.3 ounces (180 Grams)
Color	Gold
Material	Metal, Plastic, Silicone
Speaker Type	Stereo
Speaker Maximum Output Power	5 Watts
Connectivity Technology	Bluetooth, Auxiliary
Wireless Communication Technology	Bluetooth
Bluetooth Range	20 Meters
Battery Life	12 Hours (at 60% volume)
Battery Capacity	1200 mAh (Lithium Polymer)
Charging Time	3 Hours

Feature	Detail
Control Method	Touch
Includes MP3 player?	Yes (via TF card)
Built-in Microphone	Yes
Water Resistance Level	Not Water Resistant

10. WARRANTY AND SUPPORT

XLEADER offers a **3-Year warranty** for quality-related issues and **lifetime technical support** for the SoundAngel A8 speaker. For any questions, concerns, or technical assistance, please refer to the contact information provided on the warranty card included in your package or visit the official XLEADER website. Please retain your purchase receipt as proof of purchase for warranty claims.

Related Documents - **SoundAngel A8**

[XLeader Sport3 Pro Wireless Headphones: User Manual & Specifications](#)
Comprehensive user manual and technical specifications for the XLeader Sport3 Pro wireless sports headphones, detailing features like IPX7 waterproofing, 48-hour playtime, and Bluetooth connectivity.

[XLEADER SoundAngel X8 & X8 Pro Model Difference](#)
Information regarding the model differences between the XLEADER SoundAngel X8 and SoundAngel X8 Pro portable Bluetooth speakers, noting shared circuitry and RF modules.

[NovaLCT User Manual: LED Configuration Tool for Multimedia Players](#)
Comprehensive user manual for NovaLCT, NovaStar's LED configuration tool for multimedia players. Covers installation, setup, screen configuration, brightness adjustment, monitoring, and troubleshooting.

[Metapen Pencil A8 User Manual and Specifications](#)
Comprehensive user manual for the Metapen Pencil A8 stylus, detailing its features, usage instructions, specifications, troubleshooting, and compatibility with various iPad models. Includes charging guide, warnings, and FCC statement.

[AiYin Tattoo Printer Instruction Manual](#)
Comprehensive instruction manual for the AiYin Tattoo Printer, covering setup, operation, app connectivity, PC printing, maintenance, charging, and safety guidelines. Includes product sketch, power indicator status, and FCC warnings.