Manuals+
Q & A | Deep Search | Upload

Jugbow DT-68

Jugbow Dog Shock Collar Instruction Manual

Model: DT-68

Brand: Jugbow

Introduction

The Jugbow Dog Shock Collar is designed to assist in effective and humane dog training. It features multiple training modes and a long remote range, making it suitable for various training environments. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and safety.

Figure 1: Jugbow Dog Shock Collar and Remote

Included Components

Your Jugbow Dog Shock Collar package includes the following items:

- 1 x Collar (assembled with short metal prongs and short silicone covers)
- 1 x Remote
- 2 x Long Metal Prongs
- 2 x Long Silicone Covers
- 1 x User Manual
- 1 x Charging Cable

Setup

1. Charging the Devices

Before first use, fully charge both the collar receiver and the remote. The included 2-in-1 USB cable allows simultaneous charging. A red light indicates charging, and it will turn green or off when fully charged.

2. Powering On/Off

- **Collar Receiver:** Press and hold the power button for three seconds until the red light turns on. Release, then long press until the green light flashes, indicating it's powered on.
- **Remote:** The remote typically powers on automatically when the security lock is disengaged.

Figure 2: Powering on the Collar Receiver

3. Fitting the Collar

Ensure the collar fits snugly but comfortably. The contact points should touch the dog's skin. For dogs with thicker coats, use the longer metal prongs provided. Silicone covers can be used for added comfort or if static shock is not desired.

Figure 3: Adjustable Collar for Dogs 10-120lbs

Figure 4: Prong Options for Different Fur Lengths

4. Testing the Static Shock Function

Use the provided test tool to verify the static shock function. Place the test tool over the contact points on the collar. Press the static button on the remote. If the light on the test tool flashes, the static shock function is working correctly.



Figure 5: Static Shock Test Procedure

Operating Modes

The Jugbow Dog Shock Collar offers 4 humane training modes:

- **Beep (Standard):** Provides an audible tone.
- **Vibration (1-9 Levels):** Delivers a tactile vibration.
- **Safe Shock (1-99 Levels):** Administers a static correction.
- **Shock Boost (10% Higher):** Provides a slightly stronger static correction.

Figure 6: Overview of Training Modes

Remote Range and Channel Selection

The remote has a range of up to 4200 feet, allowing for training indoors or outdoors. It supports dual channels, enabling you to train two dogs simultaneously. The remote has a memory function, so settings do not need to be reset.

Figure 7: Extended Remote Range for Training

Figure 8: Remote Channel Selection

Security Lock

The remote features an instant response security on/off switch button to prevent accidental activation of training modes.

Video 1: Official Jugbow Dog Training Collar Overview. This video demonstrates the product's features, including the security lock and various training modes.

Maintenance

Proper maintenance ensures the longevity and effectiveness of your Jugbow Dog Shock Collar.

- **Waterproof Design:** The receiver collar is IPX7 waterproof and can be used in various weather conditions. Note: The remote is not waterproof.
- **Charging Precautions:** Avoid contact with other metal objects while charging. Wipe the receiver's magnetic charging interface with a rag to prevent dirt from blocking the current, which could lead to short circuits or unsuccessful charging.
- **Regular Cleaning:** Periodically clean the collar and remote with a soft, damp cloth. Ensure contact points are free of debris.

Figure 9: IPX7 Waterproof Collar

Battery Life

The collar offers impressive battery life:

- Collar Standby Time: Up to 35 days
- Remote Standby Time: Up to 45 days

Figure 10: Long-Lasting Battery Life

Troubleshooting

If you encounter issues with your Jugbow Dog Shock Collar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Collar not responding to remote	Incorrect channel selected on remote; Low battery on collar or remote; Collar not powered on; Out of range.	Ensure remote is on the correct channel (Default is Dog 1). Charge both devices. Power on the collar. Reduce distance between remote and collar.
Static shock not working	Poor contact with dog's skin; Silicone covers installed; Low battery; Test tool not used correctly.	Adjust collar for better contact. Remove silicone covers if static is desired. Charge collar. Use test tool as per instructions.
Device not charging	Charging cable not properly connected; Dirty charging port; Faulty cable/adapter.	Ensure secure connection. Clean magnetic charging interface. Try a different USB port or adapter.
Collar loosens over time	Normal wear and tear.	Regularly check and adjust the collar strap to maintain proper fit.

Specifications

Feature	Detail
Item Weight	10.2 ounces
Item Model Number	DT-68
Batteries	1 Lithium Polymer battery required (included)
Item Package Dimensions	6.97 x 4.88 x 2.28 inches
Color	Blue
Material	Nylon
Target Audience	Dogs (10-120 lbs, neck size 7.8-24.4 inches)
Age Range Description	Dogs over 6 months old
Waterproof Rating	IPX7 (Collar Receiver)
Remote Range	Up to 4200FT
Training Modes	Beep, Vibration (1-9 levels), Safe Shock (1-99 levels), Shock Boost (10% higher)

Warranty & Support

The Jugbow Dog Shock Collar comes with a 1-Year Warranty.
For any product inquiries, technical support, or warranty claims, please contact Jugbow customer service. Refer to the contact information provided in your product packaging or visit the official Jugbow website for support details.
It is recommended to wear the collar continuously for a maximum of 12 hours. This product is not suitable for aggressive dogs.

Related Documents - DT-68

	JUGBOW DT-68 Dog Training Collar User Manual & Guide Your essential guide to the JUGBOW DT-68 dog training collar. This user manual covers setup, operation, safety precautions, troubleshooting, and maintenance for effective and humane dog training. Learn about features like vibration, tone, and shock modes, waterproof design, and long-range capabilities.
	JUGBOW DT-62 Dog Training Collar User Manual - Shock, Vibration, Beep Modes Comprehensive user manual for the JUGBOW DT-62 Dog Training Collar. Learn about setup, operation, features, safety, troubleshooting, and warranty for this remote dog training device.
	JUGBOW DT-612GN Dog Training Collar User Manual Comprehensive user manual for the JUGBOW DT-612GN dog training collar, covering features, operation, safety guidelines, troubleshooting, and warranty information. Learn how to effectively train your dog using beep, vibration, and shock modes.
	JUGBOW DT-68 Dog Training Collar User Manual | Features, Operation & Safety Comprehensive user manual for the JUGBOW DT-68 dog training collar. Learn about components, operation, safety guidelines, troubleshooting, and maintenance for effective pet training.
	Jugbow DT-57 Dog Training Collar User Manual Comprehensive user manual for the Jugbow DT-57 Dog Training Collar, covering product description, operating guide, safety information, troubleshooting, and specifications.
	Jugbow DT-60 Dog Training Collar User Manual Comprehensive user manual for the Jugbow DT-60 Dog Training Collar, covering package contents, product description, safety information, operating instructions, product features, troubleshooting, and warranty details.