Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Waterdrop Compact Electric Water Filter Pitcher

Waterdrop Compact Electric Water Filter Pitcher User Manual

Model: Compact Electric Water Filter Pitcher (WD-EDF)

Brand: Waterdrop

1. About Your Waterdrop Electric Water Filter Pitcher

The Waterdrop Compact Electric Water Filter Pitcher is designed to provide clean, healthy, and great-tasting water directly from your fridge. Its compact design allows it to fit conveniently on fridge door shelves, saving space. This pitcher features an advanced filtration system and a long-lasting battery for portable use.

Key Features:

- **Fridge Door Shelf Support:** Specifically designed to fit most fridge door shelves, optimizing space.
- **Alkaline Pure Healthy Water:** Equipped with an alkaline filter replacement that offers a 2X longer slow-release lifespan for pH balancing, increasing initial pH by 1.5-2.5.
- **30-day Battery Life:** Built-in battery provides up to 30 days of use on a single charge, ideal for various settings without frequent recharging.
- **Reduces 30+ Contaminants:** Features a 5 µm premium carbon block filter material for high accuracy, excellent adsorption, and zero carbon leakage, effectively reducing impurities like PFAS, Chlorine, Lead, and more.
- **Safety First:** IPX5 waterproof tested and made from BPA-free quality materials, ensuring the purity and safety of your drinking water.

2. Product Overview

Familiarize yourself with the components of your Waterdrop Electric Water Filter Pitcher.



Image 2.1: The Waterdrop Compact Electric Water Filter Pitcher shown with four included filters (one standard, three alkaline).



Fridge Door Shelf Support

Sleek design ensures great fit.

Image 2.2: The pitcher's compact dimensions (10.6" W x 10.2" H x 4.6" D) allow it to fit perfectly on a fridge door shelf, optimizing space.



Image 2.3: Illustration demonstrating the filter's ability to reduce over 30 contaminants, including PFAS, Chlorine, Lead, and Odor, with a 5 μm filtration efficiency.



Image 2.4: The alkaline filter provides a 2X longer alkaline lifespan, reduces 30+ contaminants, and is easy to replace.



Image 2.5: The replacement filter is compatible with various Waterdrop Electric Water Filters, including models WD-ED01W, WD-ED01B, WD-ED01AW, WD-ED01AB, WD-EDC01W, WD-ED02W, WD-ED02B, WD-ED04W-L, and WD-ED04B-L.



Image 2.6: Visual comparison highlighting Waterdrop's 5 μm filtration capability versus typical 50 μm filters found in other pitchers, ensuring cleaner water.



Image 2.7: Demonstrates the simple and easy process of replacing the water filter.



Image 2.8: The alkaline filter offers a 2X longer lifespan, providing long-lasting pH balancing for up to 200 gallons or 3 months.



Image 2.9: The filter is made from safe, BPA-free and Lead-free materials, ensuring pure and healthy water.

3. Setup Instructions

3.1 Initial Cleaning

1. Unpack all components from the box.
2. Wash the pitcher reservoir, lid, and dispenser spout with mild soap and warm water. Rinse thoroughly. Do not wash the filter cartridge with soap.
3. Dry all parts completely before assembly.

3.2 Charging the Pitcher

1. Locate the charging port on the pitcher (usually on the top or side).
2. Connect the provided charging cable to the pitcher and a suitable power source (e.g., USB wall adapter).

3. Allow the pitcher to charge fully. A full charge provides approximately 30 days of battery life. The indicator light will change to show charging status (refer to specific light indicators in your product's quick start guide if available).

3.3 Filter Installation

1. Remove the new filter from its packaging.
2. Submerge the filter in cold water for 10-15 minutes to remove any air bubbles and prepare it for use.
3. Align the filter with the designated slot in the pitcher's reservoir.
4. Gently push and twist the filter clockwise until it is securely seated. Ensure a snug fit to prevent unfiltered water from bypassing the filter.
5. Fill the reservoir with tap water. Discard the first two full pitchers of filtered water to flush out any carbon fines and activate the filter.

4. Operating Instructions

4.1 Filling the Pitcher

1. Remove the lid from the pitcher.
2. Fill the reservoir with cold tap water. Do not overfill beyond the maximum fill line.
3. Replace the lid securely.

4.2 Dispensing Water

1. Place a glass or container under the dispenser spout.
2. Press the dispense button (if applicable) or tilt the pitcher to pour water. The electric pump will activate to dispense filtered water.

5. Maintenance

5.1 Cleaning the Pitcher

1. Regularly clean the pitcher reservoir, lid, and dispenser spout with mild dish soap and warm water.
2. Rinse all parts thoroughly to remove any soap residue.
3. Do not place the filter cartridge in the dishwasher. Hand wash only.

5.2 Filter Replacement

For optimal performance and water quality, replace the filter cartridge promptly.

- **Frequency:** Replace the filter after filtering 200 gallons of water or every 3 months, whichever comes first.
- **Indicator:** The pitcher may have a filter life indicator (electronic or manual) to remind you when to replace the filter.
- **Procedure:** Follow the steps outlined in Section 3.3 Filter Installation for replacing the old filter with a new

one.

6. Troubleshooting

Common Issues and Solutions:

- **Slow Filtration:**
  - Ensure the filter is properly seated and not clogged.
  - If the filter is old, it may be saturated; replace it.
  - Ensure the filter was pre-soaked to remove air bubbles.
- **Unpleasant Taste/Odor:**
  - Ensure the first two pitchers of filtered water were discarded after new filter installation.
  - The filter may have reached its capacity; replace it.
  - Ensure the pitcher and all components are clean.
- **Water Leaking:**
  - Check that the filter is securely installed and twisted into place.
  - Ensure the lid is properly sealed on the pitcher.
- **Dispenser Not Working (Electric Model):**
  - Check if the battery is charged. Recharge if necessary.
  - Ensure the dispenser button is pressed firmly.

7. Specifications

Feature	Detail
Brand	Waterdrop
Model Name	Compact Electric Water Filter Pitcher (WD-EDF)
Special Feature	Chlorine Reduction, PFAS Reduction, Lead Reduction, Alkaline Water
Package Information	Box
Installation Type	Countertop / Fridge Door Shelf
Power Source	Battery Powered
Upper Temperature Rating	101 Degrees Fahrenheit (38.3 Degrees Celsius)
Filter Lifespan	Up to 200 gallons or 3 months (whichever comes first)

Battery Life	Up to 30 days on a single charge
Material	BPA-free, Lead-free

8. Warranty and Support

Waterdrop products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official Waterdrop website. If you encounter any issues or have questions regarding your Waterdrop Compact Electric Water Filter Pitcher, please contact Waterdrop customer support for assistance.

Customer Support: Please refer to the contact information provided on the product packaging or the official Waterdrop website.

© 2024 Waterdrop. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CTY71S99

More documents and user manuals: **https://manuals.plus/**