Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Waterdrop ED04

Waterdrop Mega Electric Water Filter Pitcher User Manual

Model: ED04

Product Overview

The Waterdrop Mega Electric Water Filter Pitcher is designed to provide clean, filtered water with convenience and efficiency. This electric dispenser features a large capacity and advanced filtration technology to reduce common contaminants, ensuring a continuous supply of fresh water for multiple users.



Image: The Waterdrop Mega Electric Water Filter Pitcher shown with four replacement filters, highlighting its complete package.

- **Elevated Water Drinking Experience:** Designed for larger audiences, offering quicker filtration and fresher water with intelligent, easy operation.
- **27 Cups Ultra-large Capacity:** Meets the demands of multiple persons, reducing frequent refills and saving time and energy.
- **NSF/ANSI Certified:** Certified by IAPMO against NSF/ANSI 42, 53, 401 & 372 standards, reducing over 30 substances including chlorine, lead, mercury, benzene, bisphenol A, PFOA, and PFOS.
- **Extended Filter Lifespan:** Each filter lasts for 200 gallons or 3 months, providing prolonged effectiveness and consistent pure water.
- **30-day Battery Life:** Built-in battery offers approximately 30 days of use on a single charge, suitable for various settings without frequent recharging.



Image: Visual representation of the filter's ability to reduce over 30 contaminants, including chlorine, lead, and PFAS.

Setup Instructions

1. **Unpack the Pitcher:** Carefully remove all components from the packaging. Ensure all parts are present: the pitcher body, lid, filter, and charging cable.
2. **Wash Components:** Wash the pitcher body and lid with mild soap and warm water. Rinse thoroughly.*Do not wash the filter with soap.*
3. **Prepare the Filter:** Before first use, soak the new filter in cold water for 10-15 minutes to remove any air bubbles. This helps ensure optimal filtration performance.
4. **Install the Filter:** Insert the prepared filter into the designated slot within the pitcher. Ensure it is securely seated. Refer to the diagram for proper alignment.

5. **Initial Charge:** Connect the charging cable to the pitcher and a power source. Charge the pitcher fully before first use. The battery indicator will show charging status.
6. **First Fill and Flush:** Fill the pitcher with tap water. Dispense the first two full pitchers of filtered water and discard them. This flushes out any carbon fines and prepares the filter for regular use.

Operating Instructions

The Waterdrop Mega Electric Water Filter Pitcher is designed for simple, one-touch operation.

1. **Filling the Pitcher:** Open the lid and fill the pitcher with cold tap water. Ensure the water level does not exceed the maximum fill line.
2. **Dispensing Water:** Place a glass or container under the dispenser spout. Press the dispense button located on the top of the pitcher. Water will flow out rapidly. Release the button to stop dispensing.
3. **Battery Indicator:** The pitcher is equipped with a battery indicator light. A solid light indicates sufficient charge, while a blinking light indicates a low battery and requires recharging.
4. **Charging:** When the battery is low, connect the provided charging cable to the charging port on the pitcher and a standard USB power adapter (not included). A full charge provides approximately 30 days of use, depending on usage.



Image: The pitcher dispensing water, illustrating its rapid filtration speed of 0.8 L/min and 1-second dispensing time.



Image: Diagram showing the 30-day battery life of the pitcher with a 5000 mAh capacity, requiring charging once a month.

Maintenance

Regular maintenance ensures optimal performance and longevity of your Waterdrop Mega Electric Water Filter Pitcher.

- **Cleaning the Pitcher:** Wash the pitcher body and lid regularly with mild dish soap and warm water. Rinse thoroughly. *Do not immerse the electronic components (lid with dispense button) in water.*Wipe them clean with a damp cloth.
- **Filter Replacement:** The filter should be replaced every 200 gallons or approximately every 3 months, whichever comes first. This duration may vary based on local water quality and usage.
- **Replacing the Filter:**
    a. Remove the old filter by gently pulling it out from its slot.

b. Prepare the new filter by soaking it in cold water for 10-15 minutes.
c. Insert the new filter firmly into the slot until it clicks into place.
d. Flush the new filter by dispensing and discarding the first two full pitchers of water.



Image: A hand demonstrating the one-step easy filter replacement process for the Waterdrop pitcher.



Image: The WD-EDF replacement filter, compatible with various Waterdrop electric water filters including WD-ED01W, WD-ED01B, and others.

Troubleshooting

Problem	Possible Cause	Solution
No water dispenses / Slow flow	◦ Low battery ◦ Filter clogged or needs replacement ◦ Air bubbles in filter (new filter)	◦ Charge the pitcher fully. ◦ Replace the filter. ◦ Re-soak the filter and ensure it's properly seated.

Problem	Possible Cause	Solution
Water tastes unusual	◦ New filter not flushed ◦ Filter needs replacement ◦ Pitcher needs cleaning	◦ Flush the first two pitchers of water. ◦ Replace the filter. ◦ Clean the pitcher thoroughly.
Battery not holding charge	◦ Charging cable issue ◦ Battery degradation	◦ Try a different charging cable or power adapter. ◦ Contact customer support if the issue persists.

Specifications



Image: Dimensions of the Waterdrop Mega Electric Water Filter Pitcher: 12" length, 10.2" height, 7.1" width.

Feature	Detail
Brand	Waterdrop
Model Name	ED04
Capacity	27 Cups
Special Feature	Chlorine Reduction, NSF certified
Purification Method	Carbon Block
Power Source	Battery Powered
Filter Lifespan	200 Gallons or 3 Months

Feature	Detail
Battery Life	Approx. 30 days on a single charge
Upper Temperature Rating	100°F (38°C)
Installation Type	Not Required
Manufacturer	Waterdrop





Image: Certificate of Listing from IAPMO Research and Testing, Inc., confirming NSF/ANSI 42, 53, 401 & 372 certification for the filter.

Warranty and Support

For specific warranty information regarding your Waterdrop Mega Electric Water Filter Pitcher, please refer to the warranty card included with your product packaging or visit the official Waterdrop website.

For customer support, technical assistance, or to purchase replacement filters, please contact Waterdrop customer service or visit their official online store:

Visit the Waterdrop Store on Amazon

© 2024 Waterdrop. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CVVSRPS4

More documents and user manuals: **https://manuals.plus/**