LZBEITEM 118x118 inch

LZBEITEM Heavy Duty Outdoor Dog Kennel - Model 118x118 inch

Instruction Manual

1. Introduction

Thank you for choosing the LZBEITEM Heavy Duty Outdoor Dog Kennel. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new kennel. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Safety Information

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children and pets away during assembly.
- **Proper Anchoring:** Ensure the kennel is securely anchored to the ground to prevent tipping or movement, especially in windy conditions.
- **Regular Inspection:** Periodically inspect all components for wear, damage, or loose connections. Replace damaged parts immediately.
- **Pet Supervision:** Always supervise your pet, especially when they are first introduced to the kennel.
- **Ventilation:** Ensure adequate ventilation within the kennel. The cover provides shade but does not replace proper airflow.
- **Weight Limit:** Do not allow excessive weight or objects to rest on the kennel frame or cover.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Galvanized Steel Frame Tubes
- Chain Link Mesh Panels
- UV & Waterproof Cover
- Door Panel with Secure Latch
- Connection Hardware (bolts, nuts, washers)
- Ground Nails/Stakes
- Rubber Bands/Bungee Cords for Cover
- Cable Ties/Wire for Mesh Attachment

Figure 3.1: Illustration of the kennel's spacious interior and weather-resistant properties, including UV protection, temperature regulation, water resistance, and snow proofing.

4. Setup Instructions

Follow these steps carefully for proper assembly. Two people are recommended for easier installation.

4.1 Prepare the Area

1. Choose a flat, level outdoor surface for the kennel.
2. Clear the area of any debris, rocks, or sharp objects.

4.2 Assemble the Frame

1. Unpack all galvanized steel frame tubes.
2. Connect the horizontal and vertical frame tubes according to the diagram, forming the base and side panels. Ensure all connections are snug.
3. Secure connections using the provided bolts, nuts, and washers. Do not overtighten initially.

4.3 Attach Chain Link Mesh

1. Unroll the chain link mesh panels.
2. Attach the mesh to the assembled frame sections using the provided wire or cable ties. Start from one corner and work your way around, ensuring the mesh is taut.
3. Trim any excess wire or cable ties for a neat finish.

4.4 Install the Door

1. Position the door panel within the designated opening in the frame.
2. Attach the door hinges to the frame and door panel using the appropriate hardware.
3. Test the door to ensure it swings freely and the secure latch operates correctly.

4.5 Install the Roof Frame and Cover

1. Assemble the roof frame structure, typically a peaked design, and attach it to the top of the main kennel frame.
2. Drape the UV and waterproof cover over the roof frame.
3. Secure the cover to the frame using the provided rubber bands or bungee cords, ensuring it is taut and covers the entire roof area to prevent water pooling.

4.6 Final Securement

1. Once the entire structure is assembled, tighten all bolts and connections.
2. Use the ground nails/stakes to anchor the base of the kennel firmly into the ground.



Figure 4.1: Key dimensions of the 118x118 inch kennel, including overall length, width, height, and door opening measurements.

Figure 4.2: Detailed views illustrating the sturdy construction, secure lock mechanism, rubber band attachments for the cover, and ground nail anchoring points.

Figure 4.3: Close-up images showcasing the robust door hinges and secure frame connection points, emphasizing the overall design integrity.

5. Operating Instructions

5.1 Using the Door

- The kennel features a secure, lockable gate latch. To open, lift the latch and swing the door outwards.
- To close, swing the door shut and ensure the latch mechanism engages fully to prevent accidental opening.

5.2 Pet Placement

- Gently guide your pet into the kennel. Ensure they have adequate water and any necessary bedding or toys.
- The spacious interior is designed to accommodate various animals, providing ample room for movement.

Figure 5.1: The kennel's spacious design, suitable for a range of animals including dogs, geese, ducks, chickens, and rabbits.

6. Maintenance

6.1 Cleaning

- **Frame:** Wipe down the galvanized steel frame with a damp cloth and mild detergent as needed. Rinse thoroughly and dry to prevent water spots.
- **Mesh:** The chain link mesh can be hosed down to remove dirt and debris.
- **Cover:** The UV and waterproof cover can be cleaned with a soft brush, water, and mild soap. Avoid harsh chemicals that may damage the material. Ensure the cover is dry before storage to prevent mildew.

6.2 Inspection

- Regularly check all bolts, nuts, and connections to ensure they remain tight.
- Inspect the chain link mesh for any broken wires or sharp edges. Repair or replace as necessary.
- Examine the cover for tears, holes, or signs of wear. A damaged cover may compromise its weather-resistant properties.

- Verify that ground anchors are still firmly in place.

7. Troubleshooting

7.1 Kennel Instability

- **Issue:** The kennel feels wobbly or unstable.
- **Solution:** Ensure all frame connections are fully tightened. Verify that the ground anchors are properly installed and secured into firm ground. If the ground is uneven, consider placing leveling blocks under the frame.

7.2 Water Pooling on Cover

- **Issue:** Water collects on the roof cover after rain.
- **Solution:** Ensure the cover is stretched taut and evenly distributed over the roof frame. Re-adjust the rubber bands or bungee cords to eliminate slack. Check that the roof frame is correctly assembled to maintain its peaked shape.

7.3 Door Not Latching Securely

- **Issue:** The door latch does not engage properly.
- **Solution:** Check for any obstructions preventing the door from closing completely. Inspect the latch mechanism for damage or misalignment. Adjust the door hinges if necessary to ensure proper alignment with the latch.

8. Specifications

Feature	Detail
Brand	LZBEITEM
Model	118x118 inch Outdoor Dog Kennel
Product Dimensions (L x W x H)	118" x 118" x 71" (approximately 9.8' L x 9.8' W x 5.9' H)
Material	Galvanized Steel Frame, 170g Polythene Cover
Color	Silver
Door Size (L x H)	23" x 40"
Iron Pipe Diameter	1.25"
Mesh Diameter	Φ2.4 mm
Cover Features	UV Protection, Waterproof
Target Audience	Dogs (All Breed Sizes), other small to medium animals
Specific Uses	Outdoor Exercise Pen, Playpen, Run Cage

9. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact LZBEITEM customer service directly. Refer to your purchase documentation for specific contact details or visit the official LZBEITEM website.

© 2024 LZBEITEM. All rights reserved.