GOTCOZY BK-F-TF

GOTCOZY Heated Electric Blanket Twin Size (Model BK-F-TF) - User Manual

Brand: GOTCOZY | Model: BK-F-TF

1. Important Safety Instructions

Please read all instructions carefully before using your GOTCOZY Heated Electric Blanket. Failure to follow these instructions may result in fire, electric shock, or injury.

- Do not use with infants, children, incapacitated persons, or anyone insensitive to heat.
- Do not use if the blanket is wet.
- Do not use with damaged cords or plugs. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent to avoid a hazard.
- Do not use pins or other metallic objects with this blanket as they may damage the electrical wiring.
- Do not use the blanket folded, bunched, or rolled. Ensure it is spread flat.
- Always unplug the blanket when not in use.
- This blanket is equipped with an Overheat Protection System and a 10-Hour Automatic Shut-off function for your safety.
- Keep the controller away from open windows or heat sources.

2. Product Overview

The GOTCOZY Heated Electric Blanket provides luxurious warmth and comfort. Made from 100% polyester, it features an ultra-soft silky plush to Sherpa reversible design, ensuring maximum coziness. It is ETL certified for safety and reliability.

Image: The reversible design of the blanket, featuring a soft flannel side and a plush Sherpa side.

Image: The blanket in various usage scenarios, including on a sofa, for working, and in bed.

3. Package Contents

- 1 x GOTCOZY Heated Electric Blanket (Twin Size, Rose Dust)
- 1 x Digital Controller
- 1 x User Manual

4. Setup Instructions

Follow these steps to set up your heated blanket for first use:

1. Unpack the blanket and controller from the packaging.
2. Lay the blanket flat on your bed or desired surface, ensuring there are no folds or creases.
3. Locate the connector on the blanket and the plug on the controller cord. Firmly connect the controller plug into the blanket connector until it clicks securely into place.
4. Plug the power cord into a standard 120V AC electrical outlet.
5. Ensure the controller is placed in an easily accessible location, away from any potential

obstructions.

Image: The heated blanket laid out on a bed with the controller connected and visible.

5. Operating Instructions

Your GOTCOZY Heated Electric Blanket features a user-friendly digital controller with multiple heat settings and an automatic shut-off timer.

Power On/Off

- Press the power button on the controller to turn the blanket on. The display will illuminate.
- Press the power button again to turn the blanket off.

Adjusting Heat Levels

- The blanket offers 6 heating levels. Use the up/down arrows or corresponding buttons on the controller to cycle through the heat settings (1-6).
- Level 1 provides the lowest heat, while Level 6 provides the highest heat (up to 45°C / 113°F).

Automatic Shut-off Timer

- The blanket is designed with a 10-hour automatic shut-off function for safety and energy

conservation.

- The blanket will automatically turn off after 10 hours of continuous use. You can restart it by pressing the power button if further warmth is desired.



Image: Close-up of the digital controller, showing heat level and timer options.

6. Care and Maintenance

Proper care ensures the longevity and performance of your heated blanket.

Before Cleaning

- Always unplug the power cord from the wall outlet.
- Disconnect the controller from the blanket by firmly pulling the connector.
- Allow the blanket and controller to cool completely before washing.

Machine Washing

- Machine wash on a gentle cycle with cold water (max 30°C / 86°F).
- Use a mild detergent.
- Do not bleach or use harsh chemicals.

Drying

- Tumble dry on low heat or hang to air dry.
- Ensure the blanket is completely dry before reconnecting the controller or storing.
- Do not iron or dry clean.

Image: The heated blanket air-drying, demonstrating its easy care.

7. Troubleshooting

If you experience issues with your heated blanket, please refer to the following common solutions:

Problem	Possible Cause	Solution
Blanket not heating	Not properly plugged in; power outage; controller malfunction.	Ensure all connections are secure. Check power outlet. Contact customer support if issue persists.
Uneven heating	Blanket is folded or bunched.	Spread the blanket flat, ensuring no folds or creases.
Controller lights flashing	Error code; overheat protection activated.	Unplug the blanket for 5 minutes, then reconnect. If the issue continues, contact customer support.

8. Specifications

- **Brand:** GOTCOZY
- **Model Name:** SCE-202
- **Item Model Number:** BK-F-TF
- **Size:** Twin (62 x 84 inches)
- **Color:** Rose Dust
- **Material:** 100% Polyester
- **Heating Levels:** 6
- **Auto-Off Timer:** 10 Hours
- **Safety Features:** Overheat Protection, Automatic Shut-off
- **Certifications:** ETL Certified
- **Care Instructions:** Machine Washable
- **Item Weight:** 4.84 pounds (2.2 Kilograms)

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact GOTCOZY customer service directly. Keep your purchase receipt for any warranty claims.