Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey 3seat-B

Yalissey 3-in-1 Outdoor Porch Swing with Adjustable Canopy

Model: 3seat-B

Introduction

Thank you for choosing the Yalissey 3-in-1 Outdoor Porch Swing. This manual provides essential information for the safe assembly, operation, and maintenance of your new porch swing. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Information

Always follow basic safety precautions when using this product to reduce the risk of injury. Failure to follow these instructions may result in serious injury or property damage.

- **Weight Capacity:** The maximum weight capacity for this porch swing is 750 pounds (approximately 3 adults). Do not exceed this limit.
- **Stable Surface:** Ensure the swing is placed on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Assemble the swing strictly according to the instructions provided. Ensure all bolts and fasteners are securely tightened before use.
- **Children:** Supervise children at all times when they are near or using the swing.
- **Maintenance:** Regularly inspect the swing for loose parts, damage, or wear. Do not use if any components are damaged.
- **Weather Conditions:** While designed for outdoor use, extreme weather conditions (strong winds, heavy rain) may require securing or covering the swing to prevent damage or injury.

Setup and Assembly

Detailed installation instructions are provided with your purchase. For visual guidance, please refer to the assembly video below. Ensure all parts are present before beginning assembly.

▶ **Watch video online**
Yalissey 3-Seat Outdoor Swing with Canopy

Video: Yalissey 3-Seat Outdoor Swing with Canopy. This video demonstrates the assembly process and key features of the porch swing.

Components Overview

Familiarize yourself with the main components of your porch swing:

- **Frame:** Sturdy, powder-coated metal frame for durability and rust resistance.
- **Canopy:** Adjustable fabric canopy for sun protection.
- **Seat Cushions:** Thickened, splash-proof cushions with high-density foam.
- **Side Tables:** Two foldable side tables with cup holders.
- **Backrest:** Multi-position adjustable backrest.



Image: Overview of various assembly parts for the Yalissey 3-in-1 Outdoor Porch Swing.

Operating Instructions

Adjusting the Canopy

The outdoor patio swing canopy is designed to shield you from sunlight and can be adjusted to different angles. Use the reinforced adjustable knob to easily set the desired angle for optimal shade.



Image: Close-up of the adjustable canopy mechanism, showing how to change its angle for sun protection.

3-Position Adjustable Backrest

The backrest features three adjustable angles to suit various activities:

1. **105° (Swing Chair):** Ideal for comfortable sitting and conversation.
2. **135° (Chaise Lounge):** A unique reclining position for relaxed lounging.
3. **180° (Porch Swing Bed):** Fully flat position for napping or extended relaxation.

To adjust the backrest, pull out the pin located on the side of the backrest frame, set it to your desired angle, and lock it securely in place. The reliable buckle on the backrest ensures stability.



Image: The Yalissey porch swing in its 180° bed configuration, demonstrating its versatility.

Using the Foldable Side Tables

The swing includes two convenient foldable side tables, one on each side. These tables are designed to hold cups, phones, or small items. Simply pull them out when needed and fold them back down for storage.



Image: A foldable side table extended, showing its integrated cup holders for convenience.

Maintenance

Cleaning the Cushions

The seat cushions are upholstered in 180G polyester fabric with PA coating, making them splash-proof, water-repellent, and fade-resistant (80-hour color fastness, US standard Grade 4+). To clean, simply wipe with a damp cloth and mild soap. Allow to air dry completely.



Image: Close-up of the thickened, splash-proof cushions, highlighting their durability and comfort.

Frame Care

The frame is made of metal with a powder-coated finish, providing rust resistance. To maintain its appearance and longevity, clean the frame periodically with a damp cloth and mild detergent. Avoid abrasive cleaners that could damage the finish. Check all bolts and connections regularly and tighten if necessary.



Image: The robust metal frame of the porch swing, emphasizing its 750 lbs weight capacity and durable construction.

Troubleshooting

- **Swing feels unstable:** Ensure the swing is on a level surface. Check all assembly bolts and nuts to ensure they are securely tightened.
- **Canopy not staying in place:** Verify that the adjustable knob for the canopy is tightened sufficiently after setting the desired angle.
- **Backrest not locking:** Ensure the pin is fully engaged in the desired position. Check for any obstructions preventing the locking mechanism from functioning correctly.
- **Cushions sliding:** The seat cushion is designed with a non-slip dotted fabric base. Ensure the cushions are properly aligned on the seat frame.

Specifications

Feature	Detail
Brand	Yalissey
Model	3seat-B
Color	Khaki
Product Dimensions	19"D x 77"W x 71"H
Frame Material	Metal (Alloy Steel)
Finish Type	Powder Coated
Seat Depth	19 inches
Assembly Required	Yes
Set Name	3-seater
Item Weight	83 pounds
Maximum Weight Capacity	750 pounds
Date First Available	February 27, 2024

Warranty and Support

Your Yalissey porch swing is designed for durability and comfort. While specific warranty details are not provided in this manual, we are committed to ensuring your satisfaction.

If you encounter any problems or require assistance with your product, please do not hesitate to contact our customer support team. You can expect a prompt reply and satisfactory service from our team.

For support, please refer to the contact information provided with your purchase or visit theYalissey Store on Amazon.

© 2026 Yalissey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWP1L44S

More documents and user manuals: **https://manuals.plus/**