Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire FRCO100B

Frigidaire 5-in-1 Air Fryer Combo Oven Instruction Manual

Model: FRCO100B | Brand: Frigidaire

Introduction

Elevate your cooking experience with the Frigidaire FRCO100B 5-in-1 Air Fryer Combo Oven. Designed for versatility and convenience, this countertop oven combines five essential cooking modes – Air Fry, Bake, Reheat, Dehydrate, and Rotisserie – into one compact, space-saving appliance. With a spacious 12.6-quart capacity, it's well suited for preparing family meals and features PFAS-free* cooking surfaces for added peace of mind. Effortlessly cook your favorites at the touch of a button with seven pre-programmed recipe presets, including options for meat, chicken, fish, vegetables, fries, dinner rolls, and cake. The oven features a viewing window and interior light for easy monitoring, as well as five adjustable rack positions to accommodate any dish, from hearty dinners to indulgent desserts. Complete with six accessories, including a non-stick air fry basket, two racks, and a rotisserie kit, this all-in-one air fryer oven makes every meal efficient, enjoyable, and consistently delicious.
Frigidaire is committed to helping families make the most of their time and space with high-performing, easy-to-use appliances. We're here to make healthy meals yummier, favorite clothes last longer, and keep the air in homes fresher – shaping living for the better so we can live happier, healthier lives.
*Tested per EN 14582:2016 standardized test

Important Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always place the appliance on a stable, heat-resistant surface.
- Ensure proper ventilation around the air fryer during operation.
- Do not immerse the main unit in water or other liquids.
- Keep hands and face clear of hot steam and air vents.
- Unplug the appliance when not in use and before cleaning.
- Supervise children closely if they are near the appliance.

What's in the Box

Your Frigidaire 5-in-1 Air Fryer Combo Oven comes with the following components:

- 1 x Frigidaire 5-in-1 air fryer combo oven

- 1 x 3.5 L non-stick basket with removable handle
- 2 x racks
- 1 x rotisserie kit
- 1 x removable drip tray




Figure 1: Included accessories with the Frigidaire 5-in-1 Air Fryer Combo Oven.

Setup

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Initial Cleaning:** Before first use, wash the non-stick basket, racks, rotisserie kit, and drip tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls and other appliances to ensure adequate air circulation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

The Frigidaire 5-in-1 Air Fryer Combo Oven features an intuitive digital display for easy operation.



Figure 2: Digital display and control panel.

Controls and Display:

- **Power Button:** Press to turn the unit on/off.
- **Temperature Control:** Use the '+' and '-' buttons to adjust the cooking temperature (up to 400°F).
- **Time Control:** Use the '+' and '-' buttons to adjust the cooking time.
- **Cooking Modes:** Select from 5 distinct cooking modes: Air Fry, Bake, Reheat, Dehydrate, and Rotisserie.
- **Recipe Presets:** Choose from 7 pre-programmed settings for common dishes like meat, chicken, fish, vegetables, fries, dinner rolls, and cake.

- **Automatic Shake Reminder:** The oven provides sound and light alerts to remind you when to shake or flip food for even cooking.



Figure 3: Utilizing the 7 pre-programmed recipe presets.

Adjustable Rack Positions:

The oven features five adjustable rack positions, allowing you to customize your cooking setup for various dishes and sizes.




Figure 4: Multiple adjustable rack positions for versatile cooking.

Viewing Window:

Monitor your cooking progress easily through the clear viewing window and built-in interior light, eliminating the need to open the oven door.




Figure 5: Illuminated viewing window for easy monitoring.

Cooking Modes

The Frigidaire 5-in-1 Air Fryer Combo Oven offers five versatile cooking modes:



Figure 6: Five ways to cook with your Frigidaire Air Fryer Combo Oven.

1. Air Fry:

Achieve crispy results with little to no oil. Ideal for fries, chicken wings, and other fried favorites.

2. Bake:

Perfect for baking cookies, cakes, muffins, and other desserts or savory dishes.

3. Reheat:

Quickly warm up leftovers while maintaining their texture and flavor.

4. Dehydrate:

Create healthy dried fruits, vegetables, and jerky by slowly removing moisture.

5. Rotisserie:

Use the included rotisserie kit to cook whole chickens or roasts evenly for tender, juicy results.

Product Overview Video:

▶ **Watch video online**
Air Fryer Combo Oven Video Overview

Video 1: Official overview of the Frigidaire 5-in-1 Air Fryer Combo Oven, demonstrating its features and cooking capabilities.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your appliance.

- **Unplug:** Always unplug the air fryer and allow it to cool completely before cleaning.
- **Accessories:** The non-stick air fry basket, racks, and drip tray are dishwasher safe for easy cleaning. For stubborn residue, soak in warm, soapy water before scrubbing.
- **Interior:** Wipe the interior of the oven with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Exterior:** Clean the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **PFAS-Free Surfaces:** The cooking surfaces are PFAS-free, making them easy to clean and providing added peace of mind.



Figure 7: PFAS-Free cooking surfaces for easy cleaning.

Troubleshooting

If you encounter any issues with your Frigidaire Air Fryer Combo Oven, refer to the following common troubleshooting tips:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working outlet. Check the power button on the unit.
- **Food not cooking evenly:** Ensure food is not overcrowded in the basket or on the racks. Utilize the automatic shake reminder or manually shake/flip food during cooking.
- **White smoke from appliance:** This may be caused by grease from previous use. Clean the drip tray and interior thoroughly.
- **Food not crispy:** Ensure the temperature is set correctly and food is not overloaded. A light spray of oil can help achieve crispiness.

Specifications

Feature	Detail
Brand	Frigidaire
Model Name	Frigidaire 5-in-1 Air Fryer Combo Oven
Model Number	FRCO100B
Capacity	12.6 Quarts (12 Liters)
Cooking Modes	Air Fry, Bake, Reheat, Dehydrate, Rotisserie
Recipe Presets	7 (Meat, Chicken, Fish, Vegetables, Fries, Dinner Rolls, Cake)
Max Temperature Setting	400 Degrees Fahrenheit
Wattage	1700 Watts
Voltage	120 Volts
Control Method	Touch
Material	Plastic
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes
Product Dimensions	14.8 x 12.7 x 16.1 inches
Item Weight	15 Pounds
Country of Origin	China

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Frigidaire website. You may also contact Frigidaire customer service for assistance with product registration, troubleshooting, or replacement parts.

Online Resources:

- Visit the Frigidaire Store on Amazon

© 2024 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWS423RY

More documents and user manuals: **https://manuals.plus/**