Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-BB1

Joyroom JR-BB1 True Wireless Earbuds User Manual

Model: JR-BB1

Introduction | Safety Information | Package Contents | Product Overview | Setup | Operating Instructions | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for choosing the Joyroom JR-BB1 True Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds. Please read this manual thoroughly before using the product to ensure proper function and longevity.

2. Safety Information

To ensure safe and optimal use of your Joyroom JR-BB1 earbuds, please observe the following precautions:

- Do not expose the earbuds or charging case to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping, hitting, or disassembling the device. Unauthorized repairs will void the warranty.
- Keep the earbuds and charging case away from water and liquids. While the earbuds are IPX4 rated (splash-proof), the charging case is not.
- Clean the earbuds and charging case with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Do not use the earbuds at excessively high volumes for prolonged periods, as this may cause hearing damage.
- Dispose of the product and its battery responsibly according to local regulations.

3. Package Contents

Please check the package for the following items:

- Joyroom JR-BB1 True Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Silicone Eartips (S, M, L sizes)
- User Manual



Image: All components included in the Joyroom JR-BB1 True Wireless Earbuds package. This includes the two earbuds, the charging case, a USB-C charging cable, and multiple sets of silicone eartips for different ear sizes. The user manual is also visible.

4. Product Overview

Familiarize yourself with the different parts of your Joyroom JR-BB1 earbuds and charging case.

4.1 Earbuds



Image: A pair of Joyroom JR-BB1 True Wireless Earbuds, one left and one right. They feature a white body with a silver stem and an orange-tinted silicone eartip. A small blue indicator light is visible on the stem of one earbud.

- **Touch Control Area:** For managing playback, calls, and voice assistant.
- **Microphone:** For calls and voice commands (4-mic ENC for noise reduction).
- **Charging Contacts:** For charging inside the case.
- **LED Indicator:** Shows connection and battery status.
- **Eartip:** Silicone tips for comfortable fit and sound isolation.

4.2 Charging Case



Image: The Joyroom JR-BB1 charging case in a closed position, showing its smooth, rounded white design. A small green LED indicator light is visible on the front, indicating charging status or battery level.

- **Charging Port:** USB-C port on the bottom for charging the case.
- **LED Indicator:** Shows charging status of the case and earbuds.
- **Earbud Slots:** Magnetic slots to hold and charge the earbuds.

5. Setup

5.1 Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their magnetic slots.
2. Connect the USB-C charging cable to the charging port on the bottom of the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator on the case will show charging status. Once fully charged, the indicator may change color or turn off.
4. Charging time for earbuds is approximately 1.5 hours. Charging time for the case is approximately 1.5 hours.



Image: The Joyroom JR-BB1 charging case is open, revealing the two earbuds nestled inside their charging slots. A blue indicator light is visible on each earbud's stem, indicating they are charging or connected.

5.2 Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Open the charging case and take out both earbuds. They will automatically power on and enter pairing mode. The LED indicator on one earbud will flash, indicating it's ready to pair.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "JR-BB1" in the list of available Bluetooth devices and select it to connect.
4. Once connected, the LED indicators on both earbuds will turn off or flash slowly. You will hear a confirmation tone.
5. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, and then repeat the steps.

6. Operating Instructions

6.1 Wearing the Earbuds

Choose the eartips that provide the best seal and comfort for your ears. Insert the earbuds gently into your ear canal and rotate them slightly until they fit securely.

6.2 Touch Controls

The touch control area is located on the upper part of the earbud stem.

Function	Action
Play/Pause	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud for 2 seconds
Activate Voice Assistant	Triple tap on either earbud
Volume Up	Long press on the right earbud
Volume Down	Long press on the left earbud

7. Maintenance

7.1 Cleaning

Regular cleaning helps maintain sound quality and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For the eartips, remove them from the earbuds and clean with a damp cloth and mild soap if necessary. Rinse thoroughly and dry completely before reattaching.
- Gently clean the charging contacts on both the earbuds and inside the case with a dry cotton swab to ensure good connection.

- Do not use abrasive cleaners, alcohol, or chemical solvents.

7.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

If you encounter issues with your Joyroom JR-BB1 earbuds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing with device	◦ Ensure earbuds are fully charged. ◦ Place earbuds back into the case, close the lid, wait 5 seconds, then take them out again to re-enter pairing mode. ◦ Turn off and on Bluetooth on your device. ◦ Forget "JR-BB1" from your device's Bluetooth list and try pairing again. ◦ Ensure your device is within 10 meters of the earbuds.
Only one earbud working	◦ Place both earbuds back into the charging case, close the lid, and then take them out simultaneously. ◦ Ensure both earbuds are charged. ◦ Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed, as it's not detailed on packaging).
No sound or low volume	◦ Adjust the volume on both your device and the earbuds. ◦ Ensure earbuds are properly connected to your device. ◦ Clean the eartips and earbud mesh to remove any obstructions. ◦ Try a different audio source.
Charging issues	◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Try a different USB-C cable and power adapter. ◦ Clean the charging contacts on the earbuds and inside the case.

9. Specifications

Technical specifications for the Joyroom JR-BB1 True Wireless Earbuds:

Feature	Detail
Model	JR-BB1
Bluetooth Version	V5.3

Feature	Detail
Audio Decoding	AAC, SBC
Supported Protocols	HSP, HFP, A2DP, AVRCP
Speaker Sensitivity	100±3dB
Frequency Response	20Hz-20KHz
Earbud Battery Capacity	40mAh
Case Battery Capacity	400mAh
Music Playing Time	Approx. 7 hours (earbuds), 28 hours (with charging case)
Call Duration	Approx. 5 hours
Earbud Charging Time	Approx. 1.5 hours
Case Charging Time	Approx. 1.5 hours
Case Charging Input	5V=1A
Charging Port	Type-C
Material	ABS+PC
Net Weight	49g
Waterproof Rating	IPX4 (Earbuds only)
Noise Reduction	4-mic ENC (Environmental Noise Cancellation)



Image: The rear side of the Joyroom JR-BB1 product box, displaying technical specifications and features in various languages, including Bluetooth version, battery life, and charging details. A barcode with the number 6956116772680 is visible at the bottom.

10. Warranty and Support

Joyroom products are designed and manufactured to the highest quality standards. For detailed warranty information and customer support, please refer to the warranty card included in your package or visit the official Joyroom website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Joyroom customer service through their official channels. Please have your product model (JR-BB1) and purchase details ready.

© 2024 JOYROOM. All rights reserved.

Product Model: JR-BB1

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CWS62CZR

More documents and user manuals: **https://manuals.plus/**