Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom BE10

Langsdom AirWave Open-Ear Bluetooth 5.4 Sport Headphones User Manual

Model: BE10

Introduction

The Langsdom AirWave Open-Ear Bluetooth 5.4 Sport Headphones are designed for an active lifestyle, offering comfort, situational awareness, and high-quality audio. With a lightweight design, IPX5 Nano waterproof rating, and a built-in 32GB memory card, these headphones are suitable for various activities including cycling, workouts, and daily use. The advanced Bluetooth 5.4 chip ensures a stable connection, and the long battery life provides extended listening pleasure.



Figure 1: Langsdom AirWave Open-Ear Bluetooth 5.4 Sport Headphones.

What's in the Box

Upon unboxing your Langsdom AirWave headphones, you will find the following items:

- User Manual
- Magnetic charging cable
- Storage bag



Figure 2: Packaging and included accessories for the AirWave headphones.

Specifications

Feature	Detail

Model Name	AirWave
Connectivity Technology	Wireless (Bluetooth 5.4)
Water Resistance Level	IPX5 Nano Waterproof
Battery Life	Up to 26.5 Hours
Built-in Memory	32GB
Audio Driver Type	Dynamic Driver (14.2mm)
Weight	26 grams (approx. 0.92 ounces)
Ear Placement	Open Ear
Control Method	Remote (Touch/Swipe)

Figure 3: Key features and technologies of the AirWave headphones.

Setup

Charging the Headphones

Before first use, fully charge your AirWave headphones. Use the provided magnetic charging cable.

1. Locate the magnetic charging port on the headphones.
2. Connect the magnetic charging cable to the port.
3. Connect the USB end of the cable to a power source (e.g., USB wall adapter, computer USB port).
4. The headphone will be fully charged in approximately 1.5 hours.

Your browser does not support the video tag.

Video 1: Demonstrates how to connect the magnetic charging cable to the AirWave headphones for charging.

Power On/Off

To manually power on or off the headphones, use the multifunction button:

- **Power On**: Long press the multifunction button for about 2 seconds.
- **Power Off**: Long press the multifunction button for about 3 seconds.

Your browser does not support the video tag.

Video 2: Shows the manual power on and off procedure for the AirWave headphones.

Bluetooth Pairing

To connect your AirWave headphones to a new device:

1. Ensure the headphones are powered off.
2. Long press the headphone's Multifunction Button (MFB) for about 2 seconds until the indicator light flashes, indicating pairing mode. The headphone will automatically begin pairing.

3. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
4. Search for available Bluetooth devices and select "AirWave" to pair.
5. Once connected, the indicator light will change, and you will hear a confirmation tone.

Your browser does not support the video tag.

Video 3: A step-by-step guide on how to pair your AirWave headphones with a Bluetooth device.

Extended Link (Multi-Device Pairing)

The AirWave headphones support connecting to multiple devices. To switch between previously paired devices:

1. Ensure the headphones are paired with Device A.
2. To switch to Device B, disconnect the headphones from Device A immediately.
3. Turn on the Bluetooth on Device B.
4. Search for "AirWave" on Device B and select to connect.
5. To switch back to Device A, turn on Bluetooth on Device A and select "AirWave" to connect.

Your browser does not support the video tag.

Video 4: Demonstrates how to use the extended link feature to switch between two paired devices.

Operating Instructions

Music Mode Controls

Control your music playback using the multifunction button:

- **Play/Pause**: Press the multifunction button once.
- **Next Song**: Press the multifunction button two times.
- **Previous Song**: Press the multifunction button three times.

Your browser does not support the video tag.

Video 5: Illustrates the music playback controls using the multifunction button.

Call Mode Controls

Manage your calls with the multifunction button:

- **Answer/Hang Up**: Press the multifunction button once.
- **Reject Call**: Long press the multifunction button for about 2 seconds.
- **Switch Calls**: During a call, press the multifunction button twice to hang up the current call and answer an incoming call.

Your browser does not support the video tag.

Video 6: Demonstrates how to answer, reject, and switch calls using the multifunction button.

Volume Control

Adjust the volume by sliding your finger on the designated area:

- **Increase Volume**: Slide from the volume down button to the volume up button (slide about 1 second).
- **Decrease Volume**: Slide from the volume up button to the volume down button (slide about 1 second).

Your browser does not support the video tag.

Video 7: Illustrates how to control the volume using the touch-sensitive area on the headphones.

Switching to TF Card Mode

The AirWave headphones feature a built-in 32GB memory card for local music playback. To switch to TF (TransFlash) card mode:

- With the touch function enabled, simultaneously press and hold the "+" and "-" buttons for two seconds. This will activate the TF card function.
- To transfer music files to the 32GB memory card, connect the magnetic charging cable to a computer or use an OTG adapter. Supported music formats include MP3, WMA, WAV, APE, and FLAC.

Your browser does not support the video tag.

Video 8: Demonstrates how to switch the headphones to TF card mode for local music playback.

Maintenance

To ensure the longevity and optimal performance of your Langsdom AirWave headphones, follow these maintenance guidelines:

- **Cleaning**: Regularly wipe the headphones with a soft, dry cloth. For sweat or light dirt, a slightly damp cloth can be used, but ensure the headphones are completely dry before charging or storing.
- **Water Resistance**: The headphones are IPX5 Nano waterproof, meaning they can withstand sweat and light rain. However, they are not designed for submersion in water. Avoid exposing them to strong jets of water or prolonged immersion.
- **Charging Port**: Keep the magnetic charging contacts clean and dry to ensure proper connection and prevent corrosion.
- **Storage**: When not in use, store the headphones in the provided storage bag to protect them from dust and scratches. Avoid storing them in extreme temperatures or high humidity.
- **Cable Care**: Handle the magnetic charging cable gently. Do not pull on the cable itself when disconnecting; always grasp the plug.

Troubleshooting

If you encounter issues with your AirWave headphones, try the following solutions:

Problem	Possible Solution
Headphones won't power on.	Ensure the headphones are fully charged. Long press the multifunction button for 2 seconds.
Cannot pair with device.	Ensure headphones are in pairing mode (indicator light flashing). Turn off and on Bluetooth on your device. Forget "AirWave" from your device's Bluetooth list and try pairing again. Ensure headphones are not connected to another device.

No sound or low volume.	Increase volume on both headphones and connected device. Check if TF card mode is active if you expect Bluetooth audio. Ensure headphones are properly connected to the device.
Intermittent connection.	Ensure your device is within the Bluetooth range (approx. 30 meters). Avoid obstacles between the headphones and your device. Minimize interference from other wireless devices.
Cannot switch to TF card mode.	Ensure the touch function is enabled and simultaneously press and hold the "+" and "-" buttons for 2 seconds.

Warranty and Support

For detailed warranty information and customer support, please refer to the official Langsdom website or contact their customer service directly. The product typically comes with a standard manufacturer's warranty covering defects in materials and workmanship.
You can also refer to the official User Guide PDF for more information:Langsdom AirWave User Guide (PDF)

© 2025 Langsdom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXJ22C1J

More documents and user manuals: **https://manuals.plus/**