Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom TG12B

Langsdom Theta PRO Wireless Earbuds User Manual

Model: TG12B | Brand: Langsdom

Introduction

The Langsdom Theta PRO Wireless Earbuds are designed to provide an immersive audio experience with enhanced bass, low latency, and clear call quality. Featuring a unique retro sci-fi design, these lightweight earbuds are perfect for gaming, music, and everyday use. This manual provides detailed instructions on setting up, operating, and maintaining your earbuds.

What's in the Box

- Langsdom Theta PRO Wireless Earbuds
- Rechargeable Storage Box (Charging Case)
- USB Charging Cable
- User Manual (this document)
- Additional Ear Adapters (various sizes)



Image: The Langsdom Theta PRO wireless earbuds and their charging case displayed within their clear retail packaging, showcasing the product's presentation.

Product Overview

The Theta PRO earbuds combine advanced technology with a distinctive aesthetic. Key features include:

Retro Sci-Fi Design

Inspired by robot movies, the earbuds and case feature a sleek, rounded cybernetic body with a smooth matte texture, offering a vintage sci-fi look.



Image: The Langsdom Theta PRO wireless earbuds and their charging case, highlighting their unique design.

Dual Modes: Gaming & Music

Equipped with advanced Bluetooth 5.3 technology, these earbuds offer both gaming and music modes. Switch to gaming mode for an ultra-low latency of just 45ms, ideal for lag-free gameplay.



Image: Visual representation of the earbuds' dual modes, with graphics depicting gaming and music scenarios.



Image: Earbuds in a futuristic setting, emphasizing the 45ms ultra-low latency feature for gaming.

Enhanced Talking & Audio Experience

The built-in ENC (Environmental Noise Cancellation) technology reduces background noise for clear phone calls. Custom 10mm high-sensitivity speakers deliver enhanced bass and full-bodied sound.



Image: A cutaway view of an earbud, highlighting the 10mm customized composite diaphragm for superior audio.

Extended Battery Life

Enjoy up to 7.5 hours of continuous usage on a single charge. With the charging case, total battery life extends up to 30 hours.



Image: The charging case with a prominent "30h" indicating its extended battery life.

Lightweight and Comfortable

Each earbud weighs only 3.6g, ensuring a lightweight and comfortable fit for extended use during gaming, workouts, or on the go.



Image: A person wearing the earbuds, emphasizing their lightweight and comfortable design.

Setup

Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and a power source. The ice blue light on the earphone will be on for about 30 seconds then turn off when charging. It will be on when fully charged.



Image: The charging case with its unique side hatch design, where earbuds are stored and charged.

Automatic Power On/Off

The earbuds automatically power on when the charging box is opened and power off when placed back into the box and closed.

Your browser does not support the video tag.

Video: Demonstrates automatic power on when opening the charging case and power off when closing it. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Manual Power On/Off

To manually power on the earbuds, long press the earphone touch area for about 2 seconds. To manually power off, long press the earphone touch area for about 2 seconds.

Your browser does not support the video tag.

Video: Illustrates how to manually power on and off the earbuds by long-pressing the touch area. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Pairing

When the earphone and phone are within effective distance, turn on your phone's Bluetooth function and enter the search pairing state. Select "THETA PRO" from the Bluetooth list of smart devices to connect.

Your browser does not support the video tag.

Video: Shows the process of pairing the earbuds with a smartphone via Bluetooth. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Operating Instructions

Music Mode Controls

- **Play/Pause:** Double-tap the touch area on either the Left (L) or Right (R) earbud.
- **Volume Up:** Long press the touch area on the Left (L) earbud for 1.5 seconds.
- **Volume Down:** Long press the touch area on the Right (R) earbud for 1.5 seconds.

Your browser does not support the video tag.

Video: Demonstrates how to control music playback, including play/pause and volume adjustments. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), triple-tap the touch area on the Right (R) earbud.

Your browser does not support the video tag.

Video: Shows how to activate the voice assistant feature using the earbud's touch controls. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Game Mode

To switch to Game Mode (or back to Music Mode), triple-tap the touch area on the Left (L) earbud. Game Mode provides ultra-low latency for an optimized gaming experience.

Your browser does not support the video tag.

Video: Demonstrates how to switch between Game Mode and Music Mode. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Call Mode

- **Answer/Hang up:** Double-tap the touch area on either the Left (L) or Right (R) earbud.
- **Reject Call:** Long press the touch area on either the Left (L) or Right (R) earbud for 2 seconds.

Your browser does not support the video tag.

Video: Illustrates how to answer, hang up, and reject phone calls using the earbud controls. (Source: User Guides THETA PRO Bluetooth Wireless Earbuds by LANGSDOM)

Maintenance

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For the ear tips, you may gently remove them and clean with mild soap and water, ensuring they are completely dry before reattaching.

Storage

Always store the earbuds in their charging case when not in use to protect them from damage and to keep them charged.

Water Resistance

The earbuds are water resistant. Avoid submerging them in water or exposing them to excessive moisture for prolonged periods.

Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are charged. Place them back in the case, close it, then open it again. Check your device's Bluetooth settings and forget "THETA PRO" if previously paired, then try pairing again.
- **No sound or low volume:** Check the volume levels on both your device and the earbuds. Ensure earbuds are properly seated in your ears.
- **Intermittent connection:** Ensure your device is within the effective Bluetooth range. Avoid physical obstructions between the earbuds and your device.
- **Charging issues:** Verify the USB-C cable and power source are working. Ensure the charging contacts on the earbuds and case are clean and free of debris.

Specifications

Feature	Detail
Model Name	THETA PRO
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Latency	45 Milliseconds (Game Mode)
Audio Driver Type	Dynamic Driver (10mm)
Noise Control	Passive Noise Cancellation (ENC for calls)
Battery Life (Earbuds)	Up to 7.5 hours (single use)
Total Battery Life (with Case)	Up to 30 hours
Item Weight (Each Earbud)	3.6g
Water Resistance Level	Water Resistant
Color	Black
Included Components	Cable, User Manual, Rechargeable storage box

Warranty & Support

For detailed warranty information and further support, please refer to the official Langsdom website or the comprehensive User Guide PDF available at: Langsdom Theta PRO User Guide PDF.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CXNSZVN8

More documents and user manuals: **https://manuals.plus/**