Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AUSDOM AUSDOM 98Pro-Black&Pink-Silent

AUSDOM 98Pro Silent Wireless Mechanical Keyboard User Manual

Model: AUSDOM 98Pro-Black&Pink-Silent

Introduction

Thank you for choosing the AUSDOM 98Pro Silent Wireless Mechanical Keyboard. This manual provides detailed instructions on how to set up, operate, and maintain your new keyboard. Designed for efficiency and comfort, this keyboard features tri-mode connectivity, a silent gasket structure, hot-swappable switches, and customizable backlighting.

What's in the Box

- Wireless Mechanical Keyboard x1
- USB Receiver x1
- Type-C Charging Cable x1
- Instruction Manual x1
- Mechanical Switch x3
- Switch Puller x1

Setup

Connection Modes

Your AUSDOM 98Pro keyboard supports three connection modes: Bluetooth, 2.4GHz wireless, and wired USB-C. It can connect to up to 5 devices simultaneously and is compatible with both Windows and macOS systems.

Bluetooth Mode:

1. Toggle the switch on the keyboard to BT mode.
2. Press and hold Fn + 1/2/3 to enter pairing mode for the desired Bluetooth channel. The indicator light will flash.
3. On your device, search for "AUSDOM 98Pro" in the Bluetooth settings and connect.

2.4GHz Wireless Mode:

1. Toggle the switch on the keyboard to 2.4G mode.

2. Insert the USB receiver into an available USB port on your computer.
3. The keyboard will automatically connect.

Wired USB-C Mode:

1. Toggle the switch on the keyboard to USB-C mode.
2. Connect the keyboard to your computer using the provided USB-C cable.
3. The keyboard will be recognized as a wired device.



Figure 1: Three Connection Modes

Charging the Keyboard

The keyboard is equipped with a 3000mAh battery. Connect the USB-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, wall adapter). The indicator light will show charging status.



Figure 2: Independent USB-C Charging Port

Operating Instructions

Backlight Adjustment

The keyboard features 16 gorgeous backlight modes and 4 levels of brightness control. You can easily adjust the backlight to suit your preference and ambient lighting conditions.

Fn + ← / → **:** Change backlight levels (brightness).

Fn + ↑ / ↓ **:** Change backlight effects (modes).




Figure 3: Backlight Controls

Hot-Swappable Switches

The AUSDOM 98Pro keyboard features hot-swappable technology, allowing you to easily change keycaps and switches (3-pin/5-pin) without disassembling the entire keyboard. This enables customization of the layout and feel.



Figure 4: Hot-Swappable Switches

Programmable Software

Customize your keyboard experience with the dedicated programmable software. This software allows for customized light effects, macro programming for all keys, and shortcut key customization. The software is compatible with Windows systems only. Driver downloads are available from the official AUSDOM website.



Figure 5: Programmable Software Interface

Maintenance

To ensure the longevity and optimal performance of your AUSDOM 98Pro keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keycaps and keyboard body. For deeper cleaning, you may carefully remove keycaps using the provided switch puller and clean underneath. Avoid using harsh chemicals or abrasive materials.
- **Keycaps:** The keyboard features durable PBT keycaps that are oil-resistant and non-slip, designed to maintain their appearance over time.
- **Switches:** The pre-lubed switches provide a smooth typing experience. Avoid exposing the switches to excessive dust or liquids.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter any issues with your AUSDOM 98Pro keyboard, please refer to the following common troubleshooting steps:

- **Keyboard not responding:**
  - Ensure the keyboard is charged.
  - Check the connection mode switch (BT/2.4G/USB-C) is set correctly.
  - For 2.4GHz, ensure the USB receiver is securely plugged in.
  - For Bluetooth, re-pair the device.
  - Try connecting via USB-C cable to rule out wireless issues.
- **Backlight not working or dim:**
  - Ensure the keyboard is charged.
  - Use Fn + ← / → to adjust brightness levels.
  - Use Fn + ↑ / ↓ to cycle through backlight modes.
- **Keys not registering or double-typing:**
  - Ensure the keycap is properly seated.
  - If a specific switch is faulty, consider replacing it using the hot-swappable feature.
  - Clean any debris around or under the affected key.
- **Software issues:**
  - Ensure you have the latest software version from the official AUSDOM website.
  - The software only supports Windows systems.

If the issue persists, please contact AUSDOM customer support for further assistance.

Specifications

Feature	Detail
Product Dimensions	15.51 x 5.59 x 1.46 inches
Item Weight	3.63 pounds
Manufacturer	AUSDOM
Item Model Number	AUSDOM 98Pro-Black&Pink-Silent
Batteries	1 Lithium Polymer batteries required (included)
Compatible Devices	Laptop, PC, Tablet
Connectivity Technology	2.4G, Bluetooth, USB-C
Keyboard Description	Mechanical
Recommended Uses	Gaming
Special Features	3-Mode Connection, Backlit, Ergonomic, Hot-Swappable, Silent

Color	Black&Pink-Silent
Number of Keys	97
Style	Modern

Warranty and Support

AUSDOM provides a standard warranty for its products. For detailed warranty information, technical support, or service inquiries, please visit the official AUSDOM website or contact their customer service directly. Please retain your proof of purchase for warranty claims.
Official AUSDOM Store: AUSDOM Store on Amazon

© 2024 AUSDOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYZZCH8B

More documents and user manuals: **https://manuals.plus/**