Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mimoglad 5188H

Mimoglad Ergonomic Home Office Chair (Model 5188H) User Manual

Model: 5188H

1. Safety Information

- **Maximum Weight Capacity:** Do not exceed the maximum weight recommendation of 250 lbs (113 kg).
- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten as necessary.
- Use the chair on a level and stable surface to prevent tipping.
- Keep hands and fingers clear of moving parts during adjustments.
- This product is intended for indoor use only.
- Keep small parts away from children during assembly.

2. Product Overview

The Mimoglad Ergonomic Home Office Chair, Model 5188H, is designed to provide comfort and support for extended periods of sitting. It features adjustable lumbar support, an adjustable headrest, flip-up armrests, and a rocking function to promote a healthy posture and enhance productivity.



Image 2.1: Overall dimensions of the Mimoglad Ergonomic Home Office Chair.

Key features include:

- **Ergonomic Design:** Encourages an 'S-shaped' spinal posture with proper support.
- **Breathable Mesh Backrest:** Ensures ventilation and airflow to keep you cool.
- **High-Density Foam Seat:** Provides superior resilience and cushioning for pressure relief.
- **Flip-Up Armrests:** Allows for space-saving storage under desks and versatile use.
- **Adjustable Headrest:** For optimal neck and head support.
- **Adjustable Lumbar Support:** Customizable lower back support.
- **Rocking Function:** Offers relaxation with a 90-135 degree tilt.
- **360° Swivel:** For ease of movement and convenience.

3. Setup and Assembly

This product requires assembly. Detailed assembly instructions and all necessary tools are typically included in the product packaging. Please refer to those instructions for a step-by-step guide.

General Assembly Tips:

- Unpack all components and verify against the parts list provided in your package.
- It is recommended to assemble the chair on a soft, clean surface to prevent scratches.
- When attaching the seat back to the seat, installing the lower vertical screw first can facilitate easier alignment.
- Ensure all connections are firm but do not overtighten screws until all components are loosely fitted.

4. Operating Instructions

4.1. Headrest Adjustment

The headrest can be adjusted vertically to provide optimal support for your neck and head. Gently pull or push the headrest up or down to your desired height. It has approximately 1.6 inches of vertical adjustment.



Image 4.1: Adjusting the headrest for superior head support.

4.2. Lumbar Support Adjustment

The lumbar support is designed to provide customizable support to your lower back. The sponge-filled lumbar support can be adjusted to a height of 1.2 inches to fit your body's natural curve, reducing strain and promoting good posture.



Image 4.2: Detail of the adjustable sponge-filled lumbar support.

4.3. Flip-Up Armrests

The armrests can be flipped up by 90 degrees. This feature allows you to push the chair closer to your desk, saving space when not in use, or to provide more freedom of movement during certain tasks.



Image 4.3: Demonstrating the 90-degree flip-up armrests.

4.4. Height Adjustment

To adjust the chair's height, locate the lever under the seat on the right side. Pull the lever upwards while seated to lower the chair, or stand up and pull the lever upwards to raise the chair. The chair can be adjusted by approximately 3.93 inches.

4.5. Rocking Function

The chair features a rocking function that allows for a tilt range of 90 to 135 degrees. To activate the rocking function, pull out the lever located under the seat. To lock the chair in an upright position, push the lever in. The tension of the rocking mechanism can be adjusted by turning the round knob located under the seat, allowing you to customize the rocking resistance.




Image 4.4: Illustration of the rocking function and tension adjustment.

4.6. Swivel Function

The chair is equipped with a 360-degree swivel mechanism, allowing for easy rotation and access to different areas of your workspace without needing to move the entire chair.

5. Maintenance

- **Cleaning:** Wipe clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the chair's finish or fabric.
- **Regular Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Caster Care:** Keep the casters clean from hair and debris to ensure smooth rolling.
- **Fabric Care:** For mesh and foam parts, spot clean with a mild detergent solution if needed.

6. Troubleshooting

- **Chair Squeaks:** Check all bolted connections and tighten them. A small amount of silicone lubricant can be applied to moving parts if squeaking persists.
- **Chair Does Not Adjust Height:** Ensure the height adjustment lever is fully engaged. If the gas lift is faulty, it may need replacement.
- **Chair Does Not Rock:** Verify that the rocking function lever is pulled out. Adjust the tension knob to ensure it's not too tight.
- **Casters Not Rolling Smoothly:** Inspect casters for trapped debris (hair, lint) and clean them. Ensure the chair is on an appropriate surface (hard floor recommended).
- **Headrest Not High Enough:** While the headrest is adjustable, it may have limitations based on user height. Refer to product specifications for recommended user height.

7. Specifications

Feature	Specification
Brand	Mimoglad
Model Name	5188H
Color	Black
Product Dimensions (D x W x H)	20"D x 20"W x 25"H (Note: These dimensions may refer to packaging or a specific component. Refer to Image 2.1 for full chair dimensions.)
Maximum Weight Recommendation	250 Pounds (113 kg)
Material	Nylon (Finish Type), Foam (Fill Material)
Special Features	Adjustable Headrest, Adjustable Height, Adjustable Lumbar, Flip-Up Arms, Rocking Function, 360° Swivel
Recommended Uses	Gaming, Office
Item Weight	30 Pounds (13.6 kg)
Surface Recommendation	Hard Floor

8. Warranty and Support

Mimoglad offers a comprehensive warranty for this product:

- All parts are free to replace within 5 years from the date of purchase.
- A whole new chair replacement is provided within 2 years from the date of purchase for significant defects.

To claim warranty service or for any support inquiries, please contact Mimoglad customer service. Keep this manual and your purchase receipt for reference. You can typically find contact information on the Mimoglad official website or through your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZNZ9J2Z

More documents and user manuals: **https://manuals.plus/**