**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Chicco 00009948000000

# Chicco Push&Go Horse Instruction Manual

Model: 00009948000000

## Introduction

Thank you for choosing the Chicco Push&Go Horse. This manual provides essential information for the safe and proper use, setup, and maintenance of your new toy. Please read it thoroughly before use and retain it for future reference.

## Safety Information

**WARNING:**
Always follow the manufacturer's instructions for safe operation and use of this product. Adult supervision is recommended during play.

- Ensure all parts are securely assembled before allowing a child to play.
- Do not use the toy on uneven surfaces or near stairs.
- Keep packaging materials away from children to prevent suffocation hazards.
- Regularly inspect the toy for any damage or loose parts. Discontinue use if damage is found.

## What's in the Box

Upon opening the package, please verify that all components are present:

- 1 x Chicco Push&Go Horse toy

## Setup

The Chicco Push&Go Horse is designed for immediate play and typically requires no complex assembly. It comes pre-assembled and ready for use.

1. Remove the toy from its packaging.
2. Inspect the toy for any signs of damage or loose parts before first use.
3. Ensure all wheels spin freely.




This image displays the Chicco Push&Go Horse toy. It is primarily white with four bright blue wheels, each featuring a yellow star design. The horse has a blue bridle, a green collar, and a yellow patch on its back, suggesting a saddle. The toy is designed for young children to push and play with.

## Operating Instructions

The Push&Go Horse is designed for simple, intuitive play:

- Place the toy on a flat, smooth surface.
- Encourage the child to push the horse forward. The wheels are designed to roll smoothly, allowing the toy to move easily across the floor.
- The toy is intended for pushing and imaginative play, promoting gross motor skills.

## Maintenance

Proper maintenance will extend the life of your Chicco Push&Go Horse:

- **Cleaning:** Wipe the toy with a damp cloth and mild soap. Do not immerse in water. Dry thoroughly before storage.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check for loose parts, cracks, or excessive wear. If any damage is found, discontinue use immediately.

## Troubleshooting

If you encounter any issues with your Push&Go Horse, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Wheels do not roll smoothly. | Debris caught in wheels, or surface is not smooth. | Check wheels for hair or lint and remove. Ensure toy is used on a flat, clean surface. |
| Toy appears unstable. | Used on an uneven surface. | Move the toy to a flat, stable surface. |

## Specifications

| Attribute | Detail |
|---|---|
| Product Dimensions | 0.39 x 0.39 x 0.39 inches |
| Item Weight | 13.7 ounces |
| ASIN | B0D1VTB7BP |
| Item Model Number | 00009948000000 |
| Manufacturer Recommended Age | 24 months - 3 years |
| Manufacturer | Artsana spa |

## Warranty and Support

Chicco products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official Chicco website. If you have any questions or require assistance, please contact Chicco customer support.
**Online Support:** www.chicco.com

## Official Product Videos

No official product videos from the seller were found for this item.

© 2024 Chicco. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0D1VTB7BP**

More documents and user manuals: **https://manuals.plus/**