Pxwaxpy HX45K8

Pxwaxpy Mini Portable Charger Power Bank User Manual

Model: HX45K8

INTRODUCTION

Thank you for choosing the Pxwaxpy Mini Portable Charger Power Bank. This compact and powerful device is designed to provide convenient and fast charging for your iPhone on the go. With its 5200mAh capacity and 20W PD fast charging capability, you can keep your device powered throughout your day without the need for extra cables. This manual will guide you through the setup, operation, and maintenance of your new power bank.

PRODUCT OVERVIEW

Key Features

- **20W PD Fast Charging:** Directly plug-in charging for your iPhone without an extra cable, providing quick and efficient power.
- **5200mAh Capacity:** Sufficient power to keep your iPhone alive on the go.
- **Smart LCD Digital Display:** Shows the exact battery percentage of the portable charger.
- **Ultra-Compact Design:** As compact as a lipstick, weighing approximately 100g, making it easy to carry.
- **Built-in Smart Chip:** Protects your phone battery from overcharge, over-voltage, over-current, and short circuit.
- **USB-C Port:** Supports both input and output for versatile charging.

Package Contents

- 5200mAh Mini Portable Charger Power Bank for iPhone x 1
- Charging Cable x 1
- User Manual x 1

Compatibility

This portable charger is specifically designed for iPhone models with a Lightning port. It is compatible with:

- iPhone 14 Pro Max / 14 Pro / 14 Plus / 14 Mini / 14 Series

- iPhone 13 Pro Max / 13 Pro / 13 Mini / 13 Series
- iPhone 12 Pro Max / 12 Pro / 12 Mini / 12 Series
- iPhone 11 Pro Max / 11 Pro / 11 Mini / 11 Series
- iPhone XR / Xs / X / Xs Max Series
- iPhone 8 / 8 Plus / 7 / 7 Plus / 6 / 6s Plus / SE Series

Note: This power bank is NOT compatible with iPhone 15 Series or any USB-C devices.

Figure 1: Pxwaxpy Mini Portable Charger connected to an iPhone.

Compatible with iPhone Series


iPhone 14 Series

iPhone 13 Series

iPhone 12/11 Series

iPhone X Series

iPhone 8/7/6 Series

Reminder

*USB-C Devices

Not
Applicable

Figure 2: Compatibility details for the Pxwaxpy Mini Portable Charger.

SETUP

Initial Charging of the Power Bank

1. Locate the included USB-A to USB-C charging cable.
2. Insert the USB-C end of the cable into the USB-C port on the side of the power bank.
3. Connect the USB-A end of the cable to a compatible USB wall adapter (not included) or a computer's USB port.
4. The LCD digital display on the power bank will show the charging progress, indicating the battery percentage.
5. Charge the power bank until the display shows 100% for optimal performance on first use. A full charge typically takes about 3 hours with a 5V/2A charger, or 1.5 hours with a 9V/2A quick charger.

Figure 3: Recharging the Pxwaxpy Mini Portable Charger.

OPERATING INSTRUCTIONS

Charging Your iPhone

1. Remove the protective cap from the Lightning connector on the power bank.
2. Align the Lightning connector with your iPhone's charging port.
3. Gently plug the power bank directly into your iPhone. Ensure a secure connection.
4. The power bank will automatically begin charging your iPhone. The LCD display will show the remaining battery percentage of the power bank.
5. To stop charging, simply unplug the power bank from your iPhone.

Mini and Lightweight

Size: 3.03*1.45*1.05 in

Weight: around 100g

Figure 4: Direct charging of an iPhone using the power bank.

Recharging the Power Bank

When the power bank's battery level is low, as indicated by the LCD display, recharge it using the provided USB-C cable as described in the "Initial Charging of the Power Bank" section. You can also charge the power bank while it is simultaneously charging your iPhone (pass-through charging).

Pass-Through Technology
Charge Your Devices While Recharging

3 hrs
5V-2A Charger

100% Charged

Press once to wake it up

Lightning

100%

Tips: Charger not included, USB A-C cable included

Figure 5: Pass-Through Charging capability.

MAINTENANCE AND CARE

- Avoid exposing the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Do not drop, disassemble, or attempt to repair the device yourself. This may void the warranty and pose safety risks.
- Keep the power bank away from water and other liquids.
- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- When not in use for extended periods, store the power bank in a cool, dry place and recharge it every 3-6 months to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Power bank not charging iPhone.	Low battery on power bank; loose connection; incompatible iPhone model.	Recharge the power bank; ensure the Lightning connector is fully inserted; verify iPhone model compatibility.
Power bank not recharging.	Faulty charging cable or adapter; loose connection; power bank malfunction.	Try a different USB-C cable and wall adapter; ensure the USB-C cable is fully inserted; contact customer support if the issue persists.
LCD display not working.	Power bank is off or completely drained; internal issue.	Press the power button (if applicable, though this model seems to auto-activate); recharge the power bank; contact customer support.
Slow charging.	Using a low-power adapter for recharging; iPhone battery health; background apps on iPhone.	Use a 20W PD compatible wall adapter for faster recharging; close unnecessary apps on your iPhone.

SPECIFICATIONS

Attribute	Detail
Model Number	HX45K8
Battery Capacity	5200mAh
Output (Lightning)	DC 5V=2A (for all iPhones)
Input/Output (USB-C)	DC 5V=3A (PD Type-C)
Product Dimensions	3.03 x 1.93 x 1.05 inches
Item Weight	3.53 ounces (approx. 100g)
Manufacturer	Dongguan Yuanhaoxun Technology Co., Ltd

Easy to Hold and Portable

Figure 6: Dimensions and portability of the power bank.

WARRANTY AND SUPPORT

Pxwaxpy is committed to providing high-quality products and excellent customer service. Your Mini Portable Charger Power Bank comes with:

- **30-Day Easy Returns:** If you are not satisfied with your purchase, you may return it within 30 days.
- **Lifetime Technical Support:** For any technical questions or assistance, please contact Pxwaxpy customer support.

For support inquiries, please refer to the contact information provided on the product packaging or the official Pxwaxpy website.

Related Documents - HX45K8

	[Pxwaxpy HX200J2 Portable Power Bank User Manual](#) User guide for the Pxwaxpy HX200J2 portable power bank, covering features, specifications, charging methods (USB and solar), LED indicators, flashlight function, and safety warnings.
	[Operation Instruction: Pxwaxpy HX160Y1 Portable Power Source](#) Detailed operation instructions and specifications for the Pxwaxpy HX160Y1 portable power source (power bank), including charging, discharging, safety features, and warnings.
	[Portable Power Source Operation Instructions](#) Comprehensive operation instructions for a portable power source, detailing product features, charging methods (USB and solar), power indicator functions, and important safety notices and warnings.