Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Clihome B0D2VNVXPV

Clihome 7-Drawer High Gloss Dresser Instruction Manual

Model: B0D2VNVXPV

1. Introduction

Thank you for purchasing the Clihome 7-Drawer High Gloss Dresser. This manual provides important information for the safe assembly, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Safety Information

To ensure safe use of this product, please observe the following guidelines:

- **Anti-Tip Device:** It is highly recommended to install the included anti-tip device to prevent the dresser from tipping over, especially in households with children. Secure the dresser to a wall stud using appropriate hardware.
- **Weight Limits:** The top panel of the dresser has a maximum weight capacity of 150 pounds. Each drawer can support up to 30 pounds. Do not exceed these limits.
- **Even Distribution:** Distribute weight evenly across the drawers and top surface to maintain stability.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are securely tightened before use.
- **Supervision:** Keep children away from the assembly area and do not allow them to climb on or play with the dresser.

3. Package Contents

Before assembly, verify that all components and hardware are present. If any parts are missing or damaged, please contact customer support.

- Dresser panels (top, bottom, sides, back, drawer fronts)
- 7 Drawer boxes

- Metal legs with floor protectors
- Gold handles
- Drawer slides and runners
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip kit
- Assembly instructions

4. Setup and Assembly

Assembly is required for this dresser. Follow the clear, illustrated instructions provided in the package. All components and hardware are labeled for easy identification.

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the furniture.
2. **Identify Parts:** Unpack all components and match them with the parts list in the assembly guide.
3. **Assemble Frame:** Begin by assembling the main frame of the dresser according to the step-by-step diagrams. Ensure all connections are secure.
4. **Install Drawer Slides:** Attach the drawer slides to the dresser frame and the drawer boxes as indicated.
5. **Assemble Drawers:** Construct the 7 drawer boxes, ensuring they are square and sturdy.
6. **Attach Handles:** Secure the gold handles to the drawer fronts.
7. **Install Legs:** Attach the metal legs to the bottom of the dresser. Ensure floor protectors are in place.
8. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots.
9. **Install Anti-Tip Kit:** Securely attach the anti-tip device to the back of the dresser and to a wall stud. This step is crucial for safety.



Image: The Clihome 7-Drawer High Gloss Dresser fully assembled in a living space, showcasing its design and functionality.



Image: Detailed view highlighting the dresser's features such as the 100 lbs top weight capacity, 20 lbs per shelf capacity, gold metal base, matching handle pulls, and included floor protectors.

5. Operating Instructions

The Clihome 7-Drawer Dresser is designed for organized storage and aesthetic enhancement of your living space.

- **Drawer Usage:** Gently pull and push the drawers to open and close. Avoid forcing them to prevent damage to the slides.
- **Storage:** Utilize the seven spacious drawers to store clothing, linens, accessories, or other personal items.
- **Top Surface:** The generous top surface can be used to display decorative items, lamps, or other personal belongings. Ensure items placed on top do not exceed the 150-pound weight limit.
- **Versatile Placement:** This dresser can function as a storage cabinet, buffet, living room organizer, entryway table, or office coffee bar.

6. Maintenance

Proper care will help maintain the appearance and longevity of your Clihome dresser.

- **Cleaning:** Wipe the surface with a dry, soft cloth. The dresser features an eco-friendly, waterproof finish that is easily wipeable. Avoid abrasive cleaners or harsh chemicals that could damage the high-gloss finish.
- **Spills:** Promptly wipe up any spills to prevent staining or damage to the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration over time.

7. Troubleshooting

If you encounter any issues with your dresser, consider the following common solutions:

- **Wobbly Dresser:** Ensure all assembly screws are fully tightened. Check that the dresser is placed on a level surface. Adjust the floor protectors on the metal legs if necessary.
- **Drawers Not Closing Smoothly:** Verify that the drawer slides are correctly installed and aligned. Check for any obstructions within the drawer tracks. Ensure drawers are not overloaded.
- **Scratches on Floor:** The metal legs are equipped with floor protectors. If scratches occur, ensure the protectors are properly seated and consider adding additional felt pads for extra protection.
- **Damaged Parts:** If any part is damaged during shipping or assembly, do not attempt to force it. Contact customer support for replacement parts.

8. Specifications

Feature	Detail
Brand	Clihome
Model	B0D2VNVXPV
Product Dimensions	47.8"W x 15.75"D x 32"H
Color	Black
Material	Engineered Wood, Metal
Finish Type	Glossy
Number of Drawers	7
Item Weight	135 pounds
Top Panel Capacity	150 pounds
Drawer Capacity (each)	30 pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth




Image: Dimensional drawing of the dresser, indicating a width of 47.8 inches, height of 31.77 inches, and depth of 15.75 inches.

9. Warranty Information

For specific warranty details regarding your Clihome 7-Drawer High Gloss Dresser, please refer to the documentation included with your purchase or contact Clihome customer support directly. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

10. Customer Support

If you have any questions, require assistance with assembly, or need to report missing or damaged parts, please contact Clihome customer support. Our team is available to assist you with any inquiries.
For support, please visit the official Clihome website or refer to the contact information provided with your purchase.

© 2024 Clihome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D2VNVXPV

More documents and user manuals: **https://manuals.plus/**