Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX GM905DB+M913GX

DeLUX Wireless Ergonomic Keyboard and Side Scroll Wheel Mouse Combo

Model: GM905DB+M913GX

Introduction

Thank you for choosing the DeLUX Wireless Ergonomic Keyboard and Side Scroll Wheel Mouse Combo. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new devices. Please read this manual carefully before use to ensure optimal performance and longevity of your product.

1. Setup

1.1 Package Contents

- DeLUX Ergonomic Wireless Keyboard (GM905DB)
- DeLUX Wireless Side Scroll Wheel Mouse (M913GX)
- USB 2.4G Receiver
- User Manual



Image: DeLUX Wireless Ergonomic Keyboard and Mouse Combo with USB Receiver. This image displays the full product package, including the ergonomic keyboard, the vertical mouse, and the compact USB receiver, providing a clear overview of what is included.

1.2 Battery Installation

The mouse requires batteries for operation. Please follow these steps:

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert the required AA or AAA batteries (not included) according to the polarity indicators (+/-) inside the compartment.
4. Close the battery compartment cover securely.



Image: Mouse Battery Compartment. This image shows the underside of the mouse with the battery compartment open, illustrating where to insert the batteries.

1.3 Connecting the Devices

Your DeLUX combo supports both 2.4G wireless and Bluetooth 5.0 connectivity, allowing connection to up to 3 devices.

2.4G Wireless Connection (Plug & Play)

1. Take out the USB 2.4G receiver from the mouse's battery compartment or packaging.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the keyboard and mouse. They should automatically connect to the receiver.



Image: USB 2.4G Receiver Plug & Play. This image illustrates the compact USB receiver being plugged into a laptop, demonstrating the simple plug-and-play setup for 2.4G wireless connection.

Bluetooth Connection (BT1 / BT2)

1. Ensure the keyboard and mouse are powered on.
2. On the keyboard, press and hold the **BT1** or **BT2** button for 3-5 seconds until the indicator light flashes, indicating pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for new devices.
4. Select "DeLUX Keyboard" or "DeLUX Mouse" from the list of available devices to pair.
5. Repeat for the other device (keyboard or mouse) if connecting both via Bluetooth.



Image: Multi-Device Workflow with 2.4G and Bluetooth. This image shows the keyboard's dedicated buttons for switching between 2.4G wireless and two Bluetooth connections (BT1, BT2), illustrating its capability to connect to multiple devices simultaneously.

2. Operating Instructions

2.1 Keyboard Features

- **Ergonomic Split Design:** The keyboard features a curved and split structure designed to promote a natural typing posture, reducing strain on your hands, wrists, and shoulders.



Image: Split Ergo Structure for Natural Arm Angle. This image demonstrates the ergonomic split design of the keyboard, showing how it aligns with natural arm angles for comfortable typing posture.

- **Pillowed Wrist Rest:** A built-in wrist rest with skin-friendly synthetic leather provides comfortable support for your palms.
- **Multi-Device Switching:** Easily switch between up to 3 connected devices (2.4G, BT1, BT2) using the dedicated buttons on the keyboard.
- **Dedicated Multimedia Keys:** Access volume control, play/pause, and other media functions directly from the keyboard.



Image: Dedicated Multimedia Keys on Keyboard. This image highlights the central multimedia control cluster on the keyboard, providing easy access to functions like volume and brightness.

- **One-click Return to Desktop Button:** A dedicated button allows for quick return to your computer desktop, enhancing privacy and workflow efficiency. This button is located among the function keys on the top right of the keyboard.
- **Front and Palm Kickstand:** Adjustable kickstands allow for different typing angles (0°, 3°, 5°) to suit seated or standing postures.



Image: Front and Palm Kickstand Angles. This image illustrates the adjustable kickstands on the keyboard, showing how they can be set to 0°, 3°, or 5° for varied ergonomic preferences.

2.2 Mouse Features

- **Unique Side Scroll Wheel:** The mouse features a thumb wheel on its left side for horizontal scrolling, useful in applications like WPS and web browsing. (Note: This feature may not work with all Office Software).



Image: Side Scroll Wheel Design. This image highlights the unique side scroll wheel on the mouse, designed for horizontal navigation and enhancing workflow efficiency.

- **High Precise Tracking (DPI Adjustment):** The mouse offers 3 adjustable DPI levels (800/1200/1600 DPI) for precise and fluent tracking, suitable for various tasks and screen resolutions.



Image: High Precise Tracking with DPI Adjustment. This image illustrates the mouse's capability for high-precision tracking, indicating its adjustable DPI settings (800/1200/1600) for smooth and accurate cursor movement.

3. Maintenance

3.1 Cleaning

To maintain the appearance and functionality of your keyboard and mouse:

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- For the keyboard, use compressed air to remove debris from between the keys.

3.2 Battery Replacement

When the mouse's performance degrades or it becomes unresponsive, it may be time to replace the batteries. Refer to section 1.2 for battery installation instructions.

4. Troubleshooting

If you encounter issues with your DeLUX Wireless Ergonomic Keyboard and Mouse Combo, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low battery; Loose USB receiver; Out of range; Incorrect connection mode.	Replace batteries; Re-insert USB receiver; Move devices closer to receiver; Ensure correct 2.4G/BT mode is selected.
Lag or intermittent connection	Interference from other wireless devices; Weak signal.	Move away from other wireless devices (e.g., Wi-Fi routers); Ensure clear line of sight to receiver.
Side scroll wheel not working in Office Software	Software incompatibility.	This is a known limitation; the side scroll wheel is designed for WPS and web browsing, not all Office applications.
Cannot pair via Bluetooth	Device not in pairing mode; Bluetooth on host device is off.	Ensure keyboard/mouse is in pairing mode (flashing indicator); Turn on Bluetooth on your computer/device.

5. Specifications

Feature	Detail
Brand	DeLUX
Model	GM905DB (Keyboard) + M913GX (Mouse)
Connectivity Technology	2.4G Wireless, Bluetooth 5.0
Compatible Devices	Personal Computer (Windows, Mac, Android, etc.)
Keyboard Special Feature	Ergonomic Split Design, Built-in Wrist Rest, Multi-Device Switching, Multimedia Keys, One-click Desktop Button
Mouse Special Feature	Side Scroll Wheel, Adjustable DPI (800/1200/1600)
Power Source	AA or AAA batteries (for mouse)
First Available Date	April 30, 2024

6. Warranty and Support

DeLUX products are designed for reliability and performance. This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official DeLUX website.
If you require technical support, have questions about your product, or need assistance with troubleshooting that is not covered in this manual, please contact DeLUX customer service through their official support channels. Contact information can typically be found on the DeLUX website or on your product packaging.

© 2024 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D31LXSGM

More documents and user manuals: **https://manuals.plus/**