Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

kejector Power Lift Recliner Chair

kejector Power Lift Recliner Chair User Manual

Model: Power Lift Recliner Chair

1. Introduction

Thank you for choosing the kejector Power Lift Recliner Chair. This manual provides essential information for the safe and effective use of your new recliner, including setup, operation, maintenance, and troubleshooting. Please read this manual thoroughly before using the product and retain it for future reference.



Image 1.1: The kejector Power Lift Recliner Chair, showcasing its design and blue fabric in a home environment.

2. Safety Instructions

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- Always ensure the power cord is securely connected and not damaged.
- Keep children and pets away from the moving parts of the chair, especially during operation of the lift and recline functions.
- Do not allow anyone to sit on the footrest when it is extended.
- Avoid placing hands or feet near the chair's mechanism when operating.
- Do not use the chair if any part is damaged or malfunctioning. Contact customer support immediately.
- Ensure there is adequate space around the chair for safe reclining and lifting.
- This chair is designed for indoor use only.

3. Package Contents

The kejector Power Lift Recliner Chair typically includes the following components:

- Power Lift Recliner Chair (main unit)
- Arm Pad (integrated or separate)
- Cushion (integrated or separate)
- Ottoman (integrated footrest)
- Power Adapter and Remote Control

4. Setup Instructions

This kejector Power Lift Recliner Chair is designed for minimal assembly. Follow these steps to prepare your chair for use:

1. Carefully remove all components from the packaging.
2. Position the chair in your desired location, ensuring sufficient clearance for reclining and lifting functions.
3. Connect the power adapter to the chair's power input port, typically located at the rear or underside.
4. Plug the power adapter into a standard electrical outlet.
5. Ensure all connections are secure before operating the chair.



Image 4.1: Front view of the kejector Power Lift Recliner Chair, ready for power connection.

5. Operating Instructions

Your kejector Power Lift Recliner Chair comes with a remote control to manage its various functions.

5.1. Power Lift Function

The power lift mechanism assists users in standing up from the chair without straining their back or knees. Press and hold the 'Lift' button on the remote control. The chair will slowly tilt forward and lift, gently assisting you to a standing position. Release the button to stop at any desired height.

5.2. Reclining Function

To recline, press and hold the 'Recline' button on the remote control. The backrest will lean back, and the footrest will extend. The chair can recline up to 135 degrees. Release the button when you reach your desired reclining angle. To return to the upright position, press and hold the 'Upright' button.



Image 5.1: Illustration of the power lift and reclining capabilities, demonstrating the chair's adjustable positions.

5.3. Massage and Heating Functions

The chair is equipped with a massage and heating system for enhanced comfort. Use the remote control to activate these features:

- **Massage Modes:** Select from 3 massage modes targeting the back, lumbar, thighs, and lower legs.
- **Massage Intensity:** Adjust the intensity (high or low) and choose from 3 vibration strengths.
- **Heating:** Activate the 2 heat settings for warmth in the lumbar area.
- **Timer:** Set the massage and heat functions to operate for 10, 20, or 30 minutes using the timer function.



Image 5.2: Remote control and visual guide for the massage and heating features, including lumbar heat, 8 massage points, 4 massage parts, 3 modes, 3 vibration strengths, and timer options.

5.4. Side Pocket Usage

A convenient side storage pocket is integrated into the armrest. This pocket is ideal for storing the remote control, magazines, glasses, or other small personal items within easy reach.



Image 5.3: Side view of the recliner, showing the practical side storage pocket.

6. Product Features (Detailed)

The kejector Power Lift Recliner Chair incorporates several design elements for enhanced comfort and convenience:

- **Big Ears Armrest:** Selected high-quality padded armrests provide flexible and thick support for optimal arm comfort.
- **Storage Pockets:** In addition to the side pocket, the chair may feature other convenient storage options for loose items.
- **Overstuffed Headrest:** The headrest and backrest are adequately filled with soft and elastic foam, providing considerate support to the body.



Image 6.1: Detailed views highlighting the comfortable armrests, practical storage pockets, and supportive headrest.

7. Maintenance and Care

Proper care will extend the life and appearance of your recliner:

- **Cleaning:** The manufacturer recommends **Dry Clean** for the fabric. For minor spills, gently blot with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Inspection:** Periodically check all connections and moving parts for tightness and proper function.
- **Power Cord:** Ensure the power cord is not pinched or damaged.
- **Placement:** Avoid direct sunlight and excessive moisture to prevent fading or damage to the fabric and internal components.

8. Troubleshooting

If you encounter any issues with your kejector Power Lift Recliner Chair, refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Chair does not operate (no power).	Power cord disconnected or outlet malfunction.	Ensure power cord is securely plugged into both the chair and a working electrical outlet. Check circuit breaker.
Recline/Lift function is jerky or slow.	Obstruction in mechanism or low power.	Check for any obstructions under the chair or near moving parts. Ensure power connection is stable.
Massage/Heat function not working.	Remote control issue or internal connection.	Ensure the chair has power. Check remote control batteries (if applicable). Try restarting the chair by unplugging and re-plugging the power.
Unusual noises during operation.	Loose components or mechanism issue.	Inspect the chair for any loose screws or parts. If noise persists, discontinue use and contact customer support.

9. Specifications

Detailed specifications for the kejector Power Lift Recliner Chair:

Feature	Detail
Brand	kejector
Model	Power Lift Recliner Chair
Colour	Blue
Material	Linen (Fabric), Iron (Frame)
Refill Material	Foam, Polyester, Linen
Product Dimensions (D x W x H)	53.6D x 96W x 104.1H Centimetres
Item Weight	50.1 kg
Back Style	Solid Back
Special Features	Adjustable Backrest, Reclining, Side Pocket, Power Lift, Massage, Heating
Assembly Required	No (Minimal setup)
Batteries Required	No
Care Instructions	Dry Clean

10. Warranty and Support

For warranty information or technical support regarding your kejector Power Lift Recliner Chair, please refer to the

documentation included with your purchase or contact kejector customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D3V4Y556

More documents and user manuals: **https://manuals.plus/**