Manuals+
Q & A | Deep Search | Upload

CoasTeering Tracker

CoasTeering Nebula Cordless Robotic Pool Cleaner Caterpillar Replacement Manual

Model: Tracker

1. Introduction

This manual provides essential information for the installation and maintenance of the CoasTeering Nebula Cordless Robotic Pool Cleaner Caterpillar replacement part. The caterpillar is a crucial component of your robotic pool cleaner's drive system, ensuring efficient movement and cleaning performance across your pool's surfaces. Regular inspection and timely replacement of this part are vital for the optimal operation and longevity of your CoasTeering Nebula cleaner.



Figure 1: The CoasTeering Nebula Robotic Pool Cleaner Caterpillar replacement part.
This image displays the black rubber caterpillar track, designed with a series of interlocking teeth along its length, forming a continuous loop. This track is responsible for the robotic cleaner's propulsion and grip on pool surfaces.

2. Safety Information

Always prioritize safety when performing maintenance on your pool equipment. Adhere to the following guidelines:

- Ensure the robotic pool cleaner is completely powered off and disconnected from its charging base or power supply before attempting any installation or maintenance.
- Handle the cleaner and its components with care to avoid pinching fingers or damaging parts.
- Keep small parts away from children and pets.
- If you are unsure about any step, consult a qualified technician or contact CoasTeering customer support.

3. Product Components

The CoasTeering Nebula Cordless Robotic Pool Cleaner Caterpillar replacement package typically includes:

- One (1) CoasTeering Nebula Robotic Pool Cleaner Caterpillar (Track)

Ensure all components are present and undamaged upon receipt.

Figure 2: The CoasTeering Nebula Cordless Robotic Pool Cleaner (for reference).
This image shows the complete CoasTeering Nebula robotic pool cleaner, a compact white and black unit with a handle, designed for autonomous pool cleaning. The caterpillar tracks are visible on its underside, providing mobility.

4. Installation

Follow these steps to replace the caterpillar track on your CoasTeering Nebula Robotic Pool Cleaner. It is recommended to perform this task on a clean, flat surface.

1. **Prepare the Cleaner:** Ensure the robotic pool cleaner is turned off and disconnected from any power source. Place it upside down on a soft, clean surface to protect its top casing.
2. **Locate the Old Caterpillar:** Identify the worn or damaged caterpillar track on the underside of the cleaner. There are typically two tracks, one on each side.
3. **Remove the Old Caterpillar:** Carefully unroll the old caterpillar from around the drive wheels and idler wheels. It may require gentle stretching or prying to release it from the grooves. Note the orientation and path of the old track for reinstallation.
4. **Clean the Wheel Area:** Before installing the new track, clean any debris, hair, or dirt from the drive wheels, idler wheels, and the track channels. This ensures smooth operation and prevents premature wear of the new track.
5. **Install the New Caterpillar:** Begin by hooking one end of the new caterpillar onto a drive wheel. Carefully stretch and guide the track around all the wheels, ensuring it sits snugly in all grooves. Work your way around the entire loop until the track is fully seated.
6. **Verify Installation:** Once installed, gently rotate the wheels by hand to ensure the new caterpillar moves freely and is properly aligned. It should not be too loose or too tight.
7. **Repeat for Other Side (if applicable):** If both tracks require replacement, repeat the process for the other side of the cleaner.
8. **Test Operation:** After installation, place the cleaner back in the pool and perform a short test run to confirm proper movement and cleaning.

Note: Specific models may have slight variations in track removal/installation. Refer to your original CoasTeering Nebula cleaner's full manual for detailed diagrams if needed.

5. Maintenance

To maximize the lifespan of your replacement caterpillar and ensure continuous optimal performance of your robotic pool

cleaner, follow these maintenance tips:

- **Regular Inspection:** Periodically inspect the caterpillar tracks for signs of wear, cracks, tears, or excessive stretching. Check for any debris (leaves, hair, small stones) lodged within the track or around the wheels.
- **Cleaning:** After each cleaning cycle, or as needed, remove the cleaner from the pool and rinse the tracks with fresh water to remove chlorine, dirt, and other residues. Use a soft brush if necessary to dislodge stubborn debris.
- **Storage:** When the cleaner is not in use for extended periods, store it in a cool, dry place away from direct sunlight and harsh chemicals, which can degrade the rubber material of the tracks.

6. Troubleshooting

If you encounter issues after replacing the caterpillar, consider the following:

Problem	Possible Cause	Solution
Cleaner not moving or moving slowly.	Caterpillar not properly seated; debris caught in track/wheels; track too loose/tight.	Re-seat the caterpillar, remove debris, ensure proper tension.
Caterpillar frequently comes off.	Incorrect installation; worn drive/idler wheels; track stretched.	Re-install carefully, inspect wheels for wear, replace track if stretched.
Unusual noise from tracks.	Debris in wheels; misaligned track.	Clean wheels and track, verify alignment.

7. Specifications

The following specifications pertain to the CoasTeering Nebula Cordless Robotic Pool Cleaner Caterpillar replacement part:

- **Model Name:** Tracker
- **Product Dimensions:** 7.9 inches (L) x 1.2 inches (W) x 1.2 inches (H)
- **Item Weight:** 1.2 pounds
- **Color:** Black
- **Material:** Durable Rubber (typical for tracks)
- **Compatibility:** Specifically designed for CoasTeering Nebula Cordless Robotic Pool Cleaner

8. Warranty and Support

For information regarding the warranty of your CoasTeering Nebula Robotic Pool Cleaner Caterpillar replacement part, please refer to the original product documentation or contact CoasTeering customer support directly. While specific warranty details for replacement parts may vary, CoasTeering is committed to providing quality products and support.
If you require further assistance with installation, troubleshooting, or have questions about your product, please visit the official CoasTeering website or contact their customer service department. You can often find contact information on the product packaging or the brand's official online store.
CoasTeering Store: Visit the CoasTeering Store on Amazon

© 2025 CoasTeering. All rights reserved. This manual is for informational purposes only.