Manuals+
Q & A | Deep Search | Upload

XDOBO Try&Go Mini

XDOBO Try&Go Mini 50W Bluetooth Speaker User Manual

Model: Try&Go Mini

Introduction

Thank you for purchasing the XDOBO Try&Go Mini 50W Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your speaker. Please read it thoroughly before operation and retain it for future reference.

Image: The XDOBO Try&Go Mini 50W Bluetooth Speaker, showcasing its cylindrical design with control buttons and RGB LED light ring.

Safety Precautions

- Do not expose the speaker to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and liquids, despite its IPX7 rating, to prevent damage to internal components. Ensure port covers are sealed when near water.
- Do not attempt to disassemble, repair, or modify the speaker yourself. Contact qualified service personnel.
- Use only the provided charging cable or a certified equivalent.
- Keep out of reach of children.

Package Contents

Please check that all items are present in the package:

- XDOBO Try&Go Mini 50W Bluetooth Speaker (x1)
- USB-C Charging Cable (x1)
- 3.5mm Stereo Audio Cable (AUX Cable) (x1)
- User Manual (x1)
- Carrying Belt (x1)

Product Overview

Familiarize yourself with the speaker's components and controls. The speaker features dual passive radiators and DSP technology for clear highs, rich mids, and enhanced bass without distortion at maximum volume.

Image: Diagram highlighting key features of the XDOBO Try&Go Mini, including 50W peak power, 48mm speaker unit, 5200mAh battery, RGB dual light, and DSP sound technology.

Controls and Ports:

- **Power Button:** Press and hold to turn on/off. Short press to play/pause.

- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **EQ Button:** Short press to cycle through equalizer modes.
- **RGB Light Button:** Short press to change light modes. Long press to turn lights on/off.
- **Bluetooth/TWS Button:** Short press to enter Bluetooth pairing mode. Long press to initiate TWS pairing.
- **USB-C Port:** For charging the speaker.
- **AUX-in Port:** For wired audio connection.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker.

1. Connect the provided USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. It typically takes about 5 hours for a full charge.
4. Once fully charged, disconnect the charging cable.

2. Powering On/Off

- To power on, press and hold the Power button for 2-3 seconds until you hear an audible prompt and the LED lights activate.
- To power off, press and hold the Power button again for 2-3 seconds.

Operating Instructions

1. Bluetooth Pairing

The speaker uses Bluetooth 5.3 for stable and high-quality audio transmission.

Image: A visual representation of the advanced Bluetooth 5.3 chip, emphasizing stable and high-quality audio transmission.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (LED indicator will flash). If not, short press the Bluetooth button.
2. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
3. Select "XDOBO Try&Go Mini" from the list.
4. Once paired, the LED indicator will stop flashing, and you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if within range.

2. True Wireless Stereo (TWS) Pairing

Pair two XDOBO Try&Go Mini speakers for an immersive 360° stereo sound experience.

Image: A diagram illustrating two XDOBO Try&Go Mini speakers paired in TWS mode, creating a stereo sound field with a smartphone in the center.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), long press the Bluetooth/TWS button. You will hear a prompt indicating TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker.
4. Once successfully paired, you will hear a confirmation sound, and the LED indicators on both speakers will synchronize.
5. Now, connect your device to the primary speaker via Bluetooth as described in "1. Bluetooth Pairing". Audio will play through both speakers in stereo.

3. AUX-in Mode

Use the 3.5mm audio cable for a wired connection to devices without Bluetooth.

1. Connect one end of the 3.5mm audio cable to the speaker's AUX-in port.
2. Connect the other end to the audio output jack of your device.
3. The speaker will automatically switch to AUX-in mode.
4. Control playback and volume from your connected device.

4. RGB LED Lighting

The speaker features dynamic RGB LED lights to enhance your listening experience.

- Short press the RGB Light button to cycle through different lighting modes (e.g., solid color, pulsating, multi-color).
- Long press the RGB Light button to turn the LED lights on or off.

5. Hands-free Calling

When connected via Bluetooth to a smartphone, the speaker can be used for hands-free calls.

- **Answer Call:** Short press the Power button.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button.

Maintenance

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to about 50% every few months to prolong battery life.
- **Water Exposure:** While IPX7 waterproof, ensure the charging port and AUX port covers are securely closed before exposing to water. After water exposure, dry the speaker thoroughly before charging.

Troubleshooting

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing LED). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "XDOBO Try&Go Mini" from your device's Bluetooth list and try pairing again. Restart both the speaker and your device.
No sound or low volume.	Increase volume on both the speaker and your connected device. Ensure the speaker is properly connected (Bluetooth or AUX). Check if the speaker is muted.
TWS pairing fails.	Ensure both speakers are not connected to any other Bluetooth device. Place speakers close to each other. Repeat the TWS pairing steps carefully.
Sound distortion at high volume.	Reduce the volume on your device or the speaker. Ensure audio source quality is good.

Specifications

最大再生時間	充電時間
约20小时	约5小时
SN比	周波数帯域
⩾80dB	20Hz-20KHz
重量	サイズ
573g	80*80*180(mm)

Image: A table summarizing key specifications of the XDOBO Try&Go Mini, including maximum playback time, charging time, signal-to-noise ratio, frequency range, weight, and dimensions.

Feature	Detail
Model Name	Try&Go Mini
Brand	XDOBO
Speaker Type	Outdoor
Connectivity Technology	Bluetooth, AUX
Bluetooth Version	5.3
Audio Output Mode	Stereo
Speaker Max Output	50 Watts
Waterproof Rating	IPX7
Battery Capacity	5200mAh
Max Playback Time	Approx. 20 hours
Charging Time	Approx. 5 hours
Signal-to-Noise Ratio (SN)	≥80dB
Frequency Range	20Hz-20KHz
Product Dimensions	8D x 18W x 8H cm
Product Weight	573g
Power Source	Battery Powered (via USB-C)

Feature	Detail
Compatible Devices	Smartphones, Tablets, PCs, TVs

Warranty and Support

XDOBO products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official XDOBO website. Please retain your proof of purchase for warranty claims.

© 2026 XDOBO. All rights reserved.