Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DURACELL 1510175

DURACELL Durabeam Ultra 1500 Lumens LED Flashlight User Manual

Model: 1510175

1. Introduction

Thank you for choosing the DURACELL Durabeam Ultra 1500 Lumens LED Flashlight. This manual provides essential information for the safe and effective use of your new flashlight. Please read these instructions carefully before operation and retain them for future reference.
This flashlight features a powerful 1500-lumen output, variable focus, and three distinct lighting modes, making it suitable for various applications including home use, automotive, outdoor activities, and emergency situations.

2. Safety Information

Observe the following safety guidelines to prevent injury or damage to the flashlight:

- **Eye Safety:** Do not look directly into the LED light or shine it directly into the eyes of others. The high intensity light can cause temporary vision impairment or permanent eye damage.
- **Battery Handling:** Always insert batteries with correct polarity (+/-). Do not mix old and new batteries, or different types of batteries. Remove batteries if the flashlight will not be used for an extended period to prevent leakage. Dispose of used batteries responsibly.
- **Water Resistance:** This flashlight is IPX4 water resistant, meaning it is protected against splashing water from any direction. It is not designed for submersion in water. Do not expose to heavy rain or immerse in liquids.
- **Heat:** The flashlight head may become warm during prolonged use, especially on high mode. This is normal. Avoid touching the head directly if it feels hot.
- **Children:** Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- DURACELL Durabeam Ultra LED Flashlight (Model 1510175)
- User Manual

Note: Batteries are not included and must be purchased separately. This flashlight requires 4 D-size alkaline batteries.

4. Setup

Battery Installation

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert 4 D-size alkaline batteries into the battery compartment, ensuring correct polarity (+/-) as indicated inside the flashlight body. The positive (+) end of the battery should face towards the head of the flashlight.
3. Screw the tail cap back on clockwise until it is securely tightened.



Image: The DURACELL Durabeam Ultra LED Flashlight displayed alongside four D-size DURACELL alkaline batteries, illustrating the product and its power source.

5. Operating Instructions

Power On/Off and Mode Selection

The flashlight features a single button for power control and mode cycling, typically located on the tail cap or body.

- **To Turn On:** Press the power button once. The flashlight will activate in High mode.
- **To Cycle Modes:** With the flashlight on, press the power button repeatedly to cycle through the modes: High → Low → Strobe.

- **To Turn Off:** After cycling through all modes, the next press will turn the flashlight off. Alternatively, if the flashlight remains in one mode for several seconds, a subsequent press will turn it off directly.

Variable Focus Adjustment

The Durabeam Ultra flashlight features a slide variable focus mechanism to adjust the beam from a concentrated spot to a wide flood.

- **To Adjust Focus:** Gently slide the head of the flashlight forward or backward.
- **Spot Beam:** Slide the head forward for a narrow, intense beam that illuminates distant objects.
- **Flood Beam:** Slide the head backward for a wide, diffused beam that illuminates a larger area up close.

Refer to the product image in Section 4 for a visual representation of the variable focus mechanism.

6. Maintenance

Proper care ensures the longevity and performance of your flashlight:

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents. Keep the lens clean for optimal light output.
- **Battery Replacement:** Replace all batteries simultaneously with new, D-size alkaline batteries when the light becomes dim or stops functioning.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight. If storing for extended periods, remove the batteries to prevent corrosion.
- **Lubrication:** Periodically apply a thin layer of silicone grease to the O-rings and threads to maintain water resistance and smooth operation.

7. Troubleshooting

If you encounter issues with your flashlight, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Dead or improperly inserted batteries.	Replace batteries with new D-size alkaline batteries, ensuring correct polarity.
Light is dim or flickers.	Low battery power. Loose tail cap.	Replace batteries. Ensure tail cap is fully tightened.
Focus mechanism is stiff.	Dirt or debris in the sliding mechanism. Lack of lubrication.	Clean the sliding parts. Apply a small amount of silicone grease.
Water ingress after exposure to moisture.	Tail cap not fully tightened. Damaged O-ring. Submersion beyond IPX4 rating.	Ensure tail cap is tight. Inspect O-rings for damage and replace if necessary. Avoid submersion.

8. Technical Specifications

Detailed specifications for the DURACELL Durabeam Ultra LED Flashlight:

Feature	Specification

Feature	Specification
Model Number	1510175
Light Source	LED
Maximum Brightness	1500 Lumens (High Mode)
Low Brightness	200 Lumens (Low Mode)
Modes	High, Low, Strobe
Beam Distance (High)	150 meters
Beam Distance (Low)	60 meters
Runtime (High)	3 Hours
Runtime (Low)	35 Hours
Power Source	4 x D-size Alkaline Batteries (not included)
Water Resistance	IPX4 (Water Resistant)
Special Features	Slide Variable Focus, Anti-slip design
Material	Synthetic Material
Product Dimensions	2.5 x 2.5 x 13 inches (approx.)
Item Weight	2.51 pounds (approx.)

9. Warranty and Customer Support

DURACELL products are manufactured to high-quality standards. For information regarding warranty coverage, limitations, or to obtain customer support, please refer to the warranty card included with your purchase or visit the official DURACELL website. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact DURACELL customer service through their official channels.

© 2024 DURACELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4R4KRWB

More documents and user manuals: **https://manuals.plus/**