Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OAKHAM HOME B0D4YBL1T1

OAKHAM HOME Nightstand Instruction Manual

Model: B0D4YBL1T1 (Weathered Oak, 1 Piece)

1. Introduction

Thank you for choosing the OAKHAM HOME Nightstand. This nightstand is designed to offer both functionality and aesthetic appeal, blending seamlessly with various home decor styles. It features a drawer and an open storage shelf, providing convenient space for your essentials. This manual provides comprehensive instructions for safe assembly, proper use, and maintenance to ensure the longevity of your furniture.



Image: The OAKHAM HOME Nightstand in Weathered Oak, featuring a drawer and an open shelf, positioned next to a bed.

2. Safety Information

- Always follow assembly instructions carefully.
- Do not overtighten screws, as this may damage the material.
- Keep small parts and packaging materials away from children during assembly.
- Ensure the nightstand is placed on a flat, stable surface to prevent tipping.
- Do not exceed the maximum weight recommendations for the top (44 lbs) and drawer (11 lbs).
- Periodically check all connections to ensure they remain tight.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. All parts and screws are labeled and packed in separate bags for easy identification.

Typical Components:

- MDF Panels (Top, Sides, Bottom, Shelf, Drawer Front, Drawer Sides, Drawer Back)
- Drawer Glides
- Handle
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Assembly Guide

4. Setup and Assembly

Assembly is required for this nightstand. The process is designed to be straightforward with detailed illustrated instructions provided in the package. All parts and screws are labeled to prevent confusion.

Recommended Tools:

- Screwdriver (Phillips head recommended)

Assembly Steps Overview:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the labels and the provided assembly guide.
3. Assemble the main frame of the nightstand, securing side panels to the base and top.
4. Install the drawer glides onto the side panels.
5. Assemble the drawer box and attach the drawer front and handle.
6. Insert the assembled drawer into the nightstand frame.

For a visual guide, please refer to the official installation video below:

Your browser does not support the video tag.

Video: Official OAKHAM HOME installation guide for the Minimalist Wooden Nightstand. This video demonstrates the step-by-step assembly process.



Image: Close-up showing the aluminum handle, drawer and shelf storage, and extra thick MDF board construction.

5. Operating Instructions

The OAKHAM HOME Nightstand is designed for versatile use in various rooms, including bedrooms, living rooms, nurseries, and entryways.

Drawer Usage:

The single drawer provides concealed storage for personal items. Gently pull the handle to open and push to close. Avoid forcing the drawer, especially if it feels stiff, and ensure it is not overloaded.

Open Shelf Usage:

The open storage shelf is ideal for displaying books, decorative items, or for easy access to frequently used objects. Ensure items placed on the shelf do not protrude excessively to prevent accidental knocking.



Image: Detail of the nightstand's drawer, showcasing its construction and storage capacity.

6. Maintenance

To maintain the appearance and durability of your OAKHAM HOME Nightstand, follow these care instructions:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the MDF board.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Stability:** Periodically check and tighten all screws and fasteners to ensure the nightstand remains stable.

7. Troubleshooting

If you encounter any issues with your nightstand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Nightstand is wobbly	Loose fasteners; Uneven floor	Tighten all screws. Move to a level surface or use furniture pads to stabilize.
Drawer does not slide smoothly	Drawer glides misaligned; Obstruction in the track; Overloaded drawer	Check alignment of drawer glides and re-adjust if necessary. Remove any obstructions. Reduce weight in the drawer.
Parts missing or damaged during assembly	Packaging error; Shipping damage	Contact OAKHAM HOME customer support for replacement parts.

OAKHAM HOME aims to provide durable and easy-to-assemble storage solutions, addressing common issues like flimsy build and complex assembly. If problems persist, please contact customer support.

8. Specifications

Feature	Detail
Brand	OAKHAM HOME
Model Name	Nightstand Weathered Oak 1pcs
Product Dimensions (D x W x H)	13.7" x 16.9" x 21.6"
Item Weight	18.7 Pounds
Maximum Weight Recommendation (Top)	44 Pounds
Maximum Weight Recommendation (Drawer)	11 Pounds
Frame Material	Exterior Grade MDF Board
Color	Weathered Oak
Number of Drawers	1
Assembly Required	Yes
Recommended People for Assembly	1



Image: Diagram showing the dimensions (13.7"D x 16.9"W x 21.6"H) and maximum load capacities (Top: 44 lbs, Drawer: 11 lbs) of the nightstand.

9. Warranty Information

Specific warranty details for this product are not provided in the available information. For warranty inquiries, please contact OAKHAM HOME customer support directly.

10. Customer Support

For any questions, concerns, or assistance with your OAKHAM HOME Nightstand, please contact our customer support team. You can typically find contact information on the OAKHAM HOME official website or through the retailer where you purchased the product.

Visit the OAKHAM HOME Store: OAKHAM HOME Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4YBL1T1

More documents and user manuals: **https://manuals.plus/**