Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Biolomix TB23M

BioloMix Blender and Food Processor Combo User Manual

Brand: **Biolomix**

Model: **TB23M**

Introduction

The BioloMix Blender and Food Processor Combo is a versatile 3-in-1 kitchen appliance designed for chopping, blending, and grinding. With its powerful 700W motor, it can quickly process a variety of ingredients to help you prepare nutritious meals and beverages. This multi-functional unit is ideal for making smoothies, shakes, gourmet cereals, coffee, baby food, and for chopping vegetables, nuts, fruits, peppers, and meat.

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your BioloMix appliance.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or other liquids. Clean only with a damp cloth.
- Always unplug the appliance from the power outlet before cleaning or when not in use.
- Exercise extreme caution when handling sharp blades. Always handle blades by the plastic hub.
- Keep hands and utensils out of the container while blending to reduce the risk of severe personal injury and/or damage to the blender.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use outdoors.
- Ensure the appliance is properly assembled before operation.

Components Overview

Your BioloMix Blender and Food Processor Combo includes the following main components:

- **700W Motor Base:** The main power unit for all functions.

- **570ml (19oz) Portable Blender Bottle:** Ideal for single-serve smoothies and juices, with a convenient lid for on-the-go use.
- **1200ml (45oz) Food Chopper Bowl:** Equipped with a stainless steel blade for chopping and mincing.
- **100ml (5oz) Grinder Cup:** Designed for grinding coffee beans, spices, and grains.
- **Blade Assemblies:** Specific blades for blending, chopping, and grinding.



Figure 1: Overview of the BioloMix Blender and Food Processor Combo with all included components.

Setup and Assembly

The BioloMix system features a modular design for easy assembly and disassembly. Ensure the motor base is unplugged before assembling or disassembling any parts.

Assembling the Portable Blender

1. Place your desired ingredients (fruits, liquids) into the 570ml portable blender bottle. Do not overfill.
2. Attach the blending blade assembly securely onto the open end of the portable blender bottle by twisting it clockwise until tight.
3. Invert the assembled bottle and blade, then place it onto the motor base. Align the tabs on the bottle with the slots on the base and press down firmly.

4. Plug in the motor base. Press and hold the power button to begin blending. Release to stop.



Figure 2: Step-by-step assembly and operation for the portable blender bottle.

Assembling the Food Chopper

1. Carefully place the chopping blade onto the central pin inside the 1200ml food chopper bowl.
2. Add your ingredients (e.g., meat, vegetables) into the chopper bowl.
3. Place the lid onto the chopper bowl, ensuring it is securely locked in place.
4. Place the motor base onto the lid of the chopper bowl, aligning the motor unit with the drive shaft.
5. Plug in the motor base. Press and hold the power button to operate.



Figure 3: Step-by-step assembly and operation for the food chopper.

Assembling the Grinder Cup

1. Add ingredients (e.g., coffee beans, spices) into the 100ml grinder cup.
2. Attach the grinding blade assembly securely onto the open end of the grinder cup by twisting it clockwise until tight.
3. Invert the assembled cup and blade, then place it onto the motor base. Align the tabs on the cup with the slots on the base and press down firmly.
4. Plug in the motor base. Press and hold the power button to begin grinding.



Figure 4: Components for the dry mill function, suitable for grinding coffee beans and spices.

Operating Instructions

The BioloMix appliance features a powerful 700W motor operating at up to 24,000 RPM, ensuring efficient processing for various tasks.

General Operation

- Ensure the unit is properly assembled for the desired function (blending, chopping, or grinding).
- Plug the appliance into a standard electrical outlet.
- Press and hold the power button on the motor base to activate. Release the button to stop operation.
- Do not operate continuously for more than 1 minute to prevent overheating. Allow the motor to cool down between uses.


700W Powerful Motor


Safety Lock

Figure 5: The appliance features a powerful 700W motor and a safety lock for secure operation.

Blending Function (Smoothies, Juices)

Use the 570ml portable blender bottle for preparing beverages like smoothies and fresh juices. The 4-leaf stainless steel blade ensures smooth results.

▶ **Watch video online**
Blender for orange pineapple juice and avocado milkshake

Video 1: Demonstration of making orange pineapple juice and avocado milkshake using the blender function.



Figure 6: The 4-leaf stainless steel blade ensures efficient blending for smooth results.

Food Processor Function (Chopping, Mincing)

The 1200ml food chopper is ideal for quickly chopping vegetables, nuts, and mincing meat. Ensure ingredients are cut into small pieces before processing.

▶ **Watch video online**
Making mincemeat in a blender

Video 2: Demonstration of mincing meat using the food processor attachment.



Figure 7: The 3-in-1 system supports various uses including ice crushing, frozen fruits, smoothies, baby food, powder grinding, minced meat, and salad dressing.

Grinding Function (Coffee, Spices)

The 100ml grinder cup is perfect for grinding dry ingredients such as coffee beans, spices, and grains to your desired consistency.

▶ **Watch video online**
Blender for dry mill

Video 3: Demonstration of dry grinding various ingredients like soybeans, coffee beans, and dried chili peppers.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your BioloMix appliance.

- Always unplug the motor base before cleaning.
- The motor base should only be wiped clean with a damp cloth. Do not immerse it in water.
- All detachable accessories, including the portable blender bottle, food chopper bowl, grinder cup, and blade assemblies, are dishwasher safe.
- For manual cleaning, simply rinse the bowls, jugs, cups, and blades with water immediately after use. Use mild dish soap if necessary.
- **Caution:** Blades are sharp. Handle with extreme care during cleaning.



Figure 8: Most components are dishwasher safe for easy cleaning.

Troubleshooting

If you encounter any issues with your BioloMix appliance, please refer to the following common troubleshooting tips:

- **Appliance does not turn on:** Ensure the unit is properly plugged into a working outlet. Check that all components (bottle/bowl/cup and blade assembly) are securely attached to the motor base and locked into place. The safety lock feature prevents operation if not correctly assembled.
- **Ingredients are not blending/chopping/grinding effectively:**
  - Ensure ingredients are cut into appropriate sizes.
  - Do not overfill the container. Reduce the amount of ingredients if necessary.
  - Add more liquid when blending smoothies if the mixture is too thick.
  - For grinding, ensure ingredients are dry.
- **Motor smells or overheats:** This can occur with prolonged continuous use. Do not operate the appliance for more than 1 minute continuously. Allow the motor to cool down for at least 10-15 minutes before resuming use.

If the problem persists after trying these steps, please contact customer support for assistance.

Specifications

Brand	Biolomix
Model Number	TB23M
Power	700W
Max RPM	24,000 RPM
Voltage	110 Volts
Portable Blender Bottle Capacity	570ml (19oz)
Food Chopper Bowl Capacity	1200ml (45oz)
Grinder Cup Capacity	100ml (5oz)
Material	BPA Free Plastic, 304 Stainless Steel Blades

Product Dimensions	4.5"D x 9.5"W x 14"H
Item Weight	5.63 pounds



Figure 9: Detailed dimensions of the BioloMix Blender and Food Processor components.

Warranty and Support

Your BioloMix Blender and Food Processor Combo comes with a Limited Warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact BioloMix customer support.

For technical assistance, troubleshooting, or any inquiries regarding your product, please visit the official BioloMix website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official online store.

© 2024 Biolomix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4YNKZ9S

More documents and user manuals: **https://manuals.plus/**