Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy 3718-2

Sweetcrispy Home Office Drafting Chair User Manual

Brand: Sweetcrispy | **Model:** 3718-2

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sweetcrispy Home Office Drafting Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.





Image: Front view of the Sweetcrispy Home Office Drafting Chair in grey, highlighting its design with fixed armrests and an adjustable footrest.

Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Assembly may require tools and careful handling. Ensure the chair is fully assembled and stable before use.
- Do not exceed the maximum weight recommendation of 113.4 kilograms (250 lbs).
- Be cautious when adjusting the height and footrest to prevent injury.
- Keep children and pets away during assembly.
- Use the chair only for its intended purpose as a drafting or office chair.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Seat Cushion (1)
- Backrest (1)
- Armrests (2)

- Gas Lift Cylinder (1)
- Footrest Ring (1)
- Five-Star Base (1)
- Caster Wheels (5)
- Hardware Pack (Screws, Washers, Allen Wrench)
- Instruction Manual (1)

Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

1. **Attach Casters to Base:** Insert the five caster wheels into the holes at the end of each leg of the five-star base. Push firmly until they click into place.

Image: Illustration showing how to insert the caster wheels into the five-star base.

2. **Install Gas Lift and Footrest:** Place the gas lift cylinder into the center hole of the assembled five-star base. Slide the footrest ring over the gas lift cylinder and secure it at your desired height using the adjustment knob.



Image: Diagram illustrating the placement of the gas lift and footrest ring onto the chair base.

3. **Attach Seat Plate to Seat Cushion:** Secure the metal seat plate to the underside of the seat cushion using the provided screws. Ensure the front of the seat plate aligns with the front of the cushion.



Image: Visual guide for attaching the seat plate to the underside of the seat cushion.

4. **Connect Backrest to Seat:** Attach the backrest to the seat cushion using the designated screws. Ensure a secure fit.



Image: Illustration demonstrating how to secure the backrest to the seat assembly.

5. **Attach Armrests:** Secure the armrests to the sides of the seat and backrest using the provided screws.



Image: Diagram showing the attachment points for the fixed armrests.

6. **Place Assembled Top onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and fully seated.



Image: Final assembly step, showing the upper chair section being placed onto the gas lift and base.

7. **Final Check:** Ensure all screws are tightened and the chair is stable before use.

Operating Instructions

Your Sweetcrispy Drafting Chair is designed with several adjustable features to enhance comfort and support.

1. Height Adjustment

To adjust the seat height, locate the lever under the right side of the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up and pull the lever up. Release the lever at the desired height to lock it in place.



Image: Close-up of the height adjustment lever located beneath the seat.



Image: Two drafting chairs demonstrating the adjustable height feature, suitable for various desk heights.

2. Footrest Adjustment

The footrest ring can be adjusted vertically to provide optimal leg support. Loosen the knob on the side of the footrest ring, slide the ring to your preferred height, and then tighten the knob securely to lock it.



Image: Detailed view of the chair's components, including the adjustable footrest ring with its locking mechanism.

3. Lumbar Support

The chair features an ergonomically designed backrest with integrated lumbar support to promote a healthy posture and reduce strain during extended sitting periods. The mesh back is breathable for comfort.



Image: Visual representation of the chair's ergonomic backrest and lumbar support, designed to conform to the spine's natural curve.

4. Fixed Armrests

This model is equipped with fixed armrests, providing stable support for your arms and shoulders.

5. Swivel Function

The chair features a 360-degree swivel function, allowing for easy movement and access to different areas of your workspace without needing to reposition the entire chair.

Maintenance

Regular maintenance will prolong the life and appearance of your chair.

- **Cleaning:** For the mesh back and fabric seat, use a soft cloth dampened with mild soap and water. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically check the caster wheels for hair or debris that may hinder smooth movement. Clean as needed.

- **Hardware:** Every few months, check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Gas Lift:** Do not attempt to disassemble the gas lift cylinder. If it malfunctions, contact customer support.

Troubleshooting

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or feels unstable	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat surface.
Height adjustment not working	Gas lift cylinder malfunction or lever mechanism issue.	Ensure the lever is fully engaged. If the issue persists, contact customer support for gas lift replacement.
Caster wheels not rolling smoothly	Debris (hair, dust) caught in wheels or damaged casters.	Remove any debris from the wheels. If damaged, replacement casters may be needed.
Squeaking noises	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary (avoiding the gas lift).

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Sweetcrispy Home Office Drafting Chair
Item Model Number	3718-2
Color	Grey
Product Dimensions	24.22"D x 23.63"W x 45"H
Seat Height Adjustment	23.43" to 29.33"
Maximum Weight Recommendation	113.4 Kilograms (250 lbs)
Back Style	Mesh Back with Lumbar Support
Arm Style	Fixed Arm
Furniture Base Movement	Swivel, Rolling Casters
Fill Material	High-density Foam
Assembly Required	Yes
Item Weight	25.9 pounds



Image: Diagram illustrating the key dimensions and maximum weight capacity of the chair.



Image: Detailed view of the seat cushion, emphasizing its construction with high-density, high-resilience foam and a waterfall edge for comfort.

Warranty and Support

For warranty information, product support, or to order replacement parts, please refer to the official Sweetcrispy website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
You can also find additional information and a downloadable PDF user manual at the following linkSweetcrispy Drafting Chair User Manual (PDF)

© 2024 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4YX3N6S

More documents and user manuals: **https://manuals.plus/**