Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KAFF NYG 783B

KAFF NYG 783B Built-in Hob Instruction Manual

Model: NYG 783B

Introduction

This manual provides essential information for the safe and efficient use of your KAFF NYG 783B Built-in Hob. Please read these instructions carefully before installation and operation, and keep them for future reference. This appliance is designed for domestic use only.

Important Safety Information

- Ensure proper ventilation in the kitchen area when the hob is in use.
- Do not store flammable materials near the appliance.
- Always supervise cooking to prevent boil-overs and fires.
- Keep children away from the appliance during operation.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact a qualified technician.
- Installation and servicing must be performed by a qualified technician in accordance with local regulations.

What's in the Box

Upon unpacking, please verify that all components are present and undamaged:

- 1x KAFF NYG 783B Built-in Hob
- 1x Instruction Manual (this document)
- 1x Warranty Card

Setup and Installation

Installation of the KAFF NYG 783B Built-in Hob requires professional expertise. It is strongly recommended that a qualified technician performs the installation to ensure safety and proper functioning. Refer to the provided dimensions for countertop cutout requirements.

Pre-Installation Checks

- Ensure the gas supply type (LPG/Natural Gas) matches the appliance's specifications.
- Verify that the electrical supply (for auto-ignition) meets the required voltage and frequency.
- Confirm adequate ventilation in the installation area.

Component Assembly

After the hob is securely placed in the countertop cutout and gas/electrical connections are made, assemble the burner components:

1. Place the burner caps correctly onto the burner bases.
2. Position the heavy-duty cast iron pan supports over the burners, ensuring they are stable and level.
3. Install the metal control knobs onto their respective shafts.



Image: Top-down view of the KAFF NYG 783B Built-in Hob, showing the layout of the three burners and the three control knobs at the front.

Operating Instructions

Your KAFF NYG 783B Built-in Hob is equipped with high-efficiency brass burners, an auto electric ignition system, and a flame failure device for safe and convenient cooking.

Igniting a Burner

1. Ensure a cooking vessel is placed on the pan support over the desired burner.
2. Push down the corresponding control knob and turn it counter-clockwise to the "High Flame" position.
3. The auto electric ignition will spark, igniting the gas. Hold the knob down for a few seconds after ignition to allow the flame failure device to engage.
4. Once the flame is stable, release the knob. You can then adjust the flame intensity by turning the knob between "High Flame" and "Low Flame" settings.
5. To turn off the burner, turn the knob clockwise to the "Off" position.

Flame Failure Device (FFD): This safety feature automatically cuts off the gas supply to a burner if the flame accidentally extinguishes (e.g., due to a draft or liquid spill). If a burner does not stay lit after releasing the knob, ensure you held the knob down long enough for the FFD to activate.



Image: Close-up of the three metal control knobs, showing their ergonomic design and flame indicators.




Image: Detailed view of one of the full brass burners, highlighting the burner cap and the robust cast iron pan support.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your KAFF NYG 783B Built-in Hob.

General Cleaning

- Always ensure the hob is cool and the gas supply is turned off before cleaning.
- Wipe the 8mm premium matte black tempered glass surface with a soft cloth and mild detergent. Avoid abrasive cleaners or scouring pads that can scratch the glass.
- For stubborn stains, use a non-abrasive glass cleaner specifically designed for hob surfaces.

Burners and Pan Supports

- Remove the cast iron pan supports and brass burner caps/bases. These can be washed with warm soapy water.
- Ensure all burner parts are completely dry before reassembling them. Moisture can affect ignition.
- Periodically check the burner holes for blockages and clean them gently with a fine wire or brush if necessary.

Troubleshooting

Before contacting customer support, please refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, power outage (for ignition), clogged burner holes, wet burner parts.	Check gas supply. Verify power to the hob. Clean burner holes. Ensure burner parts are dry and correctly assembled.
Flame is uneven or yellow.	Clogged burner holes, incorrect burner cap placement.	Clean burner holes. Re-position burner cap correctly.
Burner ignites but extinguishes when knob is released.	Flame Failure Device (FFD) not engaged, FFD sensor dirty.	Hold the knob down for a few more seconds after ignition. Clean the FFD sensor (small metal rod near the burner).
Gas smell detected.	Gas leak.	**Immediately turn off gas supply, open windows, do not operate electrical switches. Contact a qualified technician or emergency services.**

Specifications

Detailed technical specifications for the KAFF NYG 783B Built-in Hob:

Brand: KAFF

Model Number: NYG 783B

Heating Elements: 3

Burner Type: Full Brass Burners (2 Mini Triple Ring, 1 Dual Ring)

Fuel Type: Gas

Ignition System: Auto Electric Ignition (Gas Pilot)

Control Type: Metal Knob

Installation Type: Built-In

Heater Surface Material: 8mm Premium Matte Black Tempered Glass

Pan Support: Heavy Duty Cast Iron with Integrated Flame Protector

Special Features: Flame Failure Device (FFD)

Item Dimensions (D x W x H): 45D x 78W x 13H Centimeters

Color: Matte Black

Warranty Information

Your KAFF NYG 783B Built-in Hob comes with a manufacturer's warranty to cover potential defects.

- **Warranty Period:** 2 Years from the date of purchase.
- **Coverage:** This warranty covers manufacturing defects in Burners, Glass, Ignition Wire, Switch, Bypass, and Generator components.
- Please retain your purchase receipt and warranty card for any warranty claims.
- The warranty does not cover damage caused by improper installation, misuse, accident, unauthorized repairs, or normal wear and tear.

Customer Support

For any queries, technical assistance, or warranty claims, please contact KAFF Customer Care:

Manufacturer: Kaff Appliances (I) Pvt.Ltd

Address: S.S. Plaza, 4th Floor, Sector -47, Gurgaon -122018 Haryana, India

Toll-Free Customer Care: 18001802221

Email: customercare@kaff.in

© 2023 KAFF Appliances (I) Pvt.Ltd. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D4ZJYQLW

More documents and user manuals: **https://manuals.plus/**