Manuals+

Q & A | Deep Search | Upload

PayLessHere Office Computer Gaming Chair

PayLessHere Office Computer Gaming Chair Instruction Manual

Product Overview

This manual provides detailed instructions for the assembly, operation, and maintenance of your PayLessHere Office Computer Gaming Chair. Designed for ergonomic comfort and versatility, this chair features a breathable mesh back, adjustable height, 360-degree swivel, and lumbar support, making it suitable for both office work and gaming.

Image: The PayLessHere Office Computer Gaming Chair in pink, set up in a home office environment.

Safety Information

Do not exceed the maximum weight capacity of 250 pounds. Ensure the chair is properly assembled and stable before use.

Always follow assembly instructions carefully. Keep small parts away from children. Regularly inspect the chair for loose screws or damaged components and tighten or replace as necessary.

Package Contents

Before beginning assembly, please verify that all components are present:

- Chair Backrest (1)
- Seat Cushion (1)
- Armrests (2)
- Gas Lift Cylinder (1)
- Star Base (1)

- Caster Wheels (5)
- Mechanism Plate (1)
- Screws and Allen Wrench (1 set)

Assembly Instructions

Follow these steps to assemble your PayLessHere Office Computer Gaming Chair:

Step 1: Attach Casters to Base

Insert the five caster wheels into the holes at the end of each leg of the star base. Push firmly until they click into place.

Image: Close-up of the chair's star base and caster wheels, highlighting 360-degree rotation and floor protection.

Step 2: Insert Gas Lift Cylinder

Place the gas lift cylinder into the center hole of the assembled star base. Do not remove the red cap from the gas lift until instructed.

Image: Detailed view of the chair's components, including the certified gas rod (lift cylinder).

Step 3: Attach Mechanism Plate to Seat

Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws using the provided Allen wrench.

Step 4: Attach Armrests

Attach the armrests to the sides of the seat cushion using the designated screws. Pay attention to the 'L' (left) and 'R' (right) markings on the armrests.

Step 5: Connect Backrest to Seat

Align the backrest with the attachment points on the seat cushion or mechanism plate. Secure with screws.

Step 6: Assemble Seat to Base

Carefully place the assembled seat (with mechanism and armrests) onto the gas lift cylinder. The tapered end of the gas lift should fit securely into the mechanism plate.

Assembly Video

Video: A demonstration of the adjustable features of the office chair, including height and swivel, for home comfort.

Operating Instructions

Familiarize yourself with the chair's adjustable features for optimal comfort:

Height Adjustment

To adjust the seat height, pull the lever located under the right side of the seat upwards. While seated, lift your weight slightly to raise the chair, or remain seated to lower it. Release the lever to lock the height.

Image: Diagram illustrating the height adjustment lever and 360-degree swivel function of the chair.

Tilt and Recline Function

The chair features a reclining backrest. To activate the tilt, pull the lever (often the same as the height adjustment lever, or a separate one) outwards. To lock the backrest in an upright position, push the lever inwards. The tension of the tilt can be adjusted by rotating the round knob located under the front of the seat.

Image: Illustration of the chair's wobbling mode, showing the reclining backrest and the tilt tension adjustment knob.

Swivel Function

The chair is designed to swivel 360 degrees, allowing for easy movement and access to different areas of your workspace without needing to reposition the entire chair.

Maintenance

Proper maintenance will extend the life of your chair:

- **Cleaning:** For mesh and fabric surfaces, use a soft cloth with mild soap and water. Avoid harsh chemicals. For the plastic and metal parts, wipe with a damp cloth.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Casters:** Keep caster wheels clean from hair and debris to ensure smooth rolling.

Troubleshooting

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift lever not engaged or gas lift faulty.	Ensure the lever is fully pulled up/down. If issue persists, contact customer support for gas lift replacement.
Chair wobbles	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, even surface.
Casters do not roll smoothly	Debris in casters or damaged wheels.	Remove any hair or debris from the caster wheels. If damaged, replace casters.
Backrest does not recline or lock	Tilt mechanism locked or tension too high.	Pull the tilt lever outwards to unlock. Adjust the tilt tension knob to a lower setting.

Specifications

Feature	Detail
Brand	PayLessHere
Model Name	Office Computer Gaming Chair
Color	Pink
Product Dimensions (D x W x H)	23"D x 22"W x 40"H
Seat Depth	17 inches
Item Weight	21 pounds
Material	Mesh (Back), Foam (Seat)
Back Style	Mesh Back
Special Features	Cushion Availability, Ergonomic, Rolling, Adjustable Height, Swivel
Furniture Base Movement	Swivel
Reclining Position Count	2 to 5
Maximum Weight Capacity	250 pounds (as per safety information)

Image: Detailed product parameter diagram showing chair dimensions in inches.

Warranty and Support

For warranty information, technical support, or to order replacement parts, please contact PayLessHere customer service through the retailer where the product was purchased. Keep your purchase receipt for warranty claims.