Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CASEKOO MagicStand Pro

Instruction Manual

CASEKOO MagicStand Pro Case for iPhone 16 Pro

Model: MagicStand Pro | Brand: CASEKOO

Introduction

The CASEKOO MagicStand Pro Case is designed to provide comprehensive protection and enhanced functionality for your iPhone 16 Pro. This innovative case integrates a patented 3600 spin stand, magnetic compatibility, and military-grade drop protection, offering a versatile and secure solution for daily use. Its sleek, translucent design allows the original beauty of your device to shine through while ensuring robust defense against impacts and scratches.



Figure 1: CASEKOO MagicStand Pro Case with integrated magnetic stand.

Setup

To install the CASEKOO MagicStand Pro Case on your iPhone 16 Pro, follow these simple steps:

1. Ensure your iPhone 16 Pro is clean and free of dust or debris.
2. Align the camera cutout of the case with your iPhone's camera module.

3. Gently push your iPhone into the case, starting from the top edge, ensuring all corners snap securely into place.
4. Verify that all buttons (volume, power) and ports (charging, speakers) are properly aligned with the case's cutouts.



Figure 2: Proper installation of the case on your device.

Operating Instructions

The MagicStand Pro Case offers several features to enhance your iPhone 16 Pro experience:

3600 Spin Invisible Stand

The patented stand is integrated seamlessly into the case. To use:

- Gently pull out the ring from the back of the case.
- Rotate the ring 3600 to achieve your desired viewing angle for both vertical (portrait) and horizontal (landscape) orientations. The ring can be adjusted within 0-1700 vertically.
- The stand is designed for durability, tested for over 30,000 opening and closing cycles.
- When not in use, simply push the ring back into its recessed position until it sits flush with the case.



Figure 3: Versatile positioning with the 3600 rotating stand.

Magnetic Compatibility (MagSafe)

The MagicStand Case features MagPrime array technology, providing 2 times stronger magnetism than official MagSafe accessories. This ensures secure attachment and efficient wireless charging.

- The case is fully compatible with all MagSafe accessories, including chargers, wallets, and car mounts.
- It also supports third-party Qi-certified wireless chargers, minimizing power loss during charging for faster and safer power delivery.

Your browser does not support the video tag.

Video 1: Demonstrating the strong magnetic force of the CASEKOO MagicStand Pro case with various MagSafe accessories and wireless charging.

Maintenance

To ensure the longevity and optimal performance of your CASEKOO MagicStand Pro Case, follow these maintenance

guidelines:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth to remove dust, dirt, and fingerprints. Avoid using harsh chemicals or abrasive materials, as they may damage the case's matte finish and anti-slip properties.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the case for any signs of wear or damage, especially around the stand mechanism and edges. While the stand is highly durable, excessive force or improper use can affect its functionality.




Figure 5: The case's matte finish resists stains and fingerprints.

Troubleshooting

If you encounter any issues with your CASEKOO MagicStand Pro Case, refer to the following common solutions:

- **Stand not retracting/extending smoothly:** Ensure there is no debris or foreign objects lodged in the stand mechanism. Gently clean the area. Avoid forcing the stand, as this may cause damage.
- **MagSafe accessories not attaching securely:** Verify that the MagSafe accessory is clean and properly aligned with the magnetic ring on the case. Ensure no foreign objects are between the case and the accessory.
- **Wireless charging issues:** Confirm that your wireless charger is Qi-certified and properly connected to its power source. Ensure the phone is centered on the charging pad. Remove any other metallic objects from the back of the phone or charger.
- **Case fit issues:** If the case does not fit snugly, ensure you have the correct model (iPhone 16 Pro). Re-install the case, making sure all edges are properly seated.

For persistent issues or concerns not addressed here, please contact CASEKOO customer support.

Specifications

Product Dimensions	5.98 x 2.97 x 0.58 inches
Item Weight	3.17 ounces

Material	Silicone, Metal, Rubber, Polycarbonate
Compatible Phone Model	iPhone 16 Pro
Special Features	Wireless, Slim Fit, Heavy Duty Protection, Kickstand, Anti-Slip
Included in Box	CASEKOO for iPhone 16 Pro Case with Magnetic Stand 1, PandaKOO Stickers 2
Drop Protection	16FT Military-Grade Drop Protection (0% damage in 5,000+ drop tests)
Magnetic Strength	2 TIMES STRONGER than Official MagSafe (MagPrime array technology)

Your browser does not support the video tag.

Video 2: Demonstration of the 16FT military-grade drop protection.

Warranty and Support

CASEKOO is committed to providing innovative and quality assurance mobile phone accessories. If you encounter any problems after receiving your product, please feel free to contact the after-sales center at any time. CASEKOO values every user's voice and strives to offer comprehensive support.

- **Manufacturer Service:** Includes product consultation, technical support, and repair.
- **180-Day No Hassle Replacement:** 100% quality and perfect product guarantee.
- **1-to-1 7*24 Standard Professional Service:** Personalized consultation and service.
- **Fast Delivery:** Ensures timely delivery of products.

For direct support, please visit the official CASEKOO website or refer to the contact information provided in your product packaging.

© 2024 CASEKOO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D5YQX199

More documents and user manuals: **https://manuals.plus/**