Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FEELIN 2201

FEELIN TV Console Entertainment Center User Manual

Model: 2201
Brand: FEELIN

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your FEELIN TV Console Entertainment Center, Model 2201. Please read this manual carefully before using the product to ensure proper setup and long-term enjoyment. Keep this manual for future reference.



Image 1.1: Front view of the FEELIN TV Console Entertainment Center.

2. Product Features

The FEELIN TV Console Entertainment Center is designed to enhance your living space with both style and functionality. Key features include:

- **Ample Storage:** Provides significant storage capacity for entertainment equipment, accessories, and decorative items, helping to maintain an organized environment.
- **Display Surfaces:** Features large top surfaces suitable for displaying collectibles, vases, and other decorative elements.
- **Four Drawers:** Includes four spacious drawers for organized, partitioned storage of various household items, contributing to a clutter-free home.
- **Modern Aesthetic:** Combines simple lines with a modern, cream-style design, offering a visually appealing addition to any living room.
- **Durable Construction:** Constructed from skin-friendly boards and fresh logs, ensuring durability and a pleasant tactile experience.

3. Specifications

Refer to the following specifications for your TV Console Entertainment Center:

Attribute	Detail
Product Name	TV Console Entertainment Center
Brand	FEELIN
Model Number	2201
Material	Bancai (Engineered Wood)
Overall Dimensions (L x W x H)	180cm x 31.5cm x 38cm (70.86in x 12.40in x 14.96in)
Item Weight	1.76 ounces *(Note: This weight seems unusually low for a TV cabinet. Please verify actual product weight upon delivery.)*
Assembly Required	No
Number of Pieces	1



Image 3.1: Detailed dimensions of the TV Console Entertainment Center.

4. Setup

Your FEELIN TV Console Entertainment Center is designed for minimal setup, as it arrives fully assembled. Follow these steps for initial placement:

1. **Unpack:** Carefully remove the TV console from its packaging. Inspect for any shipping damage.
2. **Choose Location:** Select a flat, stable surface in your desired living area. Ensure there is adequate space around the unit for ventilation and access.
3. **Position:** Gently place the TV console in its intended location. Ensure it is level and stable before placing any items on it.
4. **Arrange:** Organize your entertainment devices, cables, and decorative items on and within the console.



Image 4.1: Example placement of the TV Console Entertainment Center in a living room.

5. Operation

The TV Console Entertainment Center is designed for straightforward use. Its primary functions involve storage and display.

- **Using Drawers:** The four integrated drawers provide concealed storage. Gently pull the drawer fronts to open and push to close. Avoid forcing drawers if they feel stiff; ensure they are properly aligned.
- **Display Surfaces:** The top surface and the extended shelf are suitable for placing televisions, soundbars, decorative items, books, or other media accessories. Distribute weight evenly across surfaces.
- **Cable Management:** While not explicitly designed with cable cutouts, cables can be routed behind the unit to maintain a tidy appearance.



Image 5.1: Detail of a drawer and leg, illustrating access.



Image 5.2: The extended shelf provides additional display and storage space.

6. Maintenance

Proper care will ensure the longevity and appearance of your TV Console Entertainment Center.

- **Cleaning:** Wipe surfaces regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.
- **Heat and Moisture:** Keep the unit away from direct heat sources and areas of high humidity. Use coasters under hot or wet items.
- **Weight Distribution:** Do not overload drawers or shelves. Distribute weight evenly to maintain stability and prevent structural stress.

7. Troubleshooting

If you encounter any issues with your TV Console Entertainment Center, refer to the following common solutions:

- **Stability Issues:**
  - Ensure the unit is placed on a flat, level surface.
  - Check if all legs are firmly on the ground. If necessary, gently adjust the unit's position.
- **Drawers Sticking:**
  - Verify that the drawers are not overloaded.
  - Check for any obstructions within the drawer slides.
- **Surface Marks/Scratches:**
  - For minor marks, try a soft cloth with a small amount of furniture polish suitable for engineered wood.
  - Avoid dragging heavy or sharp objects across the surface.

If problems persist, please contact customer support.

8. Warranty and Support

For information regarding warranty coverage, returns, or technical support, please refer to the purchase documentation or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.
For direct inquiries, you may also attempt to contact the manufacturer, FEELIN, through their official channels if available.

© 2023 FEELIN. All rights reserved. This manual is subject to change without notice.
For the latest information, please visit the official product page or contact customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6W399N7

More documents and user manuals: **https://manuals.plus/**