Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RELAX4LIFE RXE-10738

RELAX4LIFE Electric Fireplace TV Stand User Manual

Model: RXE-10738

1. Introduction

Thank you for purchasing the RELAX4LIFE Electric Fireplace TV Stand. This manual provides important information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before use and retain this manual for future reference.

The RELAX4LIFE Electric Fireplace TV Stand, designed to combine functionality with modern aesthetics in your living space.

2. Safety Information

Your safety is paramount. Please observe the following safety guidelines:

- **Overheat Protection:** The electric fireplace heater is equipped with an automatic overheat protection system. If the heater becomes too hot, it will automatically shut off to prevent damage or hazards.
- **CSA Certification:** The electric heater component is CSA certified, ensuring it meets recognized safety standards.
- **Anti-Toppling Device:** An anti-toppling device is included to secure the TV stand to the wall, preventing accidental tipping. Always install this device as instructed.
- **Electrical Safety:** Ensure the power outlet used is properly grounded and rated for the appliance's power consumption (1400 watts). Do not overload circuits.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the heater.
- Do not block air vents of the fireplace heater.

3. Setup and Assembly

Assembly of the TV stand is required. Follow the detailed instructions provided in the separate assembly guide. Key points for setup include:

- **Component Identification:** Before starting, identify all parts and hardware.

- **Secure Placement:** Place the TV stand on a flat, stable surface.
- **Anti-Toppling Device Installation:** Install the anti-toppling device to a wall stud using appropriate hardware to prevent the unit from tipping over.
- **Cable Management:** Utilize the integrated cable management holes to organize and conceal media wiring neatly.

Illustration of the anti-toppling device for stability and the cable management hole for organized wiring.

4. Operating Instructions

4.1 Electric Fireplace Heater

The 18-inch electric fireplace heater provides efficient warmth and ambiance.

- **Heating Capacity:** Warms rooms up to 400 square feet with a heat output of 4777 BTU.
- **Adjustable Thermostat:** Set desired temperature between 62℉ and 82℉ (16.7℃ to 27.8℃).
- **Timer Function:** Program the heater to operate for 0.5 to 6 hours.

4.2 LED Lights and Flame Effects

Enhance your room's atmosphere with customizable lighting.

- **16 Color LED Lights:** Choose from 16 different LED light options for the side compartments.
- **LED Light Modes:** Available in 4 modes: Flash, Strobe, Fade, and Smooth.
- **3-Level Flame Brightness:** Adjust the intensity of the fireplace flame effect to your preference.

Visual representation of the fireplace heater's features including heating area, BTU, thermostat, and timer.

Demonstration of the 16 color LED lights and the remote and smart app control options.

4.3 Control Systems

The fireplace and LED lights can be controlled via multiple methods:

- **Remote Control:** A remote control is provided for convenient adjustment of temperature, flame brightness, and timer settings for the fireplace, and LED light settings. The effective control distance is approximately 33 feet (10 meters). Requires 2 x AAA batteries (not included).
- **Control Panel:** The fireplace insert features an accessible control panel for direct adjustments.
- **Smartphone APP Control:** For LED lights, use the innovative smartphone application via Bluetooth connection to change colors and settings directly from your device.

5. Storage Features

The TV stand offers ample storage for your media and decorative items.

- **Adjustable Glass Shelves:** Two side cabinets feature adjustable glass shelves, allowing customization for various item sizes.
- **Open Compartment:** A central open compartment provides additional space for game consoles, media players, or other accessories.
- **Countertops:** Three countertops offer surfaces for decorative items or additional storage.

Visual guide to the ample storage space provided by the TV stand, including shelves and compartments.

6. Maintenance

To ensure the longevity and optimal performance of your TV stand and fireplace, follow these maintenance tips:

- **Cleaning:** Dust the surfaces regularly with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and mild cleaner, then dry immediately.
- **Fireplace Unit:** Ensure the fireplace vents are clear of dust and debris. Do not attempt to clean the interior of the fireplace unit.
- **Glass Panels:** Clean glass surfaces with a glass cleaner and a soft cloth to avoid streaks.
- **Electrical Cord:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

7. Troubleshooting

If you encounter issues with your RELAX4LIFE Electric Fireplace TV Stand, refer to the following common solutions:

- **Heater Not Turning On:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the main power switch on the fireplace unit is in the 'ON' position.
  - Verify that the thermostat setting is higher than the current room temperature.
  - If the unit overheated, it might have automatically shut off. Unplug, wait 15-20 minutes, then plug back in.
- **Remote Control Not Working:**
  - Replace the batteries (2 x AAA).
  - Ensure there are no obstructions between the remote and the fireplace unit's receiver.
- **LED Lights Not Responding:**
  - Check remote control batteries or try controlling via the smartphone app.
  - Ensure Bluetooth is enabled on your smartphone for app control.
- **Unusual Noises:** A slight fan noise is normal during heater operation. If loud or unusual noises occur, turn off and unplug the unit, then contact customer support.

8. Specifications

Feature	Specification
Brand	RELAX4LIFE
Model Number	RXE-10738
Product Dimensions (D x W x H)	33D x 149.9W x 82.6H centimetres (13"D x 59"W x 32.5"H)

Feature	Specification
Item Weight	39.46 kg
Material	Engineered Wood, Metal, Tempered Glass
Power Source	Corded Electric
Power Consumption	1400 watts
Heat Output	4777 BTU
Heating Coverage	Up to 400 sq ft
Thermostat Range	62°F to 82°F
Timer	0.5H - 6H
LED Lights	16 Colors, 4 Modes (Flash, Strobe, Fade, Smooth)
Flame Brightness	3 Levels
Remote Control Batteries	2 x AAA (Not Included)
Safety Features	Overheat Protection, Anti-Toppling Device, CSA Certified Heater

9. Warranty and Support

RELAX4LIFE products are designed for quality and reliability. For warranty information, technical support, or replacement parts, please refer to the contact information provided at the point of purchase or visit the official RELAX4LIFE website. Please have your model number (RXE-10738) and purchase date available when contacting support.

© 2024 RELAX4LIFE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D6YR5DCH

More documents and user manuals: **https://manuals.plus/**