Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC SP-PA15BT

JVC SP-PA15BT Portable Wireless Bluetooth Speaker

Instruction Manual

Model: SP-PA15BT

1. Introduction

This manual provides detailed instructions for the safe and effective use of your JVC SP-PA15BT Portable Wireless Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.

2. What's in the Box

Verify that all items are present in the packaging:

- JVC SP-PA15BT Portable Wireless Bluetooth Speaker
- Aux cable
- Shoulder strap
- USB-C charging chord

3. Product Overview

3.1 Speaker Components



Figure 1: Front view of the JVC SP-PA15BT speaker, showcasing its sleek design and integrated RGB lighting on the handle and side woofers.



Figure 2: Rear view of the JVC SP-PA15BT speaker, showing the rubberized port cover opened to reveal the charging and auxiliary input ports.

3.2 Control Panel



Figure 3: Detailed diagram of the speaker's top-mounted control panel, indicating buttons for power, volume, LED mode, Bluetooth multi-link, play/pause, and EQ control.

- **Power On/Off Button:** Press and hold to power the speaker on or off.
- **Volume Up/Down Buttons (-/+):** Adjust the playback volume.
- **Play/Pause Button (▶):** Play or pause audio playback.
- **LED Mode Button (★):** Cycle through different RGB lighting modes.
- **Bluetooth Multi-Link Button ( ):** Initiate or manage multi-speaker connections.
- **EQ Control Button (M):** Switch between available sound modes (e.g., Bass Boost).
- **Built-in Microphone:** For hands-free calls and voice assistant interaction.

4. Setup

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB-C charging cable to the USB-C port on the rear of the speaker and to a compatible USB power adapter (not included). The LED indicator will show charging status.



Figure 4: The speaker's power bank feature allows charging of external devices via its USB port, extending the utility beyond just audio playback.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button on the control panel until the indicator lights illuminate.
- **To Power Off:** Press and hold the Power button again until the indicator lights turn off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "JVC SP-PA15BT" from the list of devices.
4. Once connected, the blue LED will become solid, and a confirmation tone will sound.

4.4 Multi-Link Connection (Up to 100 Speakers)

The JVC SP-PA15BT supports multi-link functionality, allowing you to connect up to 100 compatible speakers for a synchronized audio experience.



Figure 5: Multiple JVC SP-PA15BT speakers demonstrating the Multi-Link connection capability, creating a larger, synchronized soundstage.

1. Ensure all speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (the master speaker), press the Bluetooth Multi-Link button. It will enter pairing mode.
3. On the other speakers (slave speakers), press the Bluetooth Multi-Link button. They will search for the master speaker.
4. Once connected, the master speaker's LED will indicate a successful multi-link connection.
5. Connect your device to the master speaker via Bluetooth as described in Section 4.3.

4.5 Aux-in Connection

To connect a device via the auxiliary input:

1. Open the rubberized port cover on the rear of the speaker.
2. Connect one end of the supplied 3.5mm aux cable to the AUX-IN port on the speaker.
3. Connect the other end of the aux cable to the audio output of your device.
4. The speaker will automatically switch to AUX mode.

5. Operating Instructions

5.1 Basic Playback

- **Play/Pause:** Press the Play/Pause button (▶).
- **Volume Adjustment:** Use the Volume Up (+) and Volume Down (-) buttons.
- **Skip Track:** Press and hold the Volume Up (+) button for next track, or Volume Down (-) button for previous track.

5.2 RGB Lighting Modes

The speaker features dynamic RGB lighting on the handle and side woofers. Press the LED Mode button (★) to cycle through the 4 available color mode options and effects.



Figure 6: The speaker's multi-color illumination feature, highlighting the vibrant RGB lights on the side woofers.

5.3 Sound Modes (EQ Control)

The speaker offers 2 sound modes to tailor your audio experience. Press the EQ Control button (M) to switch between modes, including a Bass Boost option for enhanced low frequencies.



Figure 7: Visual representation emphasizing the speaker's 120W maximum output and striking bass capabilities.

5.4 Voice Assistant

The built-in microphone supports voice assistant integration (e.g., Siri). Once connected to your smartphone, activate your device's voice assistant feature to use it through the speaker.

5.5 Power Bank Functionality

Utilize the speaker's built-in power bank to charge your mobile devices. Connect your device's charging cable to the USB-A output port located under the rubberized cover on the rear of the speaker.

6. Maintenance

6.1 Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents. For stubborn dirt, a slightly damp cloth can be used, ensuring all ports are securely closed.

6.2 Water Resistance (IPX6)

The JVC SP-PA15BT speaker is IPX6 water-resistant, meaning it can withstand high-pressure water jets from any direction. This makes it suitable for outdoor use and splashes. **Ensure the rubberized port cover on the rear is securely closed**

before exposing the speaker to water. Do not submerge the speaker in water.



Figure 8: The speaker's IPX6 water resistance is highlighted, showing it can withstand water splashes, making it ideal for outdoor environments.

6.3 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No Bluetooth connection.	Speaker not in pairing mode / Device Bluetooth off.	Ensure speaker is in pairing mode. Enable Bluetooth on your device and re-scan.

Problem	Possible Cause	Solution
Poor sound quality.	Volume too low / EQ setting / Device audio source.	Adjust volume. Try different EQ modes. Check audio source on your device.
Multi-Link not connecting.	Speakers not in multi-link pairing mode.	Ensure all speakers are disconnected from other devices and in multi-link pairing mode.

8. Specifications

Feature	Detail
Brand	JVC
Model Name	JVC Portable Speaker SP-PA15BT
Speaker Maximum Output Power	120 Watts
Connectivity Technology	Bluetooth 5.3
Water Resistance Level	IPX6 (Waterproof)
Battery Life	11 Hours
Product Dimensions	7"D x 17"W x 8"H
Item Weight	7.7 pounds
Material	Plastic
Included Components	Aux cable, Shoulder strap, Speaker, USBC charging chord

9. Warranty and Support

This JVC SP-PA15BT speaker comes with a **Limited Warranty**. For detailed warranty information, including terms, conditions, and how to make a claim, please refer to the warranty card included in your product packaging or visit the official JVC website. For technical support or service inquiries, please contact JVC customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D7QQC7LV

More documents and user manuals: **https://manuals.plus/**