Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZWP RE95201

ZWP Replacement Remote Control User Manual

For Polk Audio SoundBar Speaker Models FR1, DSB1, D581

1. Introduction

This manual provides instructions for the ZWP Replacement Remote Control, designed for use with specific Polk Audio SoundBar Speaker models. This remote offers a direct replacement experience, requiring no complex setup or programming.
Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.

2. Setup

2.1. Battery Installation

The remote control requires one CR2032 lithium button battery (not included). Follow these steps to install the battery:

1. Locate the battery compartment on the back of the remote control.
2. Using a small coin or screwdriver, gently twist the battery cover counter-clockwise to open.
3. Insert one CR2032 battery with the positive (+) side facing upwards, as indicated inside the compartment.
4. Replace the battery cover and twist clockwise to secure it.



Figure 2.1: Battery compartment and CR2032 battery installation.

2.2. Compatibility

This ZWP replacement remote control is designed to be perfectly compatible with the following Polk Audio SoundBar Speaker System Models:

- FR1
- DSB1
- D581
- RE95201
- RE9520-1

No programming or setup is required. Simply insert the batteries, and the remote is ready for use with your compatible soundbar.



Figure 2.2: The remote control is perfectly compatible and requires no setup.

3. Operating Instructions

The ZWP Replacement Remote Control utilizes advanced infrared technology for stable and responsive control of your soundbar. It offers multi-angle and long-distance control without obstruction.



Figure 3.1: The remote control offers stable link and fast response.

3.1. Basic Functions

The remote control features intuitive buttons for common soundbar functions:

- **Power Button ( )**: Turns the soundbar on or off.
- **Mute Button ( )**: Mutes or unmutes the sound.
- **Source Buttons (OPT 1, AUX 2, ♫)**: Selects the input source for the soundbar (Optical, Auxiliary, Bluetooth).
- **Volume Buttons (VOL +, VOL -)**: Increases or decreases the main volume.
- **Bass Buttons (BASS +, BASS -)**: Adjusts the bass level.



Figure 3.2: Overview of remote control buttons.

3.2. Transmission Range and Angle

The remote control provides a maximum range of up to 26 feet (approximately 8 meters) and supports multi-angle induction, allowing for control from various positions within the room.



Figure 3.3: Multi-angle induction and effective range.

4. Maintenance

4.1. Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the surface or internal components.

4.2. Battery Replacement

When the remote control's performance diminishes or it stops responding, it is likely time to replace the battery. Refer to Section 2.1 for detailed battery installation instructions. The remote is designed for ultra-long standby time, up to 6 months, but actual battery life may vary based on usage.

5. Troubleshooting

- **Remote not responding:**

- Ensure the battery is correctly installed with the correct polarity.
- Replace the battery with a new CR2032 battery.
- Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
- Make sure you are within the effective operating range (up to 26 feet).

- **Intermittent response:**
  - The battery may be low; replace it.
  - Ensure a clear line of sight to the soundbar.

This remote control does not require programming, so issues related to setup are generally not applicable.

6. Specifications

Feature	Detail
Brand	ZWP
Model Number	RE95201
Connectivity Technology	Infrared
Compatible Devices	Polk Audio Sound Bar (FR1, DSB1, D581, RE95201, RE9520-1)
Special Feature	No Programming Required
Battery Type	1 x CR2032 (not included)
Maximum Range	10 meters (approx. 26 feet)
Item Weight	68 g
Material	High Quality ABS



Figure 6.1: Product Dimensions.

7. Warranty and Support

ZWP provides a **1-year after-sales service** for this product. If you have any questions or encounter issues with your remote control, please contact our customer support directly. We aim to respond within 12 hours to assist you.

For support, please refer to the contact information provided with your purchase or visit the ZWP official website.

© 2026 ZWP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D8GQ6XCV

More documents and user manuals: **https://manuals.plus/**