GOOJODOQ J201

Quick start guide for GOOJODOQ J201 Wireless Earbuds, covering initial charging, device pairing, touch controls, wearing instructions, and key specifications like Bluetooth 5.3, 40H playtime, IPX6 waterproof, and ANC.

GOOJODOQ J201 Wireless Earbuds User Manual

Model: J201 | Brand: GOOJODOQ

1. Product Overview

The GOOJODOQ J201 Wireless Earbuds are designed to provide a high-quality audio experience with advanced features for convenience and durability. These half in-ear lightweight headsets offer digital call noise reduction, a reset button, Hall detection for instant pairing, premium sound, and long endurance.



Image: GOOJODOQ J201 Wireless Earbuds in their charging case, showcasing their compact design.

Product Overview Video

Video: A comprehensive overview of the GOOJODOQ J201 Wireless Earbuds, highlighting key features and design elements.

2. What's in the Box

Upon opening your GOOJODOQ J201 package, you will find the following components:

- Wireless Charging Case
- User Manual
- Warranty Card
- Type-C Fast Charging Cable
- Lanyard

3. Product Features

3.1. Connectivity & Pairing

The J201 earbuds feature advanced Bluetooth 5.3 technology, offering twice the transfer speed (2Mbps) and a more reliable connection up to 10 meters. The built-in Hall Switch in the charging case enables instant pairing: simply open the lid, and the earbuds will automatically connect to your last paired device.



Image: Visual representation of the upgraded Bluetooth 5.3 chip, emphasizing stable connection.



Image: Illustration of the Bluetooth connectivity process, showing the earbuds pairing with a smartphone.

3.2. Battery & Charging

Enjoy extended listening with up to 7 hours of playtime on a single charge. The charging case provides multiple recharges, extending the total playtime to approximately 40 hours. The earbuds support Type-C fast charging, allowing for quick power-ups.



Image: Graphic illustrating the 40 hours of total playback duration and 7 hours of single charge playback.



Image: Diagram showing the fast charging capability, with 5 minutes of charging providing 5 hours of playback.

3.3. Audio Quality

The J201 earbuds are equipped with oversized 13.4mm drivers and active hybrid noise cancellation. Utilizing Sound4 acoustic processing technology, they retain more sound details, delivering an impressive CD-level sound experience with superior and deep bass, ensuring you hear every beat and detail clearly.



Image: Cross-section view of the earbud's internal components, highlighting the 13mm powerful speaker for Hi-Fi sound quality.

3.4. Design & Durability

Crafted from Acrylonitrile Butadiene Styrene (ABS) material, these earbuds are built for durability. They boast an IPX6 waterproof rating, protecting them from water and sweat, making them suitable for various activities (not for swimming). Each earbud is ultra-lightweight, weighing only 0.14 oz (approximately 4g), and the charging case is compact for easy portability.



Image: Visual demonstrating the IPX6 waterproof rating and the ultra-lightweight nature of the earbuds, depicted with feathers.



Image: Detailed product dimensions of the earbuds and charging case, with a size comparison to a quarter dollar coin.

3.5. Controls

The J201 earbuds feature intuitive touch controls directly on the earpieces. These controls allow you to manage music playback (play, pause, skip tracks), adjust volume, answer and end calls, and activate your phone's voice control with simple taps.



Image: Diagram illustrating the touch control functions on the earbud, showing various tap gestures for different commands.

4. Setup Guide

4.1. Initial Charging

1. Place both earbuds into the charging case.
2. Connect the Type-C fast charging cable to the charging port on the case and a power source.
3. Allow the earbuds and case to fully charge before first use. A full charge for the case takes approximately 1.5 hours.

4.2. Pairing with Your Device

1. Ensure the earbuds are charged.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings and turn on Bluetooth.

4. Search for available devices and select "J201" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

5. Operating Instructions

5.1. Wearing the Earbuds

Gently insert each earbud into your ear canal. Adjust for a comfortable and secure fit. The half in-ear design ensures a lightweight feel.

5.2. Touch Control Functions

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold on either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold on either earbud for 3 seconds.

6. Maintenance

6.1. Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the earbud openings or charging ports. Do not use abrasive cleaners or solvents.

6.2. Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

7.1. Earbuds Not Pairing

- Ensure both earbuds are fully charged.
- Make sure Bluetooth is enabled on your device.
- Place the earbuds back in the case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
- If issues persist, try forgetting "J201" from your device's Bluetooth settings and re-pairing.

7.2. No Sound or Low Volume

- Check the volume level on both your earbuds (via touch control) and your connected device.
- Ensure the earbuds are properly connected to your device.

- Clean any debris from the earbud speakers.

7.3. Charging Issues

- Verify that the charging cable is securely connected to both the case and the power source.
- Try using a different Type-C cable or power adapter.
- Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.

8. Specifications

Feature	Detail
Model Name	J201-White
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Metres
Total Playtime	Up to 40 Hours (with charging case)
Single Charge Playtime	Up to 7 Hours
Charging Time (Case)	Approx. 1.5 Hours (Type-C Fast Charging)
Audio Driver Type	Dynamic Driver (13.4mm)
Noise Control	Active Hybrid Noise Cancellation
Water Resistance Level	IPX6 Waterproof
Item Weight (per earbud)	Approx. 0.14 oz (4g)
Material	Acrylonitrile Butadiene Styrene (ABS)
Control Type	Touch Control
Microphone Format	Built-In
Product Dimensions	5.5 x 2 x 5 cm (Charging Case)

9. Warranty and Support

Your GOOJODOQ J201 Wireless Earbuds come with a Warranty Card included in the box. Please refer to the Warranty Card for detailed information regarding warranty coverage, terms, and conditions.
For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact GOOJODOQ customer service through the contact information provided on your Warranty Card or the official GOOJODOQ website.

© 2024 GOOJODOQ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I fix my GOOJODOQ J201 earbuds if they appear as two different devices in my Bluetooth settings?

If your GOOJODOQ J201 earbuds appear as two separate devices in your Bluetooth settings, it means they have lost their mutual synchronization and are operating in "single earbud mode." To fix this and re-sync...

Read full answer

My GOOJODOQ J201 earbuds appear as two different devices in Bluetooth settings; how do I fix this?

If your GOOJODOQ J201 earbuds are appearing as two separate Bluetooth devices, it means they have lost their mutual synchronization and are operating in "single earbud mode." To fix this and pair them as...

Read full answer

How do I factory reset and re-pair my GOOJODOQ J201 earbuds if they are appearing as two separate Bluetooth devices?

To resolve the issue where your GOOJODOQ J201 earbuds appear as two separate devices (losing their True Wireless Stereo pairing), please follow these steps to reset and re-sync them:Clear Bluetooth History: On your smartphone...

Read full answer