Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GarveeTech LLT-PHO_134VM3SUD12j

GarveeTech 24-inch Wine Cooler Refrigerator User Manual

Model: LLT-PHO_134VM3SUD12j

1. Important Safety Information

Please read all instructions carefully before using your new GarveeTech Wine Cooler. Keep this manual for future reference. Failure to follow these safety instructions may result in fire, electric shock, or property damage.

- This appliance is intended for household use only.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Ensure the appliance is properly grounded.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Unplug the appliance before cleaning or performing maintenance.
- Do not allow children to play with or inside the appliance.

2. Product Overview

The GarveeTech 24-inch Wine Cooler Refrigerator is designed to store up to 46 standard wine bottles, maintaining optimal temperature conditions for your collection. It features stable temperature control, a digital control panel, and a durable stainless steel and tempered glass construction.



Figure 2.1: Front view of the GarveeTech Wine Cooler, showcasing its sleek design and bottle capacity.

3. Setup and Installation

3.1 Unpacking

- Carefully remove all packaging materials, including foam and tape.
- Inspect the appliance for any shipping damage. If damage is found, do not plug in the unit and contact customer support.
- Remove any protective film from the stainless steel surfaces.

3.2 Placement

This wine cooler is designed for both freestanding and built-in installation. Ensure proper ventilation around the unit.

- Place the unit on a flat, stable surface strong enough to support its weight when fully loaded.
- Allow at least 2 inches (5 cm) of space at the back and sides for proper air circulation.
- Avoid direct sunlight or heat sources.
- Ensure the ambient temperature is between 60°F (16°C) and 90°F (32°C) for optimal performance.



Figure 3.1: Example of the wine cooler used as a freestanding unit.



Figure 3.2: Example of the wine cooler installed as an embedded unit, with dimensions indicated.

3.3 Leveling the Unit

The unit has adjustable feet. Use a level to ensure the appliance is perfectly level. Adjust the feet by turning them clockwise or counter-clockwise.

3.4 Electrical Connection

Plug the appliance into a dedicated, grounded 110V/60Hz electrical outlet. Do not use extension cords or adapter plugs.

4. Operating Instructions

4.1 Control Panel

The digital control panel allows you to adjust the temperature, control the interior LED lighting, and lock settings.



Figure 4.1: Digital control panel with temperature display and touch buttons.

- **Power Button (U):** Press to turn the unit on or off.
- **Temperature Up/Down Buttons (+ / -):** Adjust the desired temperature between 41°F and 64°F (5°C-18°C).
- **Light Button (Light Icon):** Press to turn the interior LED light on or off.
- **Lock Button (Lock Icon):** Press and hold for 3 seconds to lock or unlock the control panel to prevent accidental changes.

4.2 Loading Wine Bottles

The wine cooler features removable wooden shelves designed to accommodate various bottle sizes. It has a capacity of up to 46 standard wine bottles.



Figure 4.2: Interior view showing slide-out solid wood shelves comfortably accommodating 46 bottles.

- Ensure bottles are placed securely on the shelves to prevent rolling.
- Avoid overloading shelves to maintain proper air circulation.
- The double-layer tempered glass door protects wines from harmful UV radiation.

5. Maintenance

5.1 Cleaning the Interior

- Unplug the unit before cleaning.
- Clean the interior with a soft cloth dampened with a mild detergent solution.
- Do not use abrasive cleaners or solvents.
- Wipe dry thoroughly.

5.2 Cleaning the Exterior

- Clean the exterior surfaces with a soft cloth and mild soap.
- For stainless steel, use a stainless steel cleaner and polish in the direction of the grain.
- Clean the door gasket regularly to ensure a proper seal.

5.3 Activated Carbon Filter

The wine cooler includes an activated carbon filter to maintain a golden humidity environment of 60-80% and reduce microbial reproduction and unpleasant odors. Replace the filter periodically (typically every 6-12 months).



Figure 5.1: Internal components, highlighting the activated carbon filter for odor control and humidity regulation.

5.4 Defrosting

This unit features a frost-free defrost system, minimizing the need for manual defrosting.

6. Troubleshooting

Before contacting customer support, please refer to the following table for common issues and solutions.

Problem	Possible Cause	Solution
Unit does not operate	Not plugged in; circuit breaker tripped; power outage.	Check power cord connection; reset circuit breaker; check household power supply.
Unit is not cold enough	Temperature setting too high; door not closed properly; excessive door openings; poor ventilation.	Lower temperature setting; ensure door is sealed; minimize door openings; ensure adequate clearance around unit.
Excessive vibration	Unit not level; bottles touching each other.	Adjust leveling feet; rearrange bottles to prevent contact.
Noise from unit	Normal compressor operation; fan noise.	This is normal. If noise is unusual or excessive, contact support.
Door does not close properly	Unit not level; door gasket dirty or damaged; shelves out of position.	Level the unit; clean or replace gasket; ensure shelves are correctly inserted.

7. Specifications

Feature	Specification
Model Number	LLT-PHO_134VM3SUD12j
Capacity	46 Standard Wine Bottles (4.8 Cubic Feet)
Temperature Range	41°F - 64°F (5°C - 18°C)
Product Dimensions (D x W x H)	26.77 x 25.59 x 34.65 inches (68 x 65 x 88 cm)
Item Weight	99.2 pounds (45 kg)
Voltage	110V / 60Hz
Number of Doors	1
Defrost System	Frost Free
Special Features	Adjustable Shelves, Digital Control Panel, Double-Layer Tempered Glass, Safety Lock, Quiet Operation

8. Warranty and Support

8.1 Warranty Information

This product may be eligible for extended protection plans, such as a 3-Year Protection Plan or Asurion Complete Protect. Please refer to your purchase documentation or contact the retailer for specific warranty terms and conditions provided by GarveeTech.

8.2 Customer Support

For technical assistance, parts, or service inquiries, please visit the official GarveeTech store or contact their customer service department. You can find more information at the GarveeTech Store on Amazon.

© 2024 GarveeTech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D97DVZC9

More documents and user manuals: **https://manuals.plus/**