**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Dpofirs Dpxgimbnpsw4-13**

# Dpofirs Portable TV On Wheels (Model Dpxgimbnpsw4-13) - Instruction Manual

Your guide to setting up, operating, and maintaining your Dpofirs Portable TV.

## 1. Product Overview

The Dpofirs Portable TV On Wheels is a versatile 21.5-inch TFT HD LCD display designed for flexible use in various environments. It features a rotatable screen, 4G+64G internal storage, and phone screen casting capabilities, making it suitable for entertainment, live streaming, and interactive applications.



Figure 1: Dpofirs Portable TV On Wheels, showcasing its ability to display content in both horizontal and vertical orientations.




Figure 2: Key features of the Dpofirs Portable TV, including an 8MP HD front camera, Bluetooth 5.0, 10-point touch, dual speakers, wireless projection, and anti-blue light technology.

## 2. Safety Information

Please read all safety instructions before using the device to prevent injury or damage. Keep this manual for future reference.

- Do not expose the device to rain or moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Ensure proper ventilation to prevent overheating.
- Use only the provided power adapter.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Keep the device away from children and pets.
- Ensure the base is stable on a flat surface to prevent tipping.

## 3. Package Contents

Verify that all items are present in the package:

- Dpofirs Portable TV Unit (21.5-inch screen)
- Stand Pole
- Round Base
- Power Adapter (UK Plug 100-240V)
- Remote Control
- User Manual (this document)

## 4. Setup and Assembly

Follow these steps to assemble and set up your Dpofirs Portable TV:

1. **Assemble the Stand:**
    - Carefully attach the stand pole to the round base. Ensure it is securely fastened.
    - Attach the TV unit to the top of the stand pole. Make sure all connections are tight.
2. **Power Connection:**
    - Connect the provided power adapter to the TV's power input port.
    - Plug the power adapter into a suitable wall outlet (100-240V).
3. **Initial Power On:**
    - Press the power button on the TV unit or the remote control to turn on the device.
    - Follow the on-screen instructions for initial setup, including language selection and network connection.




Figure 3: Dimensional diagram of the Dpofirs Portable TV, showing screen width (50cm/19.7in), screen height (27.5cm/10.8in), total pole height (100cm/39.4in), and base diameter (34cm/13.4in).

## 5. Operating Instructions

### 5.1 Basic Operation

- **Power On/Off:** Press the power button on the TV or remote control.
- **Volume Control:** Use the volume buttons on the remote control.
- **Navigation:** Use the directional buttons and OK/Enter button on the remote control to navigate menus. The screen also supports 10-point touch for direct interaction.

### 5.2 Screen Rotation and Adjustment

The Dpofirs Portable TV features a rotatable screen and adjustable tilt for optimal viewing.

- **Rotation:** The screen can rotate 90 degrees vertically to switch between landscape and portrait modes. Gently rotate the screen until it clicks into position.
- **Tilt Adjustment:** The screen can be adjusted up and down by +/- 25 degrees and +/- 20 degrees for ergonomic viewing angles.




Figure 4: Illustration of the screen's rotational capability (90 degrees vertical rotation) and tilt adjustments (+/- 25 degrees and +/- 20 degrees).

## 5.3 Connectivity

- **Wi-Fi:** Connect to a wireless network via the settings menu for internet access and streaming.
- **Bluetooth:** Pair Bluetooth devices such as headphones or speakers through the Bluetooth settings.
- **Screen Casting:** Utilize the wireless projection screen feature to cast content from compatible smartphones or other devices. Refer to your device's casting instructions.
- **HDMI:** Connect external devices using an HDMI cable. The TV supports HDMI signal format.

- **Type-C:** Use the Type-C port for audio input or other compatible connections.

## 5.4 Advanced Features

- **10-Point Touch Screen:** Interact directly with the display for navigation, gaming, and applications.
- **8MP HD Front Camera:** For video calls or other camera-enabled applications.
- **Anti-Blue Light:** The display incorporates technology to reduce blue light emission, promoting eye comfort during extended viewing.
- **Dual Speakers:** Integrated stereo speakers for audio output.




Figure 5: The Incell screen technology provides 10-point touch capability, enhancing user interaction and display quality.




Figure 6: Explanation of eye protection against blue light, detailing how the screen's technology filters harmful wavelengths to prevent visual fatigue.




Figure 7: The Dpofirs Portable TV is suitable for a variety of scenarios, from personal fitness and cooking to professional meetings and outdoor entertainment.

## 6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Dpofirs Portable TV.

- **Cleaning the Screen:** Use a soft, lint-free cloth specifically designed for electronics. Do not use abrasive cleaners or sprays directly on the screen.
- **Cleaning the Body:** Wipe the exterior surfaces with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water.
- **Storage:** When not in use for extended periods, store the TV in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Management:** Ensure all cables are neatly organized and not under tension to prevent damage.

## 7. Troubleshooting

If you encounter issues with your Dpofirs Portable TV, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| No power | Power cable not connected; power outlet faulty; device off. | Check power cable connection; try a different outlet; press power button. |
| No picture/sound | Incorrect input source; volume too low; external device issue. | Select correct input source (HDMI, casting); increase volume; check external device connection. |
| Wi-Fi connection issues | Incorrect password; router too far; network interference. | Verify Wi-Fi password; move closer to router; restart router. |
| Touch screen unresponsive | Software glitch; screen dirty. | Restart the TV; clean the screen with a soft cloth. |
| Screen rotation not working | Not rotated fully; software issue. | Ensure screen is rotated firmly into position; restart the TV. |

If the problem persists after trying these solutions, please contact customer support.

## 8. Specifications

Detailed technical specifications for the Dpofirs Portable TV On Wheels:

| Feature | Specification |
|---|---|
| Brand | Dpofirs |
| Model Number | Dpxgimbnpsw4-13 |
| Display Technology | LCD |
| Screen Size | 21.5 inches |
| Resolution | 1080 x 1920 (Full HD) |
| Aspect Ratio | 16:9 |
| Connectivity Technology | Bluetooth, Wi-Fi, HDMI, Type-C |
| Audio Input | Bluetooth, Type C |

| Feature | Specification |
|---|---|
| Included Components | Remote control |
| On-mode Power Consumption | 35 watts |
| Package Dimensions | 106.8 x 39.6 x 2.6 cm |
| Item Weight | 12.34 kg |

## 9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Dpofirs website. Keep your proof of purchase for warranty claims.
If you require technical assistance or have questions not covered in this manual, please contact Dpofirs customer service.

© 2024 Dpofirs. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0D99XYQFB**

More documents and user manuals: **https://manuals.plus/**