Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy 1DBXX98ABK

Sweetcrispy 3.2 Cu.Ft Mini Fridge with Freezer - User Manual

Model: 1DBXX98ABK

Introduction

This manual provides essential information for the safe and efficient operation of your Sweetcrispy 3.2 Cu.Ft Mini Fridge with Freezer. Please read it thoroughly before installation and use, and retain it for future reference.

Safety Information

- Ensure the appliance is properly grounded.
- Do not use electrical appliances inside the food storage compartments.
- Keep ventilation openings clear of obstruction.
- Do not damage the refrigerant circuit.
- Unplug the appliance before cleaning or maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

What's in the Box

- 1 x 3.2 Cubic Feet Mini Fridge with Freezer
- 1 x Crisper Drawer
- 2 x Removable Shelves
- 1 x User Manual

Setup

1. Placement

Place the mini fridge on a flat, stable surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit. The compact dimensions of 17.5"W x 17.7"D x 31.5"H make it suitable for various small spaces.



Image: The Sweetcrispy Mini Fridge with its dimensions (17.5 inches wide, 17.7 inches deep, 31.5 inches high) highlighted, demonstrating its compact footprint of 2.15 sq ft.

2. Leveling

The mini fridge is equipped with adjustable leveling legs at the front to ensure stability and proper door sealing. Rotate the legs to adjust the height until the appliance is level on your surface.



Image: A close-up of the adjustable leveling leg at the bottom of the mini fridge, showing a 360-degree rotation arrow for adjustment.

▶ **Watch video online**
Sweetcrispy Product Overview

Video: An official product overview video from Sweetcrispy, showcasing the mini fridge's features including its compact size and suitability for various spaces.

3. Power Connection

Plug the appliance into a dedicated 115 Volt outlet. Allow the refrigerator to stand upright for at least 2-4 hours before plugging it in to allow the refrigerant to settle.

Operating Instructions

1. Temperature Control

The mini fridge features an adjustable thermostat with five temperature settings. Turn the dial to your desired cooling level. The third level is generally recommended for residential or workplace use.



Image: A close-up of the temperature control dial inside the mini fridge, showing settings from 0 to 5, with an arrow indicating adjustment.

2. Storage Zones

The refrigerator has a total capacity of 3.2 Cu.Ft, divided into two main zones:

- **Refrigerator Zone:** 2.9 Cu.Ft capacity, maintaining temperatures between 33.8°F and 44°F. Ideal for fruits, eggs, vegetables, and milk.
- **Freezer Area:** 0.3 Cu.Ft capacity, maintaining temperatures between 23°F and 35°F. Suitable for meat and ice cream.



Image: An open Sweetcrispy Mini Fridge showing the interior layout with the freezer compartment (0.3 Cu.Ft, 23°F to 35°F) and the main refrigerator compartment (2.9 Cu.Ft, 33.8°F to 44°F), along with examples of items stored.

3. Interior Organization

The interior is designed for efficient storage:

- **Crisper Drawer:** One transparent crisper drawer is included for keeping fruits and vegetables fresh.
- **Adjustable Shelves:** Two removable tempered glass shelves allow for flexible storage configurations.
- **Door Compartments:** Multiple compartments on the door provide space for beverages and condiments.



Image: A collage of close-up images showing various features of the Sweetcrispy Mini Fridge, including the crisper drawer, 5 temperature settings, removable door seal, removable tempered glass shelf, covered freezer, glossy black surface, adjustable leveling leg, and the 0.3 Cu.Ft freezer area.

▶ **Watch video online**

Sweetcrispy 3.2 Cu.Ft Small Refrigerator with Freezer

Video: An official product video from Sweetcrispy DIRECT showcasing the interior features of the 3.2 Cu.Ft Small Refrigerator with Freezer, including the crisper drawer, adjustable shelves, and door storage.

Maintenance

1. Cleaning

Regularly clean the interior and exterior of the refrigerator with a mild detergent and soft cloth. The removable tempered glass shelves and door seal facilitate easy cleaning.



Image: A hand demonstrating the removal of a tempered glass shelf from the interior of the mini fridge, highlighting its adjustability and ease of cleaning.

2. Defrosting

This model features manual defrost. When frost accumulates to a thickness of about 1/4 inch, turn off the appliance, remove all contents, and allow the frost to melt naturally. Clean and dry the interior before restarting.

Energy Efficiency & Noise Level

The Sweetcrispy mini fridge is designed to be energy-efficient, consuming approximately 0.41 kWh per day. It operates at a low noise level of 38dB, ensuring a quiet environment suitable for bedrooms, offices, or dorms.



Image: The Sweetcrispy Mini Fridge placed in a bedroom setting, with graphics indicating its low noise level (38dB) and energy consumption (0.41 kWh/24 hours).

Troubleshooting

If your refrigerator is not operating correctly, check the following common issues:

- **No Power:** Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
- **Not Cooling:** Verify the temperature control dial is set to an appropriate level. Ensure the door is fully closed and the door seal is intact. Avoid placing hot food inside.
- **Excessive Noise:** Check if the refrigerator is level. Ensure there is enough space around the unit for proper ventilation.
- **Frost Buildup:** This is a manual defrost unit. If frost is excessive, perform a manual defrost as described in the Maintenance section.

For persistent issues, please contact customer support.

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Number	1DBXX98ABK
Capacity	3.2 Cubic Feet (Total)
Refrigerator Fresh Food Capacity	2.9 Cubic Feet
Freezer Capacity	0.3 Cubic Feet
Product Dimensions	17.7"D x 17.5"W x 31.5"H
Item Weight	43.2 Pounds
Annual Energy Consumption	210 Kilowatt Hours Per Year
Installation Type	Freestanding
Color	Black
Voltage	115 Volts
Defrost System	Manual
Number of Doors	1
Shelf Type	Glass
Number of Shelves	2
Crispers/Drawers	1
Special Features	Adjustable Shelves, Compact, Energy Efficient, Large Capacity, Low Noise

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official Sweetcrispy website. Protection plans are available for purchase separately. You can find more information about Sweetcrispy products at theirAmazon Store.

© 2024 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9BLZK6T

More documents and user manuals: **https://manuals.plus/**