Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR JX-SW03

VEVOR JX-SW03 A-Frame Swing Set Instruction Manual

Model: JX-SW03 | Brand: VEVOR

1. Safety Information

Please read and understand all instructions and safety warnings before assembly and use of the VEVOR JX-SW03 A-Frame Swing Set. Failure to follow these instructions may result in serious injury.

- **Adult Supervision Required:** Always supervise children while they are using the swing set.
- **Weight Capacity:** This swing set is designed to support a maximum total weight of 600 pounds (272 kg). Do not exceed this limit.
- **Age Recommendation:** Suitable for children aged 3 years and older.
- **Proper Installation:** Ensure the swing set is assembled on a level surface and securely anchored to the ground using the provided ground pegs or sandbags to prevent tipping.
- **Clearance:** Maintain a safe clearance area around the swing set, free from obstacles such as fences, trees, or other play equipment.
- **Clothing:** Ensure children do not wear loose clothing, hooded garments, or items that could get caught on the swing set.
- **Regular Inspection:** Periodically check all nuts, bolts, ropes, and connections for tightness and wear. Replace worn or damaged parts immediately.

2. Setup Instructions

Follow these steps for proper assembly of your VEVOR JX-SW03 A-Frame Swing Set. All necessary tools are included in the package.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components are present against the parts list in your included manual.
2. **Assemble Top Bar:** Connect the two halves of the orange top bar using the provided bolts and iron sheets. Ensure all bolts are securely tightened.
3. **Attach Eye Screws:** Insert and secure the eye screws into the designated holes on the top bar. These will be used to hang the swings.
4. **Attach Top Legs:** Connect the blue top legs to the orange top bar using the specified bolts.

5. **Attach Bottom Legs and Side Stay Bars:** Secure the blue bottom legs to the top legs. Then, attach the orange side stay bars to the outside of the legs, securing them with bolts.
6. **Assemble Swings:**
    - **Saucer Swing:** Insert the metal frame pieces into the foam padding, then into the fabric edge of the nest swing. Connect the metal frame together and fasten using the bolt at the end of the rope.
    - **Belt Swings:** Ensure ropes are securely knotted and attached to the belt seats.
7. **Attach Swings to Frame:** Use the carabiner hooks to attach the assembled swings to the eye screws on the top bar. Ensure the carabiners are fully closed and locked.
8. **Secure to Ground:** Attach the ground pegs to the bottom legs and rotate them into the ground for enhanced stability. For additional stability, especially on hard surfaces or for heavier use, fill the provided sandbags (sand not included) and place them around the base of the legs.

Setup Visual Guide:



Image: All components laid out for assembly.

▶ **Watch video online**
VEVOR Swing Sets for Backyard

Video: Step-by-step assembly guide for the VEVOR A-Frame Swing Set, demonstrating how to connect bars, attach legs, and secure the frame. This video is provided by the seller.

▶ **Watch video online**
Swing Sets for Backyard

Video: Detailed assembly instructions for the VEVOR Swing Set, including connecting frame parts and attaching swings. This video is provided by the seller.

3. Operating Instructions

The VEVOR JX-SW03 A-Frame Swing Set offers versatile play options for children.


- **Using the Swings:** Children can enjoy the saucer swing or the two belt swings. Ensure only one child uses each swing at a time.
- **Adjusting Rope Length:** The ropes for both the saucer and belt swings are adjustable. To adjust, locate the rope adjustment mechanism (typically a buckle or knot) and modify the length to suit the child's height, ensuring their feet can comfortably reach the ground when seated.
- **Toddler Swing (if applicable):** If using a toddler swing (sold separately or as an alternative configuration), ensure the safety bar and harness are securely fastened before use.

Product Features in Use:



Image: Children playing on the VEVOR A-Frame Swing Set, highlighting the adjustable ropes for different heights.

PRODUCT PARAMETERS



Item Model Number : JX-SW03	Swing Rope Material : Fabric Rope
Maximum Load Capacity : 600 lbs / 272 kg	Rope Adjustable Range : 33.5-55 in / 850-1400 mm
Round Seat : 32 in / 813 mm	Product Weight : 48.50 lbs / 22 kg
Metal Frame Material : Steel Pipe	Product Dimensions : 72.01 x 120 x 65 in / 182.9 x 304.8 x 165.1 mm
Seat Material : Oxford Fabric	

Image: The VEVOR A-Frame Swing Set shown in different environments, demonstrating its versatile use in backyards, parks, and playgrounds.

4. Maintenance

Regular maintenance ensures the longevity and safety of your VEVOR JX-SW03 A-Frame Swing Set.

- **Monthly Checks:** Inspect all nuts, bolts, and connections for tightness. Tighten any loose fasteners immediately.
- **Rope and Seat Inspection:** Check ropes, chains, and swing seats for signs of wear, fraying, or damage. Replace any worn parts to prevent accidents.
- **Cleaning:** Clean the metal frame and plastic seats with mild soap and water. Avoid abrasive cleaners that could damage the finish.
- **Winter Storage:** During winter months or prolonged periods of non-use, it is recommended to disassemble and store the swing set indoors to protect it from harsh weather conditions. The frame features a foldable design for convenient storage.

Storage Feature:



Image: The VEVOR A-Frame Swing Set disassembled and stored, demonstrating its space-saving and portable design.

5. Troubleshooting

If you encounter any issues with your VEVOR JX-SW03 A-Frame Swing Set, refer to the following common problems and solutions:

- **Swing Set Wobbles:**
  - Ensure all bolts and nuts are securely tightened.
  - Verify the swing set is placed on a level surface.
  - Utilize the provided ground pegs to anchor the legs firmly into the ground.
  - For added stability, especially on uneven ground or with active use, fill the sandbags (sand not included) and place them around the base of each leg.
- **Squeaking Noises:**
  - Apply a small amount of lubricant (e.g., silicone spray) to the pivot points of the swing hangers and any

metal-on-metal connections.
    - Check for loose bolts and tighten as necessary.
- **Difficulty Adjusting Ropes:**
    - Ensure the rope adjustment mechanism is clean and free of debris.
    - Follow the specific instructions in the full manual for rope adjustment.

6. Specifications

Feature	Detail
Brand	VEVOR
Model Number	JX-SW03
Material	Steel Pipe
Finish Type	Powder Coated
Product Dimensions (D x W x H)	72.05" x 120.08" x 64.96" (182.9 cm x 304.8 cm x 165.1 cm)
Item Weight	48.5 Pounds (22 kg)
Maximum Load Capacity	600 Pounds (272 kg)
Round Seat Diameter	32 inches (813 mm)
Seat Material	Oxford Fabric
Swing Rope Material	Fabric Rope
Rope Adjustable Range	33.5-55 inches (850-1400 mm)
Maximum Compatible Number of Seats	3
Required Assembly	Yes

Detailed Product View:



Image: Diagram illustrating the key product parameters and dimensions of the VEVOR A-Frame Swing Set.

7. Warranty & Support

VEVOR products are designed for durability and performance. For specific warranty details, please refer to the warranty information included in your product packaging or visit the official VEVOR website.
If you have any questions, require technical assistance, or need to report a problem with your VEVOR JX-SW03 A-Frame Swing Set, please contact VEVOR customer support through their official website or the contact information provided in your product manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D9GWKJPK

More documents and user manuals: **https://manuals.plus/**