DURACELL 1805028

Duracell Durabeam Ultra Hybrid LED Flashlights (1200 Lumens) Instruction Manual

Model: 1805028

Introduction

Thank you for choosing the Duracell Durabeam Ultra Hybrid LED Flashlights. This manual provides essential information for the safe and effective use of your new flashlights. These versatile flashlights are designed for various lighting needs, offering powerful illumination and flexible power options.

Package Contents

Verify that all items listed below are included in your package:

- 3 x Duracell Durabeam Ultra Hybrid LED Flashlights
- 3 x Rechargeable Battery Packs (pre-installed in flashlights or separate)
- 3 x AAA Battery Holders
- 12 x AAA Alkaline Batteries
- 3 x USB-C Charging Cables



Image: The complete package showing three flashlights, rechargeable batteries, AAA batteries, battery holders, and USB-C cables.

Product Features

- **Hybrid Power System:** Operates with either the included rechargeable battery pack or four AAA alkaline batteries (using the provided holder).
- **High Brightness:** Each flashlight delivers up to 1200 lumens of LED light output.
- **Adjustable Beam:** Zoom function allows adjustment from a wide flood beam to a focused spot beam.
- **Multiple Light Modes:** Features High, Low, and Strobe light modes for various situations.
- **Battery Indicator:** An integrated power indicator light displays remaining battery life.
- **Durable Construction:** Made from aluminum and plastic, with an IPX4 water-resistant rating for outdoor use.
- **USB-C Charging:** Rechargeable battery packs can be conveniently charged via USB-C.



Image: Diagram illustrating the hybrid power capability (rechargeable or AAA batteries) and the adjustable zoom beam feature of the flashlight.

Setup

Battery Installation

1. **For Rechargeable Battery Pack:** The rechargeable battery pack is typically pre-installed. To access it, unscrew the tail cap of the flashlight. Ensure the battery pack is securely inserted with the correct polarity.
2. **For AAA Alkaline Batteries:** If using AAA batteries, insert four AAA batteries into the provided AAA battery holder, observing the correct polarity (+/-). Then, insert the loaded battery holder into the flashlight body and screw on the tail cap securely.

Charging the Rechargeable Battery Pack

1. Locate the USB-C charging port on the flashlight. This port is usually covered by a protective ring or sleeve. Twist or slide the ring/sleeve to expose the port.
2. Connect one end of the provided USB-C cable to the flashlight's charging port.
3. Connect the other end of the USB-C cable to a compatible USB power source (e.g., wall adapter, computer USB port, power bank).
4. The power indicator light on the flashlight will show charging status. It typically glows red during charging and turns green when fully charged.
5. Once charging is complete, disconnect the USB-C cable and ensure the protective ring/sleeve is closed to maintain water resistance.



Image: A close-up view of the flashlight, highlighting the USB-C charging port, which is revealed by sliding a protective cover.

Operating Instructions

Power On/Off and Mode Selection

The flashlight features a single power button for operation.

1. **To Turn On (High Mode):** Press the power button once. The flashlight will activate in its brightest (High) mode.
2. **To Cycle Modes:** After turning on, press the power button again within a few seconds to cycle to the next mode (Low). Press again for Strobe mode.
3. **To Turn Off:**
    - If the flashlight has been on for more than 5 seconds in any mode, a single press of the power button will turn it off.
    - If cycling through modes, press the button after Strobe mode to turn the flashlight off.

Adjusting the Beam (Zoom Function)

To adjust the beam from a wide floodlight to a narrow spotlight, gently push or pull the head of the flashlight forward or backward.



Image: A straight-on view of the Duracell Durabeam Ultra flashlight, showing the head and power button, which are used for beam adjustment and mode selection.

Maintenance

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:**
  - For rechargeable batteries, charge fully before long-term storage and recharge every 3-6 months to maintain battery health.
  - When using AAA alkaline batteries, remove them if the flashlight will not be used for an extended period to prevent leakage.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** Ensure the USB-C port cover is securely closed to maintain the IPX4 water resistance rating.

Troubleshooting

Problem	Possible Cause	Solution
Flashlight does not turn on.	• Low or depleted battery. • Incorrect battery installation. • Loose tail cap.	• Charge the rechargeable battery or replace AAA batteries. • Ensure batteries are inserted with correct polarity. • Tighten the tail cap securely.
Light is dim.	• Low battery level. • Flashlight is in Low mode.	• Charge the rechargeable battery or replace AAA batteries. • Press the power button to cycle to High mode.
Beam adjustment is stiff.	Dirt or debris in the zoom mechanism.	Gently clean the head of the flashlight. Avoid forcing the mechanism.
Flashlight gets warm during extended use.	Normal operation for high-lumen LED flashlights.	This is normal. If it becomes excessively hot, turn it off and allow it to cool.

Specifications

Brand	DURACELL
Model Number	1805028
Light Source Type	LED
Brightness	1200 Lumens
Power Source	Battery Powered (Rechargeable or AAA Alkaline)
Battery Type (Rechargeable)	Proprietary Rechargeable Pack (USB-C)
Battery Type (Alkaline)	4 x AAA (per flashlight)
Operating Voltage	3 Volts
Material	Metal (Aluminum) and Plastic
Water Resistance	IPX4 (Waterproof)
Approximate Length	7 inches (17.8 cm)
Color	Black/Orange

Safety Information

- Do not look directly into the LED light. The high brightness can cause temporary vision impairment.
- Keep out of reach of children.
- Do not mix old and new batteries, or different types of batteries (e.g., alkaline and rechargeable) in the same holder.

- Dispose of batteries according to local regulations.
- Do not attempt to disassemble or modify the flashlight, as this may void the warranty and pose a safety risk.
- Avoid exposing the flashlight to extreme heat or open flames.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Duracell website. Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

I have changed the batteries in my Duracell Durabeam Ultra Hybrid LED Flashlight (Model 1805028), but it still doesn't work. What should I do?

If your Duracell Durabeam Ultra Hybrid LED Flashlight (Model 1805028) is not working after a battery change, please check the following troubleshooting steps based on the manual:Check Battery Polarity: Ensure the batteries are inserted...

Read full answer

Do the LED bulbs in the Duracell Durabeam Ultra Hybrid LED Flashlight (Model 1805028) ever need replacing, and if so, how do you replace them?

Based on the instruction manual for the Duracell Durabeam Ultra Hybrid LED Flashlight (Model 1805028), the LED bulbs are not designed to be replaced by the user. LEDs are long-life components that typically last...

Read full answer