Mocagen B0DCN1WX69

Mocagen Phone Controller User Manual

Model: B0DCN1WX69

Brand: Mocagen

Introduction

The Mocagen Phone Controller is designed to enhance your mobile gaming experience on both iPhone and Android devices. It features an ergonomic design for comfortable extended play, upgraded Hall Effect joysticks for precise control, and customizable LED lighting. This controller supports a wide range of gaming platforms and offers convenient features like adjustable turbo functions and dual vibration feedback.



Image: The Mocagen Phone Controller with a smartphone inserted, showing various game and platform icons like Xbox Game Pass, PS Remote Play, and Steam Link.

Setup

Phone Compatibility and Fit

The Mocagen phone controller is designed with ample space to accommodate phones with cases, addressing the common issue of camera bulges. Its adjustable stretch mechanism can securely hold almost any phone between 4 to 7 inches, excluding iPads or tablets, ensuring it remains stable during gameplay.



Image: A diagram illustrating the generous space provided by the Mocagen controller for phones with cases, highlighting its maximum length of 7 inches.



Image: A visual representation of the controller's design, emphasizing the dedicated phone camera area and the 7-inch maximum length for phone insertion.

Bluetooth Connection

To connect your Mocagen Phone Controller via Bluetooth, ensure the controller is not charging during the pairing process.

1. Press the "B" button and the "HOME" button simultaneously until LED4 light begins to flash.
2. On your mobile device (iPhone or Android), navigate to your Bluetooth settings and locate the matching Bluetooth name (e.g., "wireless controller" or "DUALSHOCK4 wireless controller").
3. Select the controller to pair.

Once paired, you can press the "HOME" button to wake up the controller for subsequent use.



Image: A visual guide detailing the initial connection steps for both Android and iPhone devices, showing the buttons to press and the Bluetooth names to look for.

Operating Instructions

Supported Gaming Platforms

The Mocagen Phone Controller is compatible with a variety of cloud gaming platforms and services, allowing you to play your favorite games anywhere. Supported platforms include:

- Playstation Remote Play
- Xbox Game Pass
- Steam Link
- GeForce NOW
- Arcade

Popular games such as Fortnite, Minecraft, Call of Duty, and Roblox are fully supported.



Image: An illustration of the diverse gaming platforms and services that are compatible with the Mocagen Phone Controller.



Image: A display of popular game titles that can be played using the Mocagen Phone Controller.

Joystick and Button Features

The controller features upgraded Hall Effect Joysticks, designed to eliminate dead zones, drift, and wear, providing precise and responsive control, especially crucial for shooter and RPG games. The buttons are highly responsive and sensitive. Note that L2/R2 are not analog buttons.



Image: A close-up view of the upgraded Hall Effect Joystick, highlighting its 360-degree precision and low latency operation.



Image: A technical diagram explaining the Hall Effect Joystick's electromagnetic induction for precise, drift-free control.



Image: A visual guide to the controller's multi-function buttons, including Select, Home, and Directional Pad, emphasizing their responsive nature.

Turbo Function

The controller includes a 3-level turbo function, allowing you to set rapid firing speeds for various buttons (A/B/X/Y/L/ZL/R/ZR). This feature can provide a competitive edge in fast-paced games.

- To activate: Press the TURBO button simultaneously with the desired action button.
- To clear: Long press the TURBO button for 5 seconds to clear all assigned turbo functions.



Image: A visual representation of the turbo function, showing adjustable firing speeds (5/s, 12/s, 20/s) and the corresponding buttons.



Image: An illustration detailing the three available turbo speeds and how they can be used to enhance gameplay.

Cool Lighting & Dual Vibration

The Mocagen controller features multi-color changing aperture on the joysticks and ABXY buttons, allowing you to customize your gaming atmosphere. Additionally, dual motor vibration enhances game immersion, providing tactile feedback during gameplay.



Image: A visual of the controller's colorful RGB lighting, indicating how to control the lights on the joysticks and ABXY buttons.



Image: A graphic depicting the dual vibration motors within the controller, indicating haptic feedback during gameplay.

Maintenance

Battery and Charging

The controller is equipped with a built-in recyclable rechargeable battery and a USB-C charging port. It can be fully charged within 2 hours, providing approximately 15 hours of uninterrupted gameplay.
Important Note:

- The controller connects wirelessly to your mobile phone and does not support direct charging of the phone. This design prevents potential damage to your phone's charging port.
- Ensure the controller is not charging before attempting to connect it via Bluetooth.



Image: A visual breakdown of the controller's battery specifications, including 15 hours playing time, 600mAh capacity, and 2 hours charging time, with a note about not charging the phone directly.

Troubleshooting

Connection Issues

If you experience problems with Bluetooth connection, please re-verify the pairing steps outlined in the "Setup" section. Ensure the controller is not charging when attempting to connect.

Joystick or Button Malfunctions

In the event of technical issues with joysticks or buttons, such as unexpected drift or unresponsiveness, please refer to the support information provided in the "Support" section.

Specifications

Feature	Detail
Model Number (ASIN)	B0DCN1WX69
Brand	Mocagen
Phone Compatibility	iPhone (including 16/15 series), Android (4-7 inches)
Joystick Type	Upgraded Hall Effect Joysticks
Battery Capacity	600mAh (internal rechargeable)
Charging Time	Approx. 2 hours
Playing Time	Approx. 15 hours
Charging Port	USB-C
Special Features	LED Light (Joysticks, ABXY buttons), Turbo Function (3-level), Dual Vibration
Item Weight	1.01 pounds
Package Dimensions	8.23 x 5.43 x 2.64 inches
Country of Origin	China
Date First Available	September 26, 2024

Support

For any technical problems, connection issues, or general inquiries regarding your Mocagen Phone Controller, please contact Mocagen customer support. Refer to the product packaging or the retailer's website for the most current contact information.
While specific warranty details are not provided in this manual, please retain your proof of purchase for any potential warranty claims.

© 2025 Mocagen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question