Moondrop BLOCK

Moondrop Block True Wireless Earbuds Instruction Manual

Model: BLOCK

1. INTRODUCTION

Thank you for choosing the Moondrop Block True Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features such as a 13mm bass-enhanced dynamic driver, VDSF natural timbre tuning, dual-microphone beamforming ENC, and seamless monaural-binaural switching. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

Image 1.1: Moondrop Block True Wireless Earbuds (Pink) with charging case.

2. PACKAGE CONTENTS

The Moondrop Block package includes the following items:

- Moondrop Block True Wireless Earbuds (Left and Right)
- Wireless Charging Case
- User Manual (this document)

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case provides approximately 15 hours of additional battery life, while the earbuds offer up to 6 hours on a single charge.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the charging case to a power source using a compatible USB-C cable (not included).
3. The indicator light on the charging case will show the charging status. A full charge typically takes about 1

hour.

3.2 Bluetooth Pairing

Follow these steps to pair your Moondrop Block earbuds with your device:

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing light.
2. On your smartphone, tablet, laptop, or smart speaker, navigate to the Bluetooth settings.
3. Search for available devices and select "Moondrop Block" from the list.
4. Once connected, the indicator light on the earbuds will stop flashing, and your device will confirm the connection.

Image 3.1: Moondrop Block earbuds ready for pairing.

4. OPERATING INSTRUCTIONS

4.1 Wearing the Earbuds

The Moondrop Block features a flathead earbud design for a comfortable fit. Gently insert each earbud into your ear canal until it feels secure and comfortable.

Image 4.1: Proper wearing of the Moondrop Block earbud.

4.2 Touch Controls

The earbuds support touch operations for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Mode Switching:** Specific modes (e.g., gaming mode) can be toggled by pressing and holding for a designated duration (refer to specific mode instructions).

Image 4.2: Demonstrating touch operation on the earbud.

4.3 Monaural-Binaural Switching (TWS Mirroring)

The Moondrop Block supports TWS mirroring, allowing seamless switching between using both earbuds (binaural mode) or just one (monaural mode). Simply place one earbud back into the charging case, and the other will continue to function independently.

4.4 Environmental Noise Cancellation (ENC) for Calls

Equipped with dual-microphone beamforming ENC, the earbuds effectively reduce environmental noise during voice calls, ensuring clear communication.

Image 4.3: Dual-microphone beamforming ENC in action.

4.5 Low-Latency Gaming Mode

For an optimized gaming experience, the Moondrop Block features a low-latency gaming mode (55ms). Activate this mode via touch control (refer to specific mode switching instructions) to minimize audio delay during gameplay.

Image 4.4: Earbuds used for gaming with low latency.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Moisture:** Keep the earbuds and case away from water, humidity, and extreme temperatures.
- **Charging Contacts:** Ensure the charging contacts on both the earbuds and the case are clean and free of debris to maintain a reliable connection.

6. TROUBLESHOOTING

If you encounter any issues with your Moondrop Block earbuds, refer to the following common solutions:

| Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget "Moondrop Block" in your device's Bluetooth settings and re-pair. Reset the earbuds (refer to manufacturer's website for specific reset instructions if needed).
No sound from one earbud	Ensure both earbuds are charged. Place both earbuds back into the case, close it, then reopen to re-establish connection. Check device audio balance settings.
Charging issue	Ensure the charging cable is securely connected. Try a different USB-C cable and power adapter. Clean the charging contacts on the earbuds and case.
Poor call quality	Ensure earbuds are fully charged. Check for obstructions near the microphones. Move closer to your connected device to improve Bluetooth signal.

7. SPECIFICATIONS

Detailed technical specifications for the Moondrop Block True Wireless Earbuds:

- **Model Name:** BLOCK
- **Form Factor:** True Wireless
- **Ear Placement:** In Ear (Flathead design)
- **Connectivity Technology:** Wireless (Bluetooth)
- **Bluetooth Version:** 5.4
- **Bluetooth Range:** 10 meters
- **Audio Driver Type:** Dynamic Driver
- **Audio Driver Size:** 13 Millimeters
- **Diaphragm Material:** Composite Biological Diaphragm
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Battery Life (Earbuds):** 6 Hours
- **Battery Life (with Charging Case):** 6 + 15 Hours (Total 21 Hours)
- **Charging Time:** 1 Hour
- **Control Method:** Touch
- **Special Features:** Dual-Microphone Beamforming ENC, VDSF Natural Timbre Tuning, B&K5128 Tuning, Low-Latency Game Mode (55ms), TWS Mirroring
- **Compatible Devices:** Smartphones, Laptops, Tablets, Smart Speakers
- **Included Components:** Wireless Charging Case
- **Item Weight:** 2.89 ounces
- **Package Dimensions:** 2.92 x 2.48 x 2.05 inches

8. WARRANTY AND SUPPORT

Moondrop products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Moondrop website. Please retain your proof of purchase for warranty claims.

Related Documents - BLOCK

[Nekocake True Wireless Stereo Earbuds User Manual](#)
Comprehensive user manual for the Nekocake True Wireless Stereo Earbuds by Moondrop, covering introduction, packing list, product description, connection, usage, functions, specifications, and safety instructions.

Note:
1.It is not recommend to open and close charging case too frequently for daily usage.
2.It is recommended to turn on the Bluetooth first then take out earphones.

Connection   03

Connecting with new device
1.Put the earphones into charging case and keep the lid open.
2.Long press the function button on the charging case for 3 seconds till the indicator light flash white 3 times and green 1 time, the earphones will turn
to pairing mode.(If the indicator flash white 7 times means the action is failed)
3.Turn on the bluetooth, after the list is refreshed click the "Golden Ages" on the list for pairing.

*When first time using the Moondrop Nekocake QSZ-191,please put the earphone in the charging case, close the lid, connect the USB-C charging cable, and charge the earphone.

Connection   04

Automatically connection
When the earphone is turned on, it will automatically connect to the last connected device which has bluetooth pairing record if is in range.

Out of distance disconnection and auto reconnection
When the device is connected with earphones, if it disconnected by over bluetooth effective range. The earphones will try connect back to the device within 3 minutes when it is in connection range.
*If the earphones cannot be automatically connected to the device, it needs to be manually connected in the bluetooth list of the device.

Connection   05

Disconnect the current connected device
When is in using:
Make sure the earphones are in the charging case and keep the changing case lid open. Pressing the function button on thecase for 3 seconds. Theearphones will be disconnected from the current device and enter the pairing mode.
When is not in using :
Press and hold both touch zone on the earphones for 3 seconds at same time to disconnect current device and enter pairing mode.

Factory Reset
Delete "Golden Ages" from bluetooth paired list.

Connection   06

Put the earphone back to changing case and keep the charging case lid open, press the function button on the case for 10 seconds to clear pairing information and reenter into pairing mode.(The orange light will be flash once to indicate the action is successful otherwise the orange light will not twinkle)

Tip: Due to the connection characteristics of Bluetooth signals, in places where 2.4GHz electromagnetic signals are intensively disturbed, there may be occasional intermittent disconnection or no sound.

Usage   07

Charging
Put the earphones in the charging case and it will automatically start charging.
*When the battery of charging case is more than 10%, the green light will be always on until the earphones is fully charged
*When the battery of charging case is lower than 10%, the orange light will be always on unless the earphones is fully charged or the case is out of power.

Charging the case
Plug in the charging cable
The orange light will be flashing when is charging.

Usage   08

The green light will be flashing for 5 seconds after the case is fully charged then goesout.

Check battery
To check remaining battery of the charging case, press the function button on the charging case. The light will flash once with dedicated colour.
Green Light: The battery is more than 10%
Orange Light:The battery is less than 10%

Low battery alarm for charging case
Open the lid of the charging case and short press the function button, the orange lightwill flash 10 times.

Usage   09

(Now the orange light won't be flashing, the earphones won't be charging and the case will only keep the earphones shutting down)

Turn on
The earphone is in the charging case, when open the charging case lid, the ear-phones will be on automa-tically.

Turn off
Timeout shutdown: Automatic shutdown when the device is not connected for more than 3 minutes.
Low power shutdown: automatic shutdown when the battery voltage is lower than 3.89V.

Usage   10

Noise cancelling mode swithing
Turn on the earphones and long press one side of earphone for 1 second to switch between noise cancelling mode/normal mode (the beeping sound will appear within 3 seconds to inticate the action is successful.)

Function   11

Touch Zone

*The touch function can
be modified by
MOONDROP LINK APP

Operation
Voice Assistant
Click the left/right earphone 3 times to start, and click to exit
*Not of Android smartphones require operating like "Awaken voice assistant"

Music
Play/pause: Click the left/right earphone
Previous/NEXT: double-click the left earphone for the previous song, and the right earphone for the next song

Call
Answer: Click the left/right earphone
Decline: Long press left/right earphonefor 1.5s
Hang up: Click the left/right earphone
Third-party call: Click the left/right earphone, keep the original call and answer the new call, switch the calc Double-click the left/right earphone

---

Product Specifications   12

Product Model: Golden Ages
Bluetooth Version: 5.3
Codec: SBC/AAC/LC5/LDAC
Audio Distribution Profile: A2DP/AVRCP/HFP/HSP
Bluetooth Range: 10 meters (Open environment)
Battery Life: 4(Earphone)+12(Case)Hours

⚠ Please use the proper output charger than the device input which indicated in the manual(5V - 1A)

Security Instructions   13

Please read this important security instructions before using the equipment. This information contains general safety information applicable to this device and may include content not applicable to this device. Please follow the warnings and cautions to avoid injury to yourself or others or damage to your equipment.

Warning
Failure to comply with safety warnings and regulations would result in serious injury or death.
Do not use damaged power cord or plug or loose power socket
Unsafe connections can cause electric leakage or fire.
Do not use wet hands or other wet body parts to touch.

Security Instructions   14

Touch the device, power cord, plug or power socket, otherwise it may cause electric shock.
When unplugging the power cord, do not use too much force, otherwise it may cause electric shock or fire.
Do not bend or damage the power cord, otherwise it may cause electric leakage or fire.
Do not operate the device with wet hands while it is charging, otherwise it may cause electric shock.
Do not directly connect the positive and negative terminals of the charger together, otherwise it may cause a fire or cause serious injury.
Do not use the device outdoors during a thunderstorm, otherwise it may cause electric shock or equipment failure.
Use batteries, chargers, accessories and supplies approved

Security Instructions   15

by the manufacturer.
· Using external batteries or chargers may shorten the life of the battery or cause the device to malfunction. They may also cause a fire or cause the battery to explode.
· Only use chargers and data cables specially designed for equipment and approved by MOONDROP. Incompatible chargers and data cables may cause danger or damage the device.
· When customers use accessories or supplies not approved by MOONDROP,
MOONDROP is not responsible for the customers' safety.
Do not put the device in the back pocket or hang it on the waist
· Excessive force may damage the device, might cause explode

Security Instructions   16

or fire.
· If you hit or fall, you may be injured.
Do not drop the device or subject it to strong impact
· Otherwise, it may damage the device or battery, cause the device to fail to work normally, or shorten the device life.

[Moondrop Golden Ages True Wireless Earphones User Manual](#)

Comprehensive user manual for Moondrop Golden Ages true wireless earphones, covering package contents, product description, connection setup, usage instructions, functions, technical specifications, and essential security warnings.

Otherwise, it may distract you and cause accidents. Depending on your area, this may also be illegal.
Precautions for using the device during walking or moving.
Always pay attention to your surroundings to avoid harming yourself or others.
Do not paint or paste paper on the equipment
If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.
Install the device cautiously

Security Instructions

Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.
Do not drop the device or cause collision
•The device may be damaged or malfunction.
•If the device is bent or deformed, it may damage the equipment or cause parts malfunction.
Ensure the longest service life of the battery and charger
•If the battery is not used for a long time, the battery may malfunction.
•The equipment will discharge if left unused for a long time, and must be recharged before use.
•When the equipment is not in use, disconnect the power supply.

Security Instructions

•The battery can only be used for the designated purpose.
•Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused by failure to follow the warnings and instructions.
•The equipment may wear out over time. Although some parts and repairs are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.
Do not disassemble, modify or repair the equipment
•Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDROP authorized dealer.
•Do not disassemble or pierce the equipment, as this may

Security Instructions

cause an explosion or fire.
•Do not disassemble or reuse the battery.
When cleaning the equipment, please follow the following advices
•Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the earwax or dirt on the earpiece.
•Clean the battery contacts with a dry cloth.
•Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.
Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides.)Otherwise, the internal and external parts of the device may be damaged, or

Security Instructions

the performances may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.
Do not use the device for any purpose other than the designated purpose
The device may malfunction.
Avoid disturbing others when using the device in public places
Only qualified personnel are allowed to repair the device
If the equipment is repaired by unqualified personnel, the equipment may be damaged and the warranty will not be provided.
Do not distribute copyrighted content
Do not distribute copyrighted material without the permission

Security Instructions

of the content owner. This behavior violated copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.

Disclaimer
All content and services available through this device belong to third parties and are protected by copyright, patents, trademarks and other intellectual property laws. Such content and services are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service. In addition to the above restrictions, unless you have the explicit permission of the application content or service provider, you may not be able to modify, copy, republish,

Security Instructions

upload, post, transmit, translate, or repost, any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.
"Third-party content and services are provided. For any purpose, MOONDROP Company does not provide any express or implied guarantee for the content or services provided.
MOONDROP Co. expressly declares that it does not assume any implicit guarantees, Or through regulations, common law, or other means (including but not limited to marketability or applicability for specific purposes) recognized terms or conditions. In any case (including negligence), any content or service provided through this device, Even if it has been notified in advance that there is a possibility of such damage, whether it is in contract or tort, any direct, indirect, accidental, special or corresponding loss

Security Instructions

or damage compensation costs, attorney fees, various expenses or any resulting For other losses or damages, or connecting any information contained, or the results caused by you or any third party using any content or service, MOONDROP Co. does not guarantee for its accuracy, validity, timeliness, legality or completeness."
Third-party services may be stopped or interrupted at any time, and MOONDROP Co. is not responsible or guarantees for any content or the time period during which the service is available. The content and services are transmitted by third parties through networks and transmission equipment outside the control of MOONDROP. In addition to the generality of the exemption clause, MOONDROP also expressly stated that it does not assume any responsibility or obligation for any interruption or delay of any content or

Security Instructions

service applicable to this device.
MOONDROP Co. has neither responsibility nor obligation for customer service involving content and services. Any service requirements related to content or services should be directly borne by the content and service providers.

Security Instructions

Content of hazardous substances in products

Name	Harmful substances and elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Poly brominated diphenyl ether (PBDE)
Crust (shell)	X	O	O	O	O	O
Main body	X	O	O	O	O	O
Plastic parts	O	O	O	O	O	O
Accessories	X	O	O	O	O	O
battery	X	O	O	O	O	O
screw	X	O	O	O	O	O

O: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T 26572-2011. X: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement specified in GB/T 26572-2011, and there is currently no mature alternative technology to replace this substance. Please handle such products or materials properly to avoid impact on the environment and human health.

♻ RoHS ☒

FCC Warnning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

FCC Warnning

and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio / TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules.

FCC Warnning

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference,
and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

	[MOONDROP MD-TWS-040 FCC Part 15 Subpart C Test Report - Wireless Earphones](#) Official FCC Part 15 Subpart C test report for the MOONDROP MD-TWS-040 wireless earphones, detailing conducted and radiated emissions, output power, spectral density, bandwidth, and antenna requirements.
	[MOONDROP PILL Ear-clip Earbuds User Manual](#) Comprehensive user manual for the MOONDROP PILL Ear-clip Earbuds (Model: MD-OWS-003), detailing setup, functions, specifications, safety precautions, and FCC compliance information.
	[Moondrop Aria 2 Hi-Fi In-ear Monitors User Manual](#) User manual for the Moondrop Aria 2 Full-scene HiFi In-ear Monitors, covering how to wear, storage, notices, and after-sales terms.
	[MOONDROP MIAD Mobile Internet Audio Device User Manual](#) User manual for the MOONDROP MIAD Mobile Internet Audio Device, covering setup, operation, safety, and warranty information.

Documents - Moondrop – BLOCK

Play/pause: click the left/right earphone
Previous/Next: double-click the left earbud for the previous song /Double-click the right earbud for next song
Answer/hang up: click the left/right earbud
Decline: long press the left/right ear for 1.5s
Call forwarding: click the left/right earbud
Call Switching: double-click the left/right earbud
Voice Assistant: click the left/right earbud for 3 times
Music/game mode switching: click the left /right earbuds for 4 times

Charging:
Case charging: the orange light keeps on
Earbuds charging: the white light keeps on, and disappears when it's fully charged.
Low battery prompt: orange light flashes

Restore factory settings:
When the earbuds is not connected, long-press the left and right earphone 8s at the same time to clear the pairing information and reset.

Product Name: MOONDROP-BLOCK High-quality Semi-in-ear（Flat-head Earbuds）True Wireless Earphones
Model: MD-TWS-030
Bluetooth Version: 5.4
Distribution Profile: A2DP/AVRCP/HFP/HSP
Codec: AAC/SBC
Charging Port: USB-C
Working Distance: 10m（unobstructed open environment）
Support System: Bluetooth devices and mobile phones
Earphone Charging Time: About 1 hour
Charging Time Of Charging Case: About 1.5 hours
Earphone Battery Capacity: 3.7V/37mAh
Battery Capacity Of Charging Case: 3.7V/300mAh
Battery Life Of Earphone: About 6 hours（AAC）
Battery Life Of Charging Case: About 15 hours（AAC）

Please read this important security instructions before using the equipment. This information contains general safety information applicable to this device and may include content not applicable to this device. Please follow the warnings and cautions to avoid injury to yourself or others or damage to your equipment.
Warning
Failure to comply with safety warnings and regulations would result in serious injury or death.
Do not use damaged power cord or plug or loose power socket
Unsafe connections can cause electric leakage or fire.
Do not use wet hands or other wet body parts to touch.
Touch the device, power cord, plug or power socket, otherwise it may cause electric shock.
When unplugging the power cord, do not use too much force, otherwise it may cause electric shock or fire.
Do not bend or damage the power cord, otherwise it may cause electric leakage or fire.
Do not operate the device with wet hands while it is charging, otherwise it may cause electric shock.
Do not directly connect the positive and negative terminals of the charger together, otherwise it may cause a fire or cause serious injury.
Do not use the device outdoors during a thunderstorm, otherwise it may cause electric shock or equipment failure.
Use batteries, chargers, accessories and supplies approved by the manufacturer.

Using universal batteries or chargers may shorten the life of the battery or cause the device to malfunction. They may also cause a fire or cause the battery to explode.
Only use chargers and data cables specially designed for equipment and approved by MOONDROP. Incompatible chargers and data cables may cause danger or damage the device.
When customers use accessories or supplies not approved by MOONDROP.MOONDROP is not responsible for the customers' safety.
Do not put the device in the back pocket or hang it on the waist
Excessive force may damage the device, might cause explode or fire.
If you hit or fall, you may be injured.
Do not drop the device or subject it to strong impact
Otherwise, it may damage the device or battery, cause the device to fail to work normally, or shorten the device life.
It may also cause overheating, burning or other dangers.
Handle and dispose of equipment and chargers carefully
Do not throw battery or device into fire.
Do not place batteries or devices in or on heating devices (such as microwave ovens, ovens, or radiators). The device may explode if overheated.
When disposing of used battery or device, please comply with local regulations.
Do not squeeze or pierce the device.
Do not subject the device to external high voltage, otherwise it may cause internal short circuit and

overheating.
Protect equipment, batteries and chargers from damage.
Avoid exposing the device and battery to extremely cold or extremely hot temperatures.
Extreme temperature can damage the device, reduce the charging capacity of the device, and shorten the service life of the device and battery.
Do not use the data cable with the skin peeled off or damaged, and the charger with damaged or not working properly.
Do not store device near or in water heaters, microwave ovens, hot cooking equipment, or high-pressure containers
The battery may leak.
The equipment may overheat and cause a fire.
Do not use or store the device in areas where dust or aeolian materials are concentrated
Dust or foreign objects may cause device damaged, fire or electric shock.
Prevent the charger socket and the smaller end of the charger from contacting conductive materials such as liquid, dust, metal powder, or pencil lead.
Do not touch with sharp tools.Charger socket; do not bump the charger socket
Conductive materials may short-circuit or corrode the contacts, which may cause explosion or fire.
When using a wireless charger, do not place metal objects, magnets, and magnetic stripe cards between the device and the wireless charger.

The device may not charge properly or may overheat.
Do not bite or suck the device or battery
Otherwise, it may damage the equipment or cause an explosion or fire.
Children or animals can suffocate by swallowing small parts.
When children use this device, please make sure they use it correctly.
Do not poke the device or its accessories into your eyes, ears or mouth, otherwise it may cause suffocation or serious injury.
Do not use damaged or leaking batteries. For safe disposal of batteries, please contact the nearest authorized service center.
The device and some accessories (sold separately) contain magnets. The American Heart Association and the British Medicines and Health Products Administration also warned that magnets will affect implantable pacemakers, heart rhythm converters, defibrillators, insulin pumps or other electronic medical devices (collectively referred to as "medical devices") within 15 cm. operating. If you are a user of any of these medical devices, please do not use this device and some accessories (sold separately) before consulting a doctor.
Note
Failure to comply with safety precautions and regulations can lead to personal injury or property damage
Do not use the device near other electronic devices
Most electronic devices use radio frequency signals. Your device may interfere with other electronic

devices.
Equipment with speakers is particularly susceptible to interference.
Do not use your device in places that may be interfered by radio frequency such as hospitals, airplanes or cars
If possible, use the device beyond 37cm of the pacemaker to avoid interference with the pacemaker.
In order to minimize the interference of the device to the pacemaker, please use the device on the side of opposite to the pacemaker.
If you use medical equipment, please contact the medical equipment manufacturer before using this device to determine whether it will be affected by the radio frequency emitted by this device.
During air flight, the use of electronic equipment will interfere with the airplane's electronic navigator. Follow the airline's regulations and the instructions of the "aircraft crew. If the equipment is allowed, please always use the flight mode."
The electronic equipment of the car may malfunction due to radio interference from the equipment.
For details, please contact the manufacturer.
Do not place the device in a place with dense smoke or fog
Otherwise, the surface of the device may be damaged or may cause malfunction.
If you use hearing aids and cochlear implants, please contact the manufacturer for information about radio interference.
The radio frequencies emitted by this device may interfere with certain hearing aids and cochlear implants. Before using this equipment, please contact the manufacturer to determine whether the

equipment will be affected by the radio frequencies emitted by this equipment.
Do not use the device near radio frequency devices or instruments (such as audio systems or radio antenna towers)
Radio frequency may cause device malfunction.
Turn off the device in a potentially explosive environment
Always operate in accordance with regulations, instructions and signs in an explosive environment.
Do not use the equipment in gas stations or near flammable materials, chemical agents and explosive areas.
Do not store or carry flammable liquids, gases or explosive materials in boxes containing device and accessories.
If any part of the device is damaged, smokes, or smells of burning things, please stop using the device immediately. The equipment can not be reused until it being repaired by the MOONDROP Service Center.

Broken glass may hurt your hands and face.

If the device emits smoke or the smell of burning things, it may cause the battery to explode or burn.

Please observe all safety warnings and regulations regarding the use of equipment while driving. Driving safely is your primary responsibility while driving. If prohibited by law, please do not use the device while driving. For the safety of you and others, please follow the safety warnings and relevant regulations and remember the following tips:

Place the equipment in an easy-to-access location. No need to look away from the road to get the

---

wireless device.

In order to avoid danger, pause the call in traffic jams or bad weather conditions (rain, sleet, snow, ice).

Rain and sleet, snow, ice and heavy traffic can cause danger.

Do not record voice memos. Recording a language memo while driving prevents you from focusing on the primary responsibility of driving safely.

According to the traffic situation, decide whether to answer the call reasonably. Answer calls when not moving forward or in traffic jams. Try to call after parking.

Do not engage in nervous or excited conversations to avoid distraction. Please let the caller know that you are driving.

Property maintain and use equipment

Keep the equipment dry

Moisture and liquid can damage equipment parts or circuits.

Do not turn on the device when it is wet. If the device is turned on, turn it off (If the device cannot be turned off, please maintain the status quo). Then dry the equipment with a towel and contact the local MOONDROP service center.

Water damage to the equipment will invalidate the manufacturer's warranty.This equipment is equipped with a built-in liquid indicator.

The device should be stored on a flat ground.If the device falls, it will be damaged.

The device can be used where the atmosphere temperature is between 0°C and 35°C. You can store the device where the ambient temperature is between -20 °C and 50 °C. Using or storing the device outside

---

the recommended temperature range may cause damage to the device or shorten battery life

Do not store the device in extremely hot areas, such as in a car in summer, otherwise, the equipment may be damaged or the battery may explode.

Do not expose the device to direct sunlight for a long time, such as on the dashboard of a car. Do not store the device with metal objects such as coins, keys and necklaces.

The device may be scratched or malfunction.

If the battery contacts come in contact with metal objects, it may cause a fire.

Do not store the device near magnetic fields

When exposed to a magnetic field, the device may malfunction or the battery may discharge.

Magnetic stripe cards (including credit cards, phone cards, bank books and boarding cards) may be damaged by magnetic fields.Avoid contact with the device when it is overheated. Otherwise it may cause low temperature burns, redness and skin pigmentation

After using the device for a long time, pay attention to the heating of the device and avoid contact with the skin for too long.

Do not sit on the device, or keep in direct contact with your skin for a long time while the device is charging or connected to the power source.

High temperature resistance varies from person to person. Please pay special attention when using it by children, the elderly.Protect hearing and ears when using earplugs

Excessive exposure to strong sounds can cause hearing loss.

Contact with strong sounds while walking may distract you and cause accidents.

Always turn down the volume before using earplugs, and use only the lowest volume required to listen to conversations or music.

If there are foreign objects on the earplugs, and you wear the earplugs for a long time, it may cause ear infections. Please keep the earplugs dry and clean.

In a dry environment, static electricity may accumulate in the earplugs. Avoid using this earplug in a dry environment, or touch metal objects to discharge static electricity before using the earplug.

Do not use headphones while driving or riding a horse. Otherwise, it may distract you and cause accidents. Depending on your area, this may also be illegal.

Precautions for using the device during walking or moving.

Always pay attention to your surroundings to avoid harming yourself or others.

Do not paint or paste paper on the equipment

If you are allergic to the paint or metal parts of the device, it may cause itching, eczema or swelling of the skin. When the above situation occurs, please stop using the device and consult a doctor.

Install the device cautiously

Do not place equipment and accessories in or near the airbag deployment area. If the equipment is improperly placed, the airbag inflates rapidly, which can cause serious injury.

Do not drop the device or cause collision

The device may be damaged or malfunction.

If the device is bent or deformed, it may damage the equipment or cause parts malfunction.

Ensure the longest service life of the battery and charger

If the battery is not used for a long time, the battery may malfunction.

The equipment will discharge if left unused for a long time, and must be recharged before use.

When the equipment is not in use, disconnect the power supply.

The battery can only be used for the designated purpose.

Follow all the instructions in this manual to ensure the longest service life of the device and battery. The manufacturer will not provide warranty for damage or poor performance caused by failure to follow the warnings and instructions.

The equipment may wear out over time. Although some parts and repairs are guaranteed during the validity period, damage or deformation caused by the use of unapproved accessories is not covered by the warranty.

Do not disassemble, modify or repair the equipment

Any changes or modifications to the equipment will cause the manufacturer to not guarantee the equipment. For repairing, please contact your local MOONDROP authorized dealer.

Do not disassemble or pierce the equipment, as this may cause an explosion or fire.

Do not disassemble or reuse the battery.

When cleaning the equipment, please follow the following advices

Use a soft and dry cloth to wipe the device, use a brush or other tools to remove the earwax or dirt on the earpiece.

Clean the battery contacts with a dry cloth.

Do not use chemicals or cleaning agents. Otherwise, the surface of the equipment may be discolored or corroded, and it may also cause electric shock or fire.

Prevent the equipment from contact with dust, sweat, ink, oil, and chemical products (such as cosmetics, antibacterial sprays, hand sanitizers, detergents and insecticides.)Otherwise, the internal and external parts of the device may be damaged, or the performance may deteriorate. If the device comes into contact with any of the above-mentioned substances, please wipe it with a soft, lint-free cloth.

Do not use the device for any purpose other than the designated purpose

The device may malfunction.

Avoid disturbing others when using the device in public places

Only qualified personnel are allowed to repair the device

If the equipment is repaired by unqualified personnel, the equipment may be damaged and the warranty will not be provided.

Do not distribute copyrighted content

Do not distribute copyrighted material without the permission of the content owner. This behavior violated copyright law. The manufacturer is not responsible for any legal problems caused by any illegal actions by users against copyrighted content.

Disclaimer

All content and services available through this device belong to third parties and are protected by copyright, patents, trademarks and other intellectual property laws. Such content and services

---

are only for personal non-commercial use. Without the permission of the content owner or service provider, you may not be able to use any content or service. In addition to the above restrictions, unless you have the explicit permission of the application content or service provider, you may not be able to modify, copy, republish, upload, post, transmit, translate, or repost, any content or service displayed through this device. sell, create new derivative works, develop or distribute in any way.

"Third-party content and services are provided. For any purpose, MOONDROP Company does not provide any express or implied guarantees for the content or services provided. MOONDROP Co. expressly declares that it does not assume any implicit guarantees, Or through regulations, common law, or other means [including but not limited to marketability or applicability for specific purposes] recognized terms or conditions. In any case (including negligence), any content or service provided through this device, Even if it has been notified in advance that there is a possibility of such damage, whether it is in contract or tort, any direct, indirect, accidental, special or corresponding loss or damage compensation costs, attorney fees, various expenses or any resulting for other losses or damages, or connecting any information contained, or the results caused by you or any third party using any content or service, MOONDROP Co. does not guarantees for its accuracy, validity, timeliness, legality or completeness."

Third-party services may be stopped or interrupted at any time, and MOONDROP Co. is not responsible or guarantees for any content or the time period during which the service is available. The content and services are transmitted by third parties through networks and

---

transmission equipment outside the control of MOONDROP. In addition to the generality of the exemption clause, MOONDROP also expressly stated that it does not assume any responsibility or obligation for any interruption or delay of any content or service applicable to this device.

MOONDROP Co has neither responsibility nor obligation for customer service involving content and services. Any service requirements related to content or services should be directly borne by the content and service providers.


Content of hazardous substances in products

Name	Hazardous substances and elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium(crⅥⅠ)	Polybrominated biphenyls (BB)	Poly Australian Diphenyl Ether (PBDE)
Circuit components	X	O	O	O	O	O
Metal parts	O	O	O	O	O	O
Plastic parts	O	O	O	O	O	O
speaker	O	O	O	O	O	O
battery	X	O	O	O	O	O
annex	X	O	O	O	O	O

This form is compiled in accordance with SJ/T 11364.

O: Indicates that the amount of the hazardous substance in all homogeneous materials

[pdf] User Manual

PM0355 23 Force and Ion 2011 Software User Manual pmd lkalb Megatouch Manuals Repair Help Technical Support meritgames Center manuals 80 |||

Megatouch Ion 2011 and Force 2011 Software User Manual Visit us on the Web at http://www.amientertai ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:17 filesize: 2.97 M page_count: 48 document date: 2010-08-03

[pdf] Guide

Arms and Equipment Guide D 3e Cagle Decker Quick Redman Wyatt Eric And the eye eu public Books rpg rem uz Dungeons Dragons 3 5

CONTENTS CONTENTS Cost of Hirelings. . . . . 61 Adventuri ... lacks rigging, this statistic is omitted. For dirigibles, the rigging sta- THE VEHICLE STATISTICS **BLOCK** tistic represents the durability of the balloon. Ram: The damage dealt by the vehicle if it r...

lang:en score:15 filesize: 2.71 M page_count: 161 document date: 2007-05-24

[pdf] User Manual Owner's Manual

PM0636 14 Ion Standard and Widescreen Aurora 2K11 UNRELEASED pmd lkalb megatouch ion aurora ws touchscreen video game operators service manual merit ami entertainment bmigaming Games Manuals 80

To Purchase This Item, Visit BMI Gaming www.bmigaming.com 800 746-2255 1.561.391.7200 Ion A ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:15 filesize: 1.05 M page_count: 59 document date: 2013-03-15

Ion Aurora
Installation & Owner's
Manual

FOR TECHNICAL ASSISTANCE:
CONTACT YOUR LOCAL DISTRIBUTOR

ami

PM0636-14

[pdf] User Manual Owner's Manual

PM0636 14 Ion Standard and Widescreen Aurora 2K11 UNRELEASED pmd lkalb megatouch ion aurora touchscreen video game operators service manual merit ami entertainment bmigaming Games Manuals 80

To Purchase This Item, Visit BMI Gaming www.bmigaming.com 800 746-2255 1.561.391.7200 Ion A ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:14 filesize: 1.07 M page_count: 67 document date: 2013-03-14

Ion Rx
Installation & Owner's
Manual

FOR TECHNICAL ASSISTANCE:
CONTACT YOUR LOCAL DISTRIBUTOR
For a list of distributors, visit Merit Entertainment's Web site
www.meritgames.com

PM0721-01

Ion Rx Installation & Owner's Manual - Merit Entertainment

Comprehensive installation and owner's manual for the Merit Entertainment Ion Rx Megatouch gaming system. Covers setup, maintenance, software configuration, troubleshooting, and warranty information.

lang:en score:14 filesize: 1.2 M page_count: 56 document date: 2008-12-11

[pdf] Guide Catalog

Arms and Equipment Guide D 3e Cagle Decker Quick Redman Wyatt Eric the eye eu public Books rpg rem uz Dungeons Dragons 3rd Edition 3 0e Core

Arms and equipment guideTM Credits Designers: ERIC CAGLE, JESSE DECKER, JEFF QUICK, AND JAMES WYATT ... lacks rigging, this statistic is omitted. For dirigibles, the rigging sta- THE VEHICLE STATISTICS **BLOCK** tistic represents the durability of the balloon. Ram: The damage dealt by the vehicle if it r...

lang:en score:14 filesize: 3.03 M page_count: 162 document date: 2016-05-30

[AMI Ion Rx Installation and Owner's Manual](#)

Comprehensive guide for installing, operating, and maintaining the AMI Ion Rx amusement game machine. Covers setup, troubleshooting, and software configuration for optimal performance.

lang:en score:14 filesize: 3.47 M page_count: 64 document date: 2010-08-03

[Merit Megatouch Gametime Owner's Manual](#)

Comprehensive owner's manual for the Merit Megatouch Gametime video game machine, covering setup, operation, maintenance, troubleshooting, and software features. Includes safety instructions, game descriptions, menu navigation, internet connectivity, warranty, and software license agreements.

lang:en score:14 filesize: 3.57 M page_count: 36 document date: 0000-00-00

[pdf] Catalog

Wholesale Letterpress PLAY View our 2022 Catalog here LetterpressPlay Web 0217 v 1645220485 cdn shopify s files 1 0067 7432 5312 |||

L E T T E R P R E S S P L AY. C O M AUSTIN, TEXAS Sustainability, Community, Play Kyle Hawley P ... s charities. Our paper products employ a full range of printing methods using lead or wooden type, **block**s, or polymer plates. We print by hand or with machines dating back to the Industrial Revolutio...

lang:en score:13 filesize: 12.8 M page_count: 47 document date: 2022-02-18

[pdf] Catalog

Click here to the 2022 Letterpress PLAY CatalogCatalog PLAY0421 LetterpressPlay Catalog Webcdn shopify s files 1 0067 7432 5312 0421 Web v 1650666389 |||

L E T T E R P R E S S P L AY. C O M AUSTIN, TEXAS Sustainability, Community, Play Kyle Hawley P ... s charities. Our paper products employ a full range of printing methods using lead or wooden type, **block**s, or polymer plates. We print by hand or with machines dating back to the Industrial Revolutio...

lang:en score:13 filesize: 12.87 M page_count: 47 document date: 2022-04-21

[pdf] User Manual Owner's Manual Diagram

PM0673 05 Megatouch Entertainer 2K10 pmd lkalb Manuals Repair Help and Technical Support meritgames Center Ion Wallette |||

Megatouch Wallette and Megatouch Entertainer Installation Owner s Manual FOR TECHNICAL ASSISTANCE: ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:13 filesize: 4.06 M page_count: 64 document date: 2009-09-18

[pdf] User Manual Instructions

PM0503 10 I2K6 EVO V2 01 wireless pmd lkalb AB Soft Megatouch Gametime user manual 543634 archive org manualsbase id

FOR TECHNICAL ASSISTANCE: CONTACT YOUR LOCAL AUTHORIZED DEALER For a list of dealers, visit the Game ... . Heed all warnings. 4. Follow all instructions. 5. Do not use this apparatus near water. 6. Do not **block** any ventilation openings. Install in accordance with the manufacturer s instructions. 7. Do no...

lang:en score:13 filesize: 1.07 M page_count: 36 document date: 2007-11-26

Ion Fusion Installation & Owner's Manual - AMI Entertainment Network
Detailed installation and owner's manual for the AMI Entertainment Network Ion Fusion arcade game. Covers setup, maintenance, software configuration, networking, and troubleshooting.
lang:en score:13 filesize: 1.16 M page_count: 64 document date: 2009-06-18

[pdf] Test Report

Test Report BT PART1 Chengdu shuiyueyu technology Co Ltd MD HP 023 2AY45 2AY45MDHP023 md hp

Shenzhen CTA Testing Technology Co., Ltd. Room 106, Building 1, Yibaolai Industrial Park, Qiaotou Co ... t 5 2.4 Short description of the Equipment under Test EUT 5 2.5 EUT operation mode 6 2.6 **Block** Diagram of Test Setup 6 2.7 Related Submittal s / Grant s 6 2.8 Modifications 6 3 ...

lang:en score:11 filesize: 5.52 M page_count: 35 document date: 2024-09-04

Megatouch Wallette and Entertainer Installation & Owner's Manual

Comprehensive installation and owner's manual for AMI Entertainment Network's Megatouch Wallette and Megatouch Entertainer amusement game systems. Covers setup, maintenance, troubleshooting, and software configuration.

lang:en score:11 filesize: 4.06 M page_count: 64 document date: 2010-08-03

[pdf] User Manual Owner's Manual

PM0773 01 Megatouch FireFly owner s manual 2K10 5 UNRELEASED pmd spisarek Welcome to the first portable system Before you begin your installation should determine best place meritgames Support Center Firefly

Megatouch FireFly Installation Owner s Manual PM0773-01 Table of Contents Before You Begin ... ... l Mode on and off in order to ensure accurate bookkeeping. Rental Mode allows players to purchase a **block** of time and use it to play as many games as they want in that time. To enable Rental Mode, tou...

lang:en score:11 filesize: 804.15 K page_count: 52 document date: 2010-08-11

[pdf] User Manual Owner's Manual Instructions

PM0721 05 Ion Rx owner s manual 2K10 pmd lkalb Megatouch it is important that they be replaced Watchdog Timer This game has been equipped with a fea part number HW0339 01 can or and Snap Shot meritgames Support Center

Ion Rx Installation Owner s Manual FOR TECHNICAL ASSISTANCE: CONTACT YOUR LOCAL DISTRIBUTOR For a ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:11 filesize: 3.46 M page_count: 64 document date: 2009-09-18

[pdf] User Manual Owner's Manual Instructions

PM0636 12 Ion Standard and Widescreen Aurora 2K10 unreleased pmd spisarek Installation Owner s Manual Megatouch Repair Mega Lease Link MegaNet MegaWeb TournaMAXX game will display the Main Menu Screen Number of Free Credits meritgames Support Center

Ion Aurora Installation Owner s Manual FOR TECHNICAL ASSISTANCE: CONTACT YOUR LOCAL DISTRIBUTOR Fo ... ed on this screen with the up and down arrows. The currency amount will apply to each 15minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:11 filesize: 1.37 M page_count: 68 document date: 2009-09-18

[pdf] User Manual Owner's Manual Flyer Borchure

PM0636 08 Ion Standard Aurora 2K9 V26 UNRELEASED pmd spisarek Installation Owner s Manual megatouch aurora touchscreen video game brochure merit ami entertainment FOR TECHNICAL ASSISTANCE CONTACT YOUR LOCAL DISTRIBUTOR For a list of distributors visit the Merit Entertainment Web site meritgames bmigaming Games Flyers arcade games

To Purchase This Item, Visit BMI Gaming www.bmigaming.com 800 746-2255 1.561.391.7200 Ion A ... d on this screen with the up and down arrows. The currency amount will apply to each 15-minute time **block** selected by the customer. FIGURE 5 - COINLESS COIN-OP MENU SETTINGS SCREEN FIGURE 4 - PLAYER...

lang:en score:11 filesize: 937.45 K page_count: 46 document date: 2013-03-15

[Megatouch Ion Elite Edge Installation & Owner's Manual](#)
Installation and owner's manual for the Megatouch Ion Elite Edge video game system, covering setup, operation, maintenance, software, networking, and troubleshooting.
lang:en score:11 filesize: 1.08 M page_count: 60 document date: 2009-06-18

[MOONDROP MD-TWS-040 FCC Part 15 Subpart C Test Report - Wireless Earphones](#)
Official FCC Part 15 Subpart C test report for the MOONDROP MD-TWS-040 wireless earphones, detailing conducted and radiated emissions, output power, spectral density, bandwidth, and antenna requirements.
lang:en score:10 filesize: 4.62 M page_count: 35 document date: 2024-09-19

[pdf] Specifications Test Report
EMC TRF Template Tara Mitchell Test report part 1 Chengdu shuiyueyu technology Co Ltd MD TWS 039 2AY45 2AY45MDTWS039 md tws
Shenzhen CTA Testing Technology Co., Ltd. Room 106, Building 1, Yibaolai Industrial Park, Qiaotou Co ... n of the Equipment under Test EUT 5 2.5 EUT configuration 5 2.6 EUT operation mode 6 2.7 **Block** Diagram of Test Setup 6 2.8 Related Submittal s / Grant s 6 2.9 Modifications 6 3 ...
lang:en score:10 filesize: 5.72 M page_count: 32 document date: 2025-02-20

MOONDROP DL-TWS-001 FCC Part 15.247 Test Report and Technical Specifications

FCC Part 15.247 test report for the MOONDROP DL-TWS-001 wireless audio device, covering conducted and radiated emissions, power output, bandwidth, and spectral density tests performed by Shenzhen CTA Testing Technology Co., Ltd.

lang:en score:10 filesize: 5.8 M page_count: 45 document date: 2024-09-11

[pdf] Test Report

EMC TRF Template Tara Mitchell Test report part 1 Chengdu shuiyueyu technology Co Ltd MD TWS 039 2AY45 2AY45MDTWS039 md tws

Shenzhen CTA Testing Technology Co., Ltd. Room 106, Building 1, Yibaolai Industrial Park, Qiaotou Co ... n of the Equipment under Test EUT 5 2.5 EUT configuration 5 2.6 EUT operation mode 6 2.7 **Block** Diagram of Test Setup 6 2.8 Related Submittal s / Grant s 6 2.9 Modifications 6 3 ...

lang:en score:9 filesize: 5.8 M page_count: 35 document date: 2025-02-20