Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR SS2-XS

VEVOR X-Small 2-Wheel Dog Wheelchair Instruction Manual

Model: SS2-XS | Brand: VEVOR

1. Introduction

This manual provides detailed instructions for the assembly, adjustment, and proper use of your VEVOR X-Small 2-Wheel Dog Wheelchair. This device is designed to provide mobility assistance for pets with hind limb weakness, injury, or paralysis, allowing them to regain activity and improve their quality of life. Please read all instructions carefully before use to ensure the safety and comfort of your pet.

2. Product Features

- **Aerospace-grade Aluminum Alloy:** Constructed from strong, lightweight, and corrosion-resistant aluminum alloy for durability and ease of use.
- **Exclusive Design:** Features an aluminum frame, adjustable straps, EVA wheels, foam leg straps, and a 1.5m/4.92ft dog leash, specifically designed for pets with disabled hind legs.
- **Adjustable Size:** The wheelchair can be adjusted in length, width, and height to fit various small dogs up to 15 lbs, supporting pets with hind leg issues while maintaining normal front leg function.
- **Easy Installation:** Simple assembly process with no additional tools required beyond those provided.
- **Comfortable Drive:** Equipped with 5.5-inch EVA wheels and secure straps for a smooth, quiet, and stable ride on various surfaces.



Image: A beagle dog demonstrating the lightweight aluminum alloy frame and comfortable design of the VEVOR wheelchair.

3. Package Contents

Upon opening the package, you should find the following components:

- Main Wheelchair Frame with Harness (Sheff)
- Toolkit (L-shaped small tool, screws, hex wrench)
- Two Wheels
- Dog Leash (1.5m / 4.92ft)
- Instruction Manual



Image: Overview of all included components for the VEVOR dog wheelchair, including the frame, wheels, toolkit, and leash.

4. Sizing Guide

Accurate measurement of your pet is crucial for proper fit and comfort. Please measure the **Back Height** (from ground to back), **Hip Width**, and **Body Length** (from center of front legs to butt) of your dog. Refer to the table below for the X-Small size specifications.



Image: Detailed sizing chart and measurement guide for VEVOR dog wheelchairs.

X-Small Size Specifications

Measurement	Range
Back Height	19-47 cm (7.5-18.5 in)
Hip Width	14-24 cm (5.5-9.4 in)
Body Length	23.5-43 cm (9.3-16.9 in)
Pet Weight	Up to 6.8 kg (15 lbs)

Note: This wheelchair is primarily designed for dogs. For cats, a specialized cat wheelchair is recommended due to their slender body structure.

5. Assembly and Setup

Follow these steps to assemble your VEVOR dog wheelchair. For a visual guide, please refer to the embedded installation video.

1. **Prepare the Frame:** Lay the main frame flat. Ensure the frame is oriented correctly with the harness facing upwards.
2. **Attach the Wheels:** Insert the wheel brackets into the designated guide holes on the frame. Ensure the holes in the aluminum frame align with the holes in the black guides. The fit may be tight to ensure stability; apply firm pressure to fully insert. Secure each wheel bracket with the provided screws and tighten using the hex wrench. Ensure the wheels face outward.
3. **Adjust Width (if necessary):** For X-Small and Small models, one transparent set screw is used on each wheel bracket. For Medium and Large models, two transparent set screws are required. These screws are located on the back side of the frame and adjust the width.
4. **Initial Harness Adjustment:** Loosen all adjustable straps on the harness.



Image: Visual guide for the 4-step installation process of the dog wheelchair.

▶ **Watch video online**

Installation Instructions for VEVOR Dog Wheelchair

Video: Official VEVOR Installation Instructions for the Dog Wheelchair. This video demonstrates the step-by-step assembly and initial adjustments of the wheelchair components.

6. Adjustments

The VEVOR dog wheelchair offers multiple adjustment points to ensure a custom and comfortable fit for your pet.

- **Length Adjustment:** Loosen the transparent screw on the side of the main frame. Press the ball pin and slide the frame to adjust the length according to your pet's body length. Tighten the screw once the desired length is achieved.
- **Height Adjustment:** The vertical posts for the wheels have multiple holes. Adjust the height by selecting the appropriate hole and securing it with the transparent set screw.
- **Width Adjustment:** The rear crossbar has multiple holes for width adjustment. Insert the transparent set screws into the desired holes to match your pet's hip width.
- **Harness Straps:** The harness features adjustable straps with Velcro and buckles. Adjust all straps (chest, belly, and leg straps) to be snug but not overly tight, ensuring your pet can move comfortably without chafing. After adjustment, secure the straps to prevent slipping.



Image: Illustration of the various adjustment points for length, width, and height on the VEVOR dog wheelchair.

7. Operation and Usage

Introducing your pet to the wheelchair requires patience and positive reinforcement.

1. **Placing Your Pet:** Unfasten the buckles and open the Velcro on the hind leg harness. Gently lift your pet and place their hind legs into the leg support loops. Secure the harness around their body, ensuring a snug and comfortable fit.
2. **Initial Adaptation:** Not all pets will be comfortable with a wheelchair immediately. Some may be afraid of unfamiliar equipment or the feeling of restraints. Allow your pet time to adapt. Start with short sessions in a familiar, safe environment.
3. **Assisted Movement:** Use the provided leash to gently guide and support your pet as they learn to walk in the wheelchair. Slowly pull your pet along to help them understand how to move.
4. **Encouragement:** Provide comfort, praise, and treats to encourage your pet. Gradually increase the duration of use as your pet becomes more accustomed to the wheelchair. The goal is for them to eventually walk freely by themselves.
5. **Hind Leg Support Loops:** The wheelchair includes two support loops for the hind legs. Depending on your pet's condition, you may remove them if not needed. To open and adjust, pull the clip towards the black foam cylinder to create

a loop, then close the clip to lock in the desired size.



Image: Close-up of the harness design, highlighting the integrated leg protection sleeve and wide waistband for enhanced support.

8. Maintenance

Regular maintenance will prolong the life of your pet's wheelchair.

- **Cleaning:** Wipe down the aluminum frame with a damp cloth. The fabric harness can be hand-washed with mild soap and air-dried.
- **Inspect Wheels:** Periodically check the EVA wheels for wear and tear. Ensure they spin freely and the lock nuts are secure.
- **Check Fasteners:** Regularly inspect all screws, buckles, and Velcro straps for tightness and integrity. Tighten any loose screws and replace worn components if necessary.
- **Storage:** Store the wheelchair in a clean, dry place when not in use.

9. Troubleshooting

If you encounter issues with your VEVOR dog wheelchair, consider the following:

- **Pet Refuses to Move:** Ensure the wheelchair is properly adjusted to your pet's size. Incorrect sizing can cause discomfort. Start with very short training sessions and use positive reinforcement (treats, praise).
- **Wheelchair Feels Unstable:** Double-check all screws and adjustment points to ensure they are securely tightened. Verify that the wheels are correctly inserted and facing outward.
- **Straps Slipping:** Ensure all harness straps are tightened and secured as shown in the adjustment section. Loose straps can cause the harness to slip off.
- **Difficulty Inserting Screws:** If you have trouble inserting screws, check the hole alignment between the bracket and the guide hole. Some force may be required initially as the black guide hole has no threading, but ensure the screw is not cross-threading.

If you have further questions or require assistance during the installation or use of your VEVOR dog wheelchair, please contact our after-sales customer service team for support. We are committed to helping you resolve any issues you may encounter.

10. Specifications

Specification	Detail
Item Model Number	SS2-XS
Materials	Aerospace-Grade Aluminum Alloy, Fabric
Weight Range	Up to 15 lbs (6.8 kg)
Net Weight	1.2 kg / 2.6 lbs
Maximum Dimensions (L×W×H)	445×260×375 mm / 17.91×10.23×14.76 inch
Minimum Dimensions (L×W×H)	255×160×190 mm / 10×6.29×7.48 inch
Front Wheel Diameter	5.5 Inches
Harness Type	3 Point, Adjustable Straps
Number of Wheels	2
Color	Blue



Image: Visual representation of the VEVOR dog wheelchair's specifications and dimensions.

11. Warranty and Support

VEVOR products are designed for quality and durability. For information regarding warranty coverage, returns, or technical support, please refer to the official VEVOR website or contact our customer service directly. Keep your purchase receipt for warranty claims.

Thank you for choosing VEVOR for your pet's mobility needs. We wish you and your pet the best of luck in their journey towards increased mobility!

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDPBPRPN

More documents and user manuals: **https://manuals.plus/**