Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Metz 40MTE6000Z

Metz 40" Smart TV MTE6000 FHD Google TV

User Manual

1. Introduction

Thank you for choosing the Metz 40" Smart TV MTE6000. This manual provides essential information for setting up, operating, and maintaining your new television. Please read it thoroughly before using the product to ensure safe and optimal performance.

The Metz MTE6000 offers a superior viewing experience with its FHD resolution, HDR10 support, and Trochilus Extreme 2.0 technology for enhanced contrast and vivid colors. Enjoy immersive audio with Dolby Audio, and navigate your entertainment seamlessly with the integrated Google TV platform and voice remote control. Advanced Eye Care features, including blue light reduction and flicker-free display, are designed to protect your vision and enhance viewing comfort.



Figure 1.1: Metz 40" Smart TV MTE6000

This image shows the front view of the Metz 40" Smart TV MTE6000, highlighting its slim bezels and the "40"" display size. Logos for TÜV Rheinland Eye Care Certified, Trochilus Extreme 2.0, Boundless Screen, Dolby Audio, Hey Google, and Google TV are visible on the screen, indicating key features.

2. Setup

2.1 Unpacking and Contents

Carefully remove all items from the packaging. Ensure all components are present and undamaged.

The box should contain:

- 1 x Metz 40" Smart TV
- 1 x Remote Control
- 2 x AAA Batteries (for remote control)
- 1 x Power Cable
- 1 x Quick Guide (Manual)
- 4 x Screws (for base assembly)
- 2 x Support Bases

2.2 Attaching the Base

To ensure stability, attach the two support bases to the bottom of the TV. Place the TV face down on a soft, clean surface to prevent screen damage.

1. Align each support base with the corresponding slots on the bottom of the TV.
2. Secure each base using the provided screws. Tighten firmly but do not overtighten.



Figure 2.1: TV Dimensions and Inputs/Ports

This image provides a detailed diagram of the Metz 40" Smart TV, showing its dimensions with and without the base, and its weight. It also illustrates the various input and output ports available on the side and back of the TV, including HDMI, USB, DVB-S/S2, CI Slot, Digital Audio Out, LAN, AV, DVB-T/T2/DVB-C ATV, and Headphone jack.

2.3 Connecting Peripherals

Connect your external devices to the appropriate ports on the TV. Refer to Figure 2.1 for port locations.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes. (2 ports available)
- **USB:** Connect USB drives for media playback. (2 ports available)
- **Ethernet (LAN):** For wired internet connection.
- **DVB-T/T2/C/S/S2:** For antenna or satellite connections.
- **Digital Audio Out:** For connecting to external audio systems.
- **Headphone:** For private listening.

2.4 Initial Power On and Setup Wizard

After connecting the power cable, press the power button on the remote control or TV. The TV will guide you through the

initial setup process.

1. Select your preferred language.
2. Connect to your Wi-Fi network or use a wired Ethernet connection.
3. Sign in with your Google account to access Google TV features and apps.
4. Follow the on-screen prompts to complete channel scanning and other settings.

3. Operating Instructions

3.1 Basic TV Operation

- **Power On/Off:** Press the **Power** button on the remote control.
- **Input Selection:** Press the **Source** button to switch between HDMI, TV, USB, etc.
- **Volume Control:** Use the **Volume +/-** buttons.
- **Channel Change:** Use the **Channel +/-** buttons.
- **Navigation:** Use the directional pad and **OK** button to navigate menus.

3.2 Google TV Features

Your Metz MTE6000 TV comes with Google TV, providing a personalized and intuitive entertainment experience.

- **Personalized Content:** Google TV organizes movies, shows, and live TV from all your apps and subscriptions, tailored to your interests.
- **App Access:** Access over 8000 apps, including popular streaming services like Netflix, YouTube, Prime Video, and Disney+.
- **Voice Control (Hey Google):** Press the Google Assistant button on your remote and speak commands to search for content, control smart home devices, get answers, and more.



Figure 3.1: Google TV Interface

This image displays the Google TV home screen, showcasing a wide variety of streaming applications and personalized content recommendations. It highlights the extensive app ecosystem available through Google TV.



Figure 3.2: Hey Google Voice Control

This image demonstrates the "Hey Google" voice control feature, showing a user holding the remote and speaking a command. The TV screen displays weather information, illustrating the smart assistant's capabilities.

3.3 Picture Quality Enhancements

- **HDR10:** High Dynamic Range 10 provides a wider range of colors and contrast, resulting in more realistic and vibrant images.
- **Trochilus Extreme 2.0:** This advanced image processing technology optimizes picture quality by enhancing color, contrast, and clarity.



Figure 3.3: Trochilus Extreme and HDR10 Comparison

This image illustrates the visual difference provided by Trochilus Extreme and HDR10 technologies. The left side of the screen shows an image with enhanced color and contrast, labeled "Trochilus Extreme HDR 10", while the right side shows a "Normal" image with less vibrancy, demonstrating the improvement.

3.4 Audio Quality with Dolby Audio

Experience rich, clear, and immersive sound with Dolby Audio technology, enhancing your viewing experience by bringing every detail to life.



Figure 3.4: Dolby Audio Experience

This image depicts a TV displaying a concert scene, with sound waves emanating from the screen, symbolizing the immersive cinematic audio experience provided by Dolby Audio technology.

3.5 Eye Care Features

The Metz MTE6000 is designed with your eye health in mind, incorporating features to reduce eye strain during prolonged viewing.

- **Flicker-Free Display:** Reduces screen flickering, which can cause eye fatigue and discomfort.
- **Low Blue Light Emission:** Minimizes harmful blue light, promoting a more relaxing and visually comfortable entertainment experience, especially during night viewing.
- **Night Mode:** Adjusts screen settings for comfortable viewing in low-light conditions.
- **Automatic Volume Control:** Helps maintain consistent audio levels to prevent sudden loud noises.



Figure 3.5: Flicker-Free Display

This image compares a flicker-free display (left) with a flickering display (right), showing visible horizontal lines on the latter, illustrating how the Metz TV's technology provides a more comfortable viewing experience.



Figure 3.6: Reduced Blue Light Emission

This image explains the reduced blue light emission feature, showing a spectrum graph comparing harmful blue light with the Metz TV's optimized light output, designed for eye comfort.



Figure 3.7: Health Platform Features

This image illustrates the "Health Platform" features, including Night Mode, Eye Protection, and Automatic Volume Control, all designed to enhance the viewing experience and protect user's eyes and ears.

4. Maintenance

4.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry, lint-free cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.

4.2 Software Updates

Your TV may receive software updates periodically to improve performance and add new features. Ensure your TV is

connected to the internet to receive these updates.

- Navigate to **Settings > System > About > System update**to check for and install updates manually.
- It is recommended to enable automatic updates for convenience.

5. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet issue	Ensure power cable is securely plugged in; Try a different power outlet.
No picture, but sound is present	Incorrect input source; Loose HDMI/AV cable	Press the **Source** button to select the correct input; Check cable connections.
No sound, but picture is present	Volume muted or too low; External audio system issue	Unmute volume or increase level; Check connections to external audio devices.
Remote control not working	Batteries depleted; Obstruction between remote and TV	Replace batteries; Remove any obstructions; Ensure remote is pointed at the TV's IR sensor.
Cannot connect to Wi-Fi	Incorrect password; Router issue; TV too far from router	Re-enter Wi-Fi password; Restart router; Move TV closer to router or use wired connection.

6. Specifications

Feature	Detail
Brand	Metz
Model Number	40MTE6000Z
Screen Size	40 Inches / 102 cm
Display Technology	LED
Resolution	1080p (Full HD)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Special Features	Flat, HDR10, Trochilus Extreme 2.0, Dolby Audio, Google TV, Eye Care (Flicker-Free, Low Blue Light)
Connectivity Technology	Bluetooth, Wi-Fi, USB, Ethernet, HDMI
Product Dimensions (with stand)	89.2 x 21.4 x 56.5 cm (W x D x H)
Product Dimensions (without stand)	89.2 x 7.4 x 51.1 cm (W x D x H)
Weight (with stand)	6.56 kg

Feature	Detail
Energy Efficiency Class	E
Energy Consumption (SDR)	37 kWh/1000h
Energy Consumption (HDR)	58 kWh/1000h
Components Included	TV, Remote Control, Manual, Base



Figure 6.1: Energy Efficiency Label

This image displays the EU energy efficiency label for the Metz 40MTE6000Z TV, showing its energy class 'E' and consumption rates for SDR (37 kWh/1000h) and HDR (58 kWh/1000h). A QR code is also visible, linking to more product information.

For more detailed energy information, visit the EPREL database.

7. Warranty and Support

Your Metz TV comes with a standard warranty. For specific details regarding warranty coverage and duration, please refer to the warranty card included in the packaging or visit the official Metz website.

Returns Policy: If you wish to return a product within 30 days of receipt because you have changed your mind, please consult the Amazon return policy page. If you have received a defective or damaged product, please consult the Amazon help page for damaged items. For specific information on purchases made on the Marketplace, please consult the Amazon help page for Marketplace purchases.

For technical support, product inquiries, or service requests, please contact Metz customer service or visit their official support channels. You can often find contact information on the manufacturer's website or in the quick start guide.

Metz Official Store: Visit the Metz Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DDQCFBRX

More documents and user manuals: **https://manuals.plus/**